

P/N	Description	P/N	Description
572B101	A-2 Technology	121D104	Acer 6511TW w/W in keys Fcc:JVP KBS-W IN "L" Shaped Enter Key
466C112	ABB #6053T Universal Keyboard	349D105	Acer 6312KW w/W in(Euro) Fcc:JVPKBS-WIN
297C135	ABB(ASEA) 47DSIH80	279D104	Acer 6311TW/6511HW "L"enter Fcc:JVPKBS-WIN
87D129	ABB Advant DCS	281D104	Acer 6311KW/6511KW Win "L" Fcc:JVPKBS-WIN
413C90	Abbott Axsym Keyboard	266D84	Acer Acenote Light 350PCX(PORT) Fcc:HLZ350P
413G83	Accuratus KYB500-K82A	475D104	Acer 6514 Fcc:JVP6511
584G105	Accurates KYBAC 276-OUPK (Euro)	521D105	Acer 6512-C W/Win (EURO) Fcc: JVPKBS-WIN
631G88	Accurates KYB-MON2M IX-LCUH (Euro)	587D104	Acer 6311-C Fcc: JVPKBS-W IN W/W IN KEYS
776C102	Ace Natural Ergo Kybrd (also Addison, PC Concepts, Chicony)	598D104	Acer 6511AW Fcc: JVP KBS-W in W/ Win
288D104	Ace Model F-21 W/ Win keys Fcc :GOGAPC-21	600D105A-B	Acer Ergo Keyboard Fcc:JVPERGO Numeric Pad Separate unit
229D105	Ace Model F-21, F-21J w/Win keys Fcc: GOGAPC-21 (single left shift key)	610D104	Acer 6511-Q Fcc:JVP6511Q W/Win Keys
441D104	Ace F-21,F21D, fcc:GOGAPC-F-21 win/curve spacebar	611D105	Acer 6511-Q (Euro) Fcc: JVP6511Q w/W in Keys
457D105	Ace GOGAPC-21 W/Win keys, Single right shift key Curve spacebar, back-L enter	664D104	Acer 6511-M Fcc: JVP6511M (also Tangent)
756D105	Ace F-21J(X) Fcc:GOGAPC21, Back- L enter	658D86	Acer 7100 T Fcc:HLZ970T (also Texas Instrument)
792D109	Ace F21XQ Fcc:GOGAPC-F-21 (also Softkey,APC)	879D105	Acer 6512-P Fcc:JVP6511-P "7" enter
193E125	Ace F21GQ, Fcc:GOGAPC21, "7" enter	139E107	Acer 6511-TA, back L enter
789C85	Acekey ACK-500 Mini Keyboard (also Unitek)	920D108	Acer 6512-TA (Euro)"7" enter
245D88	Acekey ACK-595 w/Win keys Fcc:L2BACEKEY595	929D108	Acer 6512-VA (Euro) "7" enter
790C101	Acekey ACK-200 Fcc:H2UACEKEY200 (also Unitek)	961D105	Acer 6512-V (Euro) "7" enter
791C101	Acekey ACK-700 Fcc:L2ACEKEY700 (also Unitek)	93E119	Acer 6512-VM (Euro) Multimedia "7"enter
998D102	Acekey ACK-700 UKDin (Euro) Fcc:L2ACEKEY700	951D108	Acer 6512-HA (Euro) "7" enter
415D108	Acekey ACK360/220 Fcc:L2BACEKEY220 (also Cirque)	966D86	Acer #720 Fcc:722itx W/win, rec enter, glidepoint
359D105	Acekey ACK-310 Fcc: L2BACKEY310 (Also Supermac)	29E87	Acer WIL-172U, Fcc:JVPWIL, Windows, mousebutton
640D90	Acekey ACK-540 Fcc: L2BACKEY540	86E86	Acer Travelmate 602TER, M/N 1902, Glidepoint
814D105	Acekey ACK-210 Fcc: L2BACEKEY210	89E86	Acer Travelmate 507DX, M/N 1901, Glidepoint
807D104	Acekey ACK-295 Fcc: L2BACEKEY295 (also Netier)	452E89	Acer Travelmate C100 series, M/N MS2101, Rec enter
734D105	Acekey ACK-295 (Euro) Fcc:L2BACEKEY295	153E104	Acer 6511CX, back-L enter
659D104	Acekey KB9000 Fcc:LFACKEY1 (also KTX)	154E105	Acer 6511CX (Euro), "7" enter
789D109	Acekey KB9000(E) Fcc:LFACKEY1	190E118	Acer 6512-JV (Euro), Multimedia, "7" enter
26E107	Acekey 260A Fcc:L2BACEKEY260A, 3 Multimedia, Curve spacebar, back-L enter (also Logitech)	261E112	Acer 6512-G (Euro), "7" enter, Multimedia
62E88	Acekey ACK-550 Fcc:L2BACEKEY550, w/Windows	262E108	Acer 6512-X (Euro), "7" enter, Multimedia
204E104	Acekey ACK-700, back-L enter	293E117	Acer 6511-UV, back-L enter, Multimedia
214E91	Acekey ACK-570,ACK-571, Wireless keybd., Recenter	538E108	Acer 6512-HK (Euro) "7" enter
291E104	Acekey K2726, Back-L enter, c/c reader (also Unitech)	608E107	Acer 6511WA, Back-L enter, 3keys above arrows
392E108	Acekey ATEZ-9000 (Euro), "7" enter, w/windows	640E90	Acer Travelmate 800, model ZG15
517E105	Acekey ACK-720 (Euro), "7" enter, (also Unitech)	643E110	Acer 6512-JY (Euro)
637E109	Acekey ACK-730, Glidepoint, Back-L enter	1986B104	Acer 6511-XA
725E107	Acekey ACK-270A, back-L enter, Curve Spacebar (Also Logitech)	846E91	Acer 4151 Laptop
854E107	Acekey 201A	900E115	Acer KU-0355, SK9610
908E105	Acekey 206UA (Euro), 3 hot buttons, "7" shape enter	47G116	Acer KU-0355 (Euro)
927E88	Acekey ACK573	1840B107	Acer 6511VA
86G111	Acekey 2100H	1356B084	Acer 370C - A cernote Light
529E101	Acekey ACK-91	263G122	Acer KU0420, 9893301 (also Fellowes)
168G108	Acekey 260UAC - Japanese Layout	377G84	Acer ZG-5 laptop - Keys Only
169G106	Acekey 260UAC - Korean Layout	477G84	Acer VG5 laptop - Keys Only
422G91	Acekey ACK5010U (also Adesso)	503G103	Acer A spire 5738/5738Z/5738G - Keys Only
565G107	Acekey ACK581	581G113	Acer SK9625
73B101	Acer Data 101/710/910/915/1100/1030, 6311-K (8x19.5) model APC-HA410 (also NEC, Multitech, Cannon, Stone System, Delta Gold, Texas Instrument, Data General) Fcc: QG87EE6011	603G114	Acer SK9625 (Euro)
810B101	Acer 6011/6311/6511/6511-N, KB101 (18 X7.5), Fcc: GQ86311-K, Rec. Enter (also Acros)	514G86	Acer Timeline 4820T/4810T - keys only lapbp
645B102	Acer MF II 102 Germany 6312-K, Fcc:GQ86311-K (Euro) (also Data General)	516G103	Acer 7740/7740G/5542N/5542W/5810PG 77405691-keys only
961A97	Acer 900 MKO22035641 (also Multitech)	537G85	Acer D250-1821 Aspire
157C102	Acer 6012(Euro)	539G89	Acer Aspire 5920
324C101	Acer 6311G Fcc:GQ86311G	556G88	Acer Aspire 5512/5513/5514/5515-17/5520 Keys only
382C101	Acer 6311-B (also Acros)	559G103	Acer Aspire 5810/5910T/5536/7735/5410/5738 Keys
609C101	Acer 6511-T Fcc:JUP-6511-T	568G99	Acer Aspire 5532/5534/5732 keys only
675C101	Acer 6311K Fcc:JUP6311 ("L" shaped enter)	604G105	Acer KB0759 (Euro)
482C82	Acer V386SL Laptop Fcc:GQ8V386SL	810B101	Acros 200/386SX(also Acer)
494C102	Acer 6512-T (Euro) Fcc:JVP6511-T	382C101	Acros 6311-B (also Acer)
178D105	Acer 6512-TW (Euro) w/W in keys	730B102	Actebis K104 (Euro) (also Montrey, Amax)
516C101	Acer 6311-W ,6311-KE (also Smith Corona)	511E108	Acteck AT-9900-1 (Euro) Fcc: ZDK8QL6908W
15D101	Acer 6511-H Rec. Enter Fcc: JVP-6511-H	512E126	Acteck AT-EZ8810 (Euro)
303D104	Acer 6511-HW Fcc:JVPKBS-WIN rec enter	772E136	Acteck EZ-7000, AT-7000XP, (Euro), Multimedia
134D105	Acer 6511-HW (EURO) W/Win keys Fcc:JVP6511H	773E108	Acteck AT-9910 (Euro)
97D101	Acer 6511-K11 Fcc:JVP6511 "L" shaped enter	774E129	Acteck EZ-9930, AT-9930 (Euro), Multimedia
		424C101	Addison KB5311 (also Chicony, Compudyne)
		720C92	Addison KB5591 w/trackball FCC:E8HKB5591 (also Chicony)
		776C102	Addison KB-7001 FCC:LIAKB7000 (also Ace, PC Concepts, Chicony)
		52A72	Adds Viewpoint A-2 old Style w/Raised border
		378A81	Adds Viewpoint A-2 New Version
		382A98	Adds Viewpoint 60

P/N	Description	P/N	Description
623A99	Adds Viewpoint 60(+) Color	959E108	AI- 98T WK808/KT808 - Back L enter (also WK)
634A98	Adds Viewpoint 60(+) Color(New Larger Shift Key)	509C101	AIC-KNS Keyboard
175B87	Adds 78	157D101	AIC-KNS Keyboard (Lower Keys than 509C101)
764A83	Adds 1010	662D104	AIC Cybemet Keyboard
767A100	Adds 2020	253B84	AID 84 Switch, AID-3
81B100	Adds/NCR 4940	437D84	AID 84 Switch (same as above but flaps under)
209B112	Adds 3220	736B82	AID-3 (KURT CHECK XT)
538C101	Adds 4000 P/N 006-9801788, 119967-001, Fcc:AQ6ZRT687XT "L" Shaped Enter Key (also Esprit, Hitek)	918B101	AID EKT-101(also Kodak)
70C106	Adds PC+4000(also NCR,Hitek,Tandem)	423C102	AID EKT-102 (Euro)(also Kodak)
70C106	Adds TS-530 (also Hitek,NCR,Hitek)	712B59	AID MK057
898C106	Adds 120049-001 #006-980149,RT665DT (also Hitek)	94E109	AIMC SK1689(Euro),Fcc:GYUR89SK,"7" enter, (also Compaq, Dell, Liteon)
13D105	Adds Ansi 598-004308	404E107	Alaska Scorpius KII+ (also Qtronix)
129C105	Adds Ansi P/N 2970-9003-9000 (also NCR)	241E108	Alaska Scorpius KII+ (Euro), "7" enter (also Qtronix)
478C101	Adds 598-0010481 M/N 121674-001 (also AST,Compaq,Hitek,NEC,NCD)	296E115	Alaska SK2690, P/N KK2690R2E, (Euro), "7" enter Multimedia
767B108	Adds 598-001-2208, P/N297-9003-9000, 598-0013684 (also Dec)	619E109	Alaska KB-AK2002R, Fcc:ZITK-105M (also Pro)
285E101	Adds ASCII598-0011717, rec enter, (also Wyse)	712E125	Alaska Multimedia keyboard Fcc:IZITK-105M (also Professional)
38D106	Adesso AEK606 ERGO Fcc:KJXKB-205	192G104	Alaska 61923
69D103	Adesso AEK-202 Propoint w/mousebutton Fcc:GM8M AK105TB	99C125	Alphamerique One(European)
71D105	Adesso AEK-305 Softouch Plus, Fcc:KJXKB205	103B106	Alpha Micro 106
72D107	Adesso AEK806 Truform ERGO Fcc:KJXEKB105MJ	592B106	Alpha Micro Model 62
289D108	Adesso EKB104MJ(MCK-108P) TRUFORM ERGO w/ trackball Fcc:KJXEKB104MJ	82B106	Alpha Micro Model 62A(also Ampex)
290D107	Adesso PCK-308T TRUFORM ERGO w/glidepad Fcc:KJXEKB104MJ	692B102	Alpha Micro 65 (3 lights)(also Link, Wyse)
291D108	Adesso AEK-906T TRUFORM ERGO w/glidepoint Fcc:KJXEKB105MJ	966C80	AlphasmartALF-B01 FCC:K2VALPHASMART001
292D105	Adesso PCK208A TRUFORM MCK208 Fcc:KJKEKB104MJ	471D80	Alphasmart2000/3000 port Fcc:K2VALPHASMART001
293D105	Adesso PCK301 NUFORM ERGO Fcc:GM8EKB804	228E81	Alphasmart3000 (Euro), Fcc:K2VALPHASMART003
294D107	Adesso PCK303T NUFORM ERGO w/Glidepoint Fcc:GM8EKB804	539E90	Alphasmart Dana, Neo #NON-PVT, Rec enter
295D106	Adesso AEK501 NUFORM ERGO "MAC" version Fcc:KJXEKB105MJ	77C101	Alps SM-101
310D108	Adesso AEK503T Mac NUFORM ERGO w/touchpad Fcc:KJXEKB105MJ	609B101	Alps MPS101 AT101 (also Dell,Samsung)
296D108	Adesso PCK-302P (EKB-804MJ) w/touchpoint FccKJXEKB804MJ	372C101	Alps MDS101 Fcc:GYIMIDAS101-102
514D105	Adesso KB405 Fcc:KJXKB405	109D101	Alps MCL-101 #10080500 Fcc:GYISAT-101-102 "L" shaped Enter Key
346E109	Adesso WKB-120, back-L enter, Glidepoint	153D101	Alps Metro/AT101 ME39490 FCC:LPZMETRO
347E110	Adesso Trueform EKB-2000TP, PCK-308T, Fcc: KJXEKB104MJ	231D108	Alps Glide point Model MGL, Fcc: CWT CME ASC, w/win keys split-spacebar "L" enter key
348E108	Adesso Trueform EKB-2000, MCK208, Fcc:KJXEKB104MJ	278D109	Alps Glidepoint Model MGM-106 w/win keys, split-spacebar, "L" enter key FCC:CWTCMEASC
529E101	Adesso MCK-91 (also Ortek)	560D104	ALPS "WB" SERIES w/Win Fcc:CWTKFRCE
741E109	Adesso KB2101PUSG	35B101	ALR 386 (also Maxiswitch,Everex,Gateway, Opus,Easy Data,Avtech,Texas Microsystems)
802E88	Adesso AKB901	477C101	ALR RT-101(+) 119135-001 rev.B 119637 Fcc:AQ6ZG-RT-667XT
853E124	Adesso EL-9805PB illuminated multimedia keyboard	286C101	Alton SK-8843-IU (also Liteon)
20G90	Adesso WKB-4000US -rect. enter -older version	385A101	Altos III/386/Altos V (also Wyse)
102G90	Adesso AKB-410 UB, Rec enter	840A101	Altos VII (also Wyse)
135G102	Adesso WKB-3000UB	730B102	Am ax (also Monterey,Actebis)
546D106	Adesso TKB970 (also PC Concepts)	841A102	Amdek 102 Key (also Wyse,Arnet)840358-16
329G138	Adesso AKB-4200UB	803E91	Amino JKWL03
422G91	Adesso ACK5010U (also Acekey)	520A105	Amkey 105 Switch
418G116	Adesso TruForm Pro PCK-308UB	799B80	Amkey Trackball #93-002
431G87	Adesso AKB110B	140C130	Amkey 130-0001
497G87	Adesso WKB4000BB, 2keys right shift -newer version	357E70	Amkey model 70-0017
520G90	Adesso WKB3100UB Mini with trackball	478A86	Ampex 210/210(+)
583G115	Adesso AKB130US	646A105	Ampex 220 (also Phillips)
593G122	Adesso AKB131UB	570A111	Ampex 230 (also Televideo)
600G105	Adesso WKB4200UB	82B106	Ampex 230(+)/219/232/270/280 (also Alpha Micro)
154C108	ADP 507CT (108 keys)	812A85	Amstrad 1512 P.C.1640
151C101	ADP 505MT/507CT	867B101	Amstrad PPC 512
03C107	ADP 502MT/M22	591A94	Ann Arbor V269
774B101	ADP 503/504MT	158A77	Ann Arbor 400E
711B101	ADP APC920MXT	797B101	Ancer Research DFK121/171/191 (also Datacomp,Asser,Diamond Flower)
986C101	ADP 508VT (also Chicony)	111D104	Ancer KB8000 KF191 w/Windows Keys FCC:KM988KKB88191
848B101	AEG Olympia EO3601(also Keytronics)	2017B104	Ancer DFK191-WB13P
850D88	Ager Model# 862, Fcc:FMA862, Multimedia Laptop	310G95	Anyware W9829BK
338B101	AGI 386/486 (also Keytronics, Premier, Datamax, Mitsubishi,Goldstar, Spear Technologies,Gateway)	553D104	AOPEN KB850P P/N 90.0007.21 (Also Keytronics)
		14E107	AOPEN KB898AS Ergo, Windows, back-L enter KBWIN98, (also Monterey)
		971D108	AOPEN KB898AS (Euro) Ergo, Windows, "7" enter
		188E123	AOPEN KB-SP910PS2 (Euro), Multimedia, "7" enter
		279E107	AOPEN KB855,KB-858 back-L enter (also Monterey) 3 keys above directional keys

P/N	Description	P/N	Description
463E107	AOPEN KB-858, 90.00029.58B, 90.00029.UB20 Rec. enter	782A102	Apricot XEN-I(European)
301E107	AOPEN #90-00007.A01, Rec enter, 3 keys above arrows	584B101	ARC KB518 1(also Chicony,Hyundai, Magn avox,Head start,Identity)
599E107	AOPEN 90.00029.868 (also Monterey)	9799B080	ARC notebook 386SX
585E107	AOPEN 90.00029.823 Back-L enter	652B101	Arch Rival 386SX(also Hitek,Micronics)
948E112	AOPEN 90.00029.959 (also Logitech)	445C101	Arche SK4100R-1U (also Liteon)
411G108	AOPEN KM826	172E94	Argonaut 900X, Glidepoint, Rec enter, Win.
114G108	AOPEN KN826 (Euro) "7" enter	213E94	Argonaut Model#7521, Rec enter, Glidepoint
913B101	APC 101	381E95	Argonaut Model #8575, wins., Glidepoint, Multimedia
258C101	APC 101 (notepad)(also Fame) Fcc:GOG3YL-5539	509E90	Argonaut P14N Laptop, Rec enter, Glidepoint
40D101	APC-21 Fcc:GOGAPC-21 (also DTK)	510E95	Argonaut 8640, Rec enter, Glidepoint
309D101	APC F-21 GO GAPC-2 1 (also PC Concepts)	642E93	Argonaut R15GN/ Ranger 1500M, Glidepoint
441D104	APC F-21,21D Fcc:GOGAPC-2 1 W/W in curve spacebar	152G91	Argonaut D15TS-WL Fcc: PD9WM3945ABG laptop
457D105	APC F-21 Fcc:GOGAPC-21 W/Win, Single right shift key, Curve Spacebar	153G89	Argonaut S14Y laptop
288D104	APC F-21 Fcc:GOGAPC-21 W/WIN (ALSO ACE)	841A102	Arnet Multiuser 102 (also Wyse,Amdek)
229D105	APC F-21, F-21J, w/WIN KEYS,FCC:GOGAPC-21 Single left shift key	802A101	Arnet Multiuser 101 (also Keytronics, AT&T,Samsung,Dell,Rita,US101)
711B101	APC 920 MXT(also Hitek,NCD)	417G93	Artech GK5, GK520DG6
388D105	APC NBK-2104S/C 875644 (EURO) Fcc: GOGAPC-21	647B81	ASEA MA214/215
756D105	APC-21J(X) Fcc:GOGAPC21, Back-L enter	756A138	ASEA DSIH 70 Keyboard
792D109	APC F21XQ Fcc:GOGAPC-F-2 1 (also ACE, Softkey)	297C135	ASEA 47DS IH 80 Keyboard
860D109	APC F-21, W/win keys, Back-L enter, Curve Spacebar (also Nimble)	298B134	ASEA Keyboard BG5735
909D109	APC F-21YQ (SPK-2000) Fcc:GOGAPC21, Curve Spcbr	797B101	Aser DFK121/171/191(also Datacomp, Aner Research,Diamond Flower) Fcc:FBX5E9DFK121
438E123	APC PC-200055, multimedia, back-L enter (also Perfect Choice)	41D102	Aser DFK-172/192 (EURO) Fcc:FBX5E9DFK171M
439E125	APC PC-200048, Fcc:GOGAPC-F21, Back L enter, Multimedia (also Perfect Choice)	718E136	Aspect Braille keyboard model #3192
05C108	Apollo/HP A1630-82001	176G88	ASK-3000H (also Solidtek)
54C106	Apollo/HP 7121 Rev 1	21B101	AST Enhanced
275A52	Apple II(II+)	672B101	AST KB101 Taiwan 230082(also T.I.)
407A62	Apple II(C)	774B101	AST Enhanced 230098(RT-101+) NMB CMG65001(also Hitek,Versyss)
482B65	Apple II(c) Plus	478C101	AST Bravo 230402-001A FCC:AQ6ZG-RT687XT KB101 119127-001, Sk1200, Fcc:GYUR15SK (also Hitek,Compaq,NEC,Dec,NCD)
87A63	Apple II(E)	275C82	AST Laptop 386SX/20 Model 43V
785A81	Apple II(E) Enhanced Platinum	254C101	AST SKR1032 (also Radio Shack,Se Jin,Trigem)
728A80	Apple IIGS MO330	550C82	AST Power/Exec. 3/25i
709C105	Apple Design M2980/2891 "UNIVERSAL" Spacebar Fcc:BCGM2980	737C83	AST Bravo NB Laptop w/trackball FCC:HFSLK4
763C106	Apple Design M2980 (European)	579C101	AST SK-1100 230612-001-A FCC:GYUR10SK (also Liteon,Dell)
121A76	Apple Lisa	808C83	AST Ascenia 900A Laptop
274A58	Apple Mac M0110	936C101	AST SK1200 #230851-001C FCC:GYUR15SK (also Liteon, Hitek)
789B81	Apple Mac Classic/LC MO487	957C104	AST RT-6655TW W/Windows Keys (also Liteon, Hitek, Compaq) FCC:AQ6MTN7Z15
974B81	Apple Mac Classic/LC (European)	170D86	AST Ascenia "J" Series
645A78	Apple Mac (+)M0110A	171D81	AST Ascenia "P" Series
835A81	Apple Mac SE M0116	172D82	AST Ascenia 950N
676B82	Apple Mac SE (European) M0118	596D89	AST Ascenia "M" Series W/Touchpad, Windows
936A105	Apple Mac Extended-Enhanced MO115	124D104	AST 4958TW (also Dec, Hitek)
696B105	Apple Mac ExtEnh II (M0312)(M3501)	585D104	AST SEM-DC8H FCC:E2XSEM-DC8H (also Samsung)
785B106	Apple Mac ExtII (European)	358E108	AST SEM-DC8L (Euro), Fcc:E2XSEM-DC8L
209C63	Apple Powerbook 140/145/170 Port.	9922B082	AST Powerexec EL model 83 Notebook Digital PCP34
198D77	Apple Powerbook 520C/540C FCC:BCGM4880	851B101	Astrix 101 (SEE HITEK FOR OTHER MODELS)
505C101A-D	Apple Norsij Adjustable Keyboard (4 pc. set) FCC:DEV-001-0085-01	341G103	ASUS Y-BP62A, rect. enter
980C101A-D	Apple Norsij Adjustable (EURO) (4 pc. set) FCC:DEV-001-0085-01	392G80	ASUS 700, 800
677D97	Apple iMac, M2542	536G86	ASUS EKC-1
699D98	Apple iMac (Euro)	538G100	ASUS KS2003
66E79	Apple iBook M/N M2453, M6411	542B106	AT 1127
75E108	Apple iMac, Pro, G4, M7803	692D101	ATR SK710 Fcc:GYUR12SK (also LiteOn)
108E109	Apple iMac (Euro) Pro, G4, M7803	791B101	AT&T 305/305B FCC:A5593MK-305
386E79	Apple Powerbook G4, model A1001, Glidepoint	236C102	AT&T 305D-LA(also Keytronics)(Euro)
563E109	Apple Emac, G5, A1048, 9034LLA, A1046, Bluetooth	237C102	AT&T 305B-LA (Euro)FCC:AS593MK305
1966B109	Apple A1048, Rect enter key	802A101	AT&T 304/605 (also Arnet,Keytronics, Samsung,Dell,Rita,US101)
542E79	Apple iBook M6497 - 11" , Rec enter	271C102	AT&T 304 (102 Keys)EO3417202
33G78	Apple Mac Pro 15" - A1211 MA609LL/A	660B102	AT&T 705
105G108	Apple Slimline A1243, Rec enter	847B101	AT&T New 705(also Keytronics)
127G110	Apple Slimline A1243 (Euro), "7" enter	508A83	AT&T 6300 (301)
128G79	Apple A 1255 (Euro)	553A84	AT&T 6300(+)(302)
252G78	Apple Mac Pro A1286 15.4", MB470LLA	943A101	AT&T 6310 (303) (also Keytronics, Radio Shack, Phillips)
295G78	Apple Mini Keyboard A1242		
298G78	Apple Mac Pro, Mac Air		
806A57	Applied Dynamics 57 Switch		

P/N	Description	P/N	Description
745A103	AT&T 56K 430	332C101	BTC 5 139 BPCS#120019 (also Packard Bell, Reveal) FCC: E5XKBM111 "L" enter key
777A102	AT&T 56K 470 4425	647C102	BTC 5 149(Euro)102 Keys (also Packard Bell)
700A122	AT&T 6500	947A102	BTC 5161/5339 Enhanced (also Packard Bell, Hyundai,Minta)
707B122	AT&T NEW 6500 (raised f keys)	710C101	BTC 5130 BPCS#120032 FDA1021, SK2100, Fcc:E5XK BM10 140, (also Packard Bell)
528A103	AT&T 7300	884C101	BTC 5169 (rec. Enter) FCC:E5XKBM111
744A98	AT&T 56K 420	529B102	BTC 5339R-O/5349R-O/5339SX Back-L enter (also Pack Bell, Goldstar,Tatung,KLH,Hewitt Rand)
131C102	AT&T 306E(also Keytronics)	449C101	BTC 53 Series rectangular Enter Key,no macro Fcc: E5X5R BTC-5339R-O
153C103	AT&T 306E-FC (also Keytronics)	697C102	BTC 53 Series 5339R-O (France-Euro)
272C98	AT&T EO 35550 01 (also Keytronics)	962B102	BTC 5339RO (S.A.)(EUROPEAN)
416C117	AT&T model OSPS code 56K 114AOP	184C102	BTC 5349(Euro) (also Pack Bell,Facit, Mitac,Donatec)
520C138	AT&T Switchboard Keyboard #501013528 Fcc:CIG8AVEO3417 (also Keytronics)	492C101	BTC 5369 (also Leading Edge)
526A62	Atari 800	116C101	BTC-7000 Series 7339R/7339S
481B84	Atari Mega 1040ST	698C102	BTC-FT-7000 (Euro)7849R FCC:E5X5R5BTC(also IPC)
409C95	Atari Mega STE	649C101	BTC 7XX9/7139 FCC:E5XKBP10110
611B134	Atex (European)	711C101	BTC 7939 BPCS120029 FCC:E5XKMP10140
129B101	Austin 386 KB5161(also Chicony,Samsung)	812C102	BTC "BTD-53 Series" FCC:E5X5R5BTC
768C85	Austin laptop	865C101	BTC 55 Series Fcc: LAKBTC-55 SERIES
36C101	Auva KB2101/2102 FCC:HWIA2KB21012 (also Chicony.Handok,Kris Tech,Lead Edge)	07D104	BTC 5539K/55XX w/Windows Keys FCC:LAK55XXX-A1
472C80	Avanti 025 Portable FCC:17NSX025	08D105	BTC 5131C/SK2100W/BPCS#120059/FDA1051 Win Keys "L" Enter FCC:E5XKBM10510 (also Packard Bell)
342B101	Avar 101 Enhanced	182D104	BTC 5140 w/windows keys FCC:E5XKBM10410
35B101	Avtech 200,270 386SX (also Easysdata, Everex, Maxiswitch, Gateway,ALR,Opus,Texas Micro)	214D105	BTC 5140 w/windows (EURO) FCC:E5XKBM10410
938B101	Azuka KB3000/SMK corp	238D105	BTC 5549 w/win keys(Euro) FCC:LAK55XX-K-A-1
749B96	Baublys STG12 (European)	428D104	BTC 5530K w/win keys FCC:LAK55XXX-A2
627A74	BBC MicroComputer	321D105	BTC 5530K-SP (Euro)w/win keys FCC:LAK55XXX-A2
653D105	Belkin KB6868 Fcc: F8E206 (also Precision)	464D110	BTC 8110 Fcc:E5XKBP10920U W/Win
997D109	Belkin KB6868 Fcc:F8E206, 3 extra keys above directionals (also Precision)	183D108	BTC 8120 ERGO 2 part keyboard w/windows Fcc:E5XKBP10910U
210E107	Belkin KB6868 Fcc:F8E206BLK, back-L enter	375D104	BTC 7931 FCC: E5XKBP10410U
395E108	Belkin F8E208-BLK, ERGO, (KB23-BLK), Fcc: MWIEZ-9000, Back-L enter, Split spacebar	356D104	BTC 5121 FCC: E5XKBM104M10UC w/win "L"enter
455E108	Belkin KB6868, F8E200, Back-L enter	140E104	BTC 5121 FCC: E5XKBM104M10UC w/win Rec enter (also Micron)
625E107	Belkin KB-885, F8E885-BLK, Back-L enter	361D105	BTC 5121 (Euro) E5XKBM104 M10UC w/win keys
727E126	Belkin KB-820, F8E820, Multimedia, back-L enterkey	752D107	BTC 5121W Fcc:E5XKB5121WTH0110 Back-L enter Three extra keys above Directional keys
1236B104	Belkin FE206, 104key, rect enter	851D108	BTC 5121W (Euro) Fcc:E5XKB5121WTH0110, Win,"7"enter
788E104	Belkin F8E206USB - Rect enter key	922D108	BTC 5201 (Euro) "7" enter
842E108	Belkin F8E223, KB6869, 2 purple keys above directional	809D86	BTC 5510M Mini keyboard, Rec enter, Windows
903E105	Belkin KB887, Fcc: F8E887-BLK Rec enter	56E107	BTC 5123S/5201 Fcc:E5XKB5121WTH0110, Back-L
09G118	Belkin F8E32 Fcc:K7SF8E32KYBD	237E107	BTC KB5201 Fcc: E5XKB5121 WTH0110 back L enter
11G123	Belkin KB-837, F8E837-BLK	74E120	BTC 9000, Fcc:E5XKB9000TH0010, Multimedia
12G112	Belkin F8E815, Fcc: K7SF8E815KYPD "7" enter	105E109	BTC KB5301 (Euro), Fcc:E5XKB5301, "7" enter
976B105	Bell & Howell 105ST(also Honeywell)	236E107	BTC KB5199, KB5197, Fcc:E5XKB5199, back-L enter
745C105	Bell & Howell P/N 21356 (also Keytronics)	312E109	BTC KB5199 (Euro), Fcc: E5XKB5199, "7" enter
746C105	Bell & Howell 5-64995-195 (also Oak)	258E107	BTC KB5126 T Fcc: E5XKB5126 TH0610, rec enter (Also Tag ent)
790E107	Ben Q P010 Fcc IZTIK105M (also Professional)	505E104	BTC 7932M, Rec enter (also Wyse)
313D48	BigKey FCC: LEW KB48-1	516E107	BTC 5107 Fcc:E5XKB5301, P/N 5187-1734 Back-L enter, (also HP)
57E60	Big Keys LX	1672B107	BTC 5201 (also HP)
240B84	Bios XT/AT	1801B104	BTC 7800
746B84	Bilink Portable 84 Key	28G85	BTC 9118H, Fcc: E5XKB9116H, Rec enter
957B101	Bilink Portable PL101	84G126	BTC KM7102 (Euro), BRBTC8159XX0301
693C103	Bilink Portable (103 Keys)	993E109	Buffalo BKBP-J109LG (euro)
410C80	BNT Terminal (Behring Nephelometer)	90C100	Bull Questar 210(European)
*****	Boundless Technologies - See ADDS	658B105	Bull Questar 400 (European)
511B101	Brother TM500 (also Link)	455C115	Bull Questar KBU3103(Euro)
843D82	Brother Geobook NB-80C W/glidepoint, Rec enter	737B107	Bull (Honeywell) BDS-3
257B84	Brotherbox KS 251	967B93	Bull BDS-1/M9048
442B101	BSC-Blue Star(also Zeos,Nan Tan,NTC,Wang Twin Head,Premier,Dataware,Magitronics)	03C107	Bull M22(also Honeywell,Memorex)
427B101	BSR -101(also Packard Bell)	523A98	Burroughs B25/B26/B38
35C101	BSR-386SX FCC:1010DS(also Packard Bell,Leading Tech.Emerson,Cordata, Laser,Samsung,CMS,Se Jin,Leading Edge)	519A90	Burroughs Et 1100/2100
989A84	BTC 5060 Pyramid Keys	519A90	Burroughs BETKB-8 NR3388 (European)
750A84	BTC 5060 Flat Keys	608A95	Burroughs 95 Switch
811A84	BTC 84 Swith(also Kaypro)	815A113	Burroughs T27K3
54B122	BTC 122 Switch	954B112	Burroughs B-25 K-2 (S.A.)
72C80	BTC 5100 Mini Kybd- Rec enter	340C114	Burroughs B25-K5
152C81	BTC 5100 "L" shaped Return Fcc:E5X5R5BTC-5100		
453E81	BTC 5100C, Fcc:E5X5R5BTC-5100C Rec enter(also Sig)		
534B99	BTC 5151		

P/N	Description	P/N	Description
622B97	Cable Data (also E sprit)	64G107	Chestercreek F21-WE28 Lesson, LB2B
573A72	Cannon TX50	73G80	Chestercreek Kinderboard KB
73B101	Cannon Navigator (also Acer,Delta Gold , Nec, Multitech ,Stone, Data General, Texas Instrument)	174G68	Chestercreek MB-1C, Myboard-1C Large Keys
xxxxxx	CE ALL MODELS UNDER CHICONY ELECTRONICS	578G92	Chestercreek Foreign Language keyboard
147E90	C.E. M722 Laptop, Rec enter, Glidepoint	602G104	Chestercreek Large Print L82B-AWE
92C101	Celem (Euro)K-108(also M tek,Mon terey)	159B84	Chicony 5160 AT/XT
421B98	Centennial Keyboard	129B101	Chicony Enh 101/5161(also Austin,Samsung) Fcc:E8H5KKB-5161
120D123	CG Compugraphics #9298-501	476B102	Chicony KKB5162 (European)
250B83	Cherry G80-0413	584B101	Chicony 5181(also Hyundai, Magn avox, Headstart, ARC ,Identity)
176B75	Cherry G80-0414H/07	669C102	Chicony 5182 FCC:E8H51KKB-5182(also Mitac)
422B101	Cherry G80-1800,G81-1800 HAU/03 MY1800	219B101	Chicony 5191 (4 raised lights)
210D101	Cherry MX1800 G80-1838HPU (also Compaq)	36C101	Chicony KB5191(also Leading Edge Handok,Kris Tech,Auva)
873D104	Cherry MY1800,G81-1800 W/Win, Rec enter	682B102	Chicony Magix5192 (European)
577E105	Cherry G81-1800LPMS-0/000 (Euro) "7" enter	723C102	Chicony 102 (EURO-UK)
560B101	Cherry G-81-3000/NCR 916 RS3000 G83-3077-SBU	217C85	Chicony/ULTRA 386SX-20mhz(also Epson)
925D104	Cherry MY3000 Fcc:GDDG81-3000, Rec enter	246C101	Chicony KB-101 (Euro)
856D105	Cherry MY3000 Fcc:GDDG81-3000, W/ Win, "7" enter	424C101	Chicony KB-5311 FCC:E8HKB5311 (also Compudyne,Addison)
393B107	Cherry HAD 104 (107 Switch)	721C102	Chicony KB5312 (EURO) FCC:E8HKB5311 (also Kodak)
395B83	Cherry XT/AT	243C101	Chicony KB-5391
997B106	Cherry G80-1080 HAU/01	397C101	Chicony KB5581A with Trackball Fcc: E8HKB-5581A (also PC Accessories)
365B102	Cherry 102 Keys G80-1800HAE/07(Euro)	720C92	Chicony KB-5591 with Trackball Fcc:E8HKB-5591 (also Addison)
448B102	Cherry Pyramid G80-3012HAD (European)	273C101	Chicony 100M/OK-100M FCC:IZEOTCOK100M
714B102	Cherry G80-1251-SAD (European)(Tandon)	761C101	Chicony KB5331 FCC:E8HKB-5311 (also Ultra)
490B101	Cherry G81-1000H/G81/G81-1600 SAU	782C101	Chicony KB8851 FCC:KM988KKB8851
536B101	Cherry G81-3000-HAU/03 (European)	776C102	Chicony KB-7001 Ergo Kybrd FCC:LIAKB7000 (also PC Concepts,Ace,Addison)
537B102	Cherry G81-3000-HAB/04 (European)	108D104	Chicony KB5911 w/windows keys E8HKB-5911
557C101	Cherry G81-1900 HDU/17 C/C Reader	496D105	Chicony KB5911 W/Win (euro) Fcc:E8HKB5911
309C101	Cherry G81-3100 SDU/03 C/C Reader	916C104	Chicony KB5923, KB6923 FCC:E8HKB-5323 w/win keys (also Reveal,SII G,IBM)
540B102	Cherry G80-1000-HAD/16 (European)	132D105	Chicony KB5923 (Euro) Fcc:E8HKB-5323
387C105	Cherry G80-1191-HBU(also Tandem)	986C101	Chicony KB5323/KB6323 FCC:E8HKB-5323 (also Zenith,IBM)
738B107	Cherry G80-1114-HAO (also CTM) (European)	888C101	Chicony KB2313 FCC: E8HKB-2313
61C126	Cherry G80-2507HAD(also Siemens-Nixdorf, SINIX (European)	998C104	Chicony "ERGONOMIC" w/windows keys KB7903 (also Fellows)
200C106	Cherry/Tandon G80-1207-HAD/04(Euro)	931C104	Chicony SKR-2033
267C123	Cherry G80-2100 Hau/02	151D102	Chicony KB5323 (EURO)(also Zenith,IBM)
338C105	Cherry G80-3314-HAU(also Triad)	248D104	Chicony KB7923 FCC:E8HKB5923 (also Sony)
528C103	Cherry G80-1600 HAU/17	160D104	Chicony KB8923 FCC:E8HKB5923 (also IBM)
667C83	Cherry ML4100 FCC:GDDG84-4100	220D105	Chicony 8926 w/win keys (Euro) Fcc:E8HKB5923(also IBM)
690C101	Cherry MY1600 G81-1600SAU	132D105	Chicony PCK104-SKB (EURO)FCC:E8HKB5323 (also Unisys)
190D101	Cherry MY3100 Credit Card reader	201D104	Chicony KB2923 FCC:LIAKWD-200 (also Mousesystem s)
811C117	Cherry G80-3190HDU w/ cc reader	793D104	Chicony European Fcc:LIALWD-200
982C86	Cherry ML4400 w/trackball G84-4400-RAU	325D104	Chicony KB5981 w/win keys FCC:E8HKB5981
45D21	Cherry MX3700 Keypad G80-3700-HAU	320D104	Chicony KB2931 w/win FCC:E8HKB5923
130D101	Cherry RS6000 G83-6000-LPAUS, PCXAC-GA	532D104	Chicony KB2961 fcc:E8HKB-2961, Back L enter
188D102	Cherry RS6000 (EURO)FCC:GDDG83-6000-LABG	899E105	Chicony KB2961 Back L enter Single back space key
123D104	Cherry RS6000 w/ win G83-6104LAMUS101	808E104	Chicony KB2961 - Rect enter (also Gateway)
123D104-Revise	Cherry RS6700	538D104	Chicony PCK104-SKB FCC: CMYKPPQ7615/ Fcc: KPQE 99ZC-13 (rect. Enter)
189D105	Cherry RS6000 w/windows(EURO)G83-6105	721D118	Chicony KB9805 Multimedia (also Toshiba)
458D105	Cherry G83-6105LC(Euro) Fcc:GDDG83-6000	723D105	Chicony KB3963 w/win, rec enter, ez button
470D104	Cherry MY7000 G81-7000LABUS/03	03E107	Chicony KB-9850, rec enter
515D86	Cherry ML4100 w/win keys	112E104	Chicony KB2971, Back L enter (also eMachines,Fellows es)
504D104	Cherry RS8000,MY8000, G81-8000LPC-US, G81-8008 L W/ CreditCard Reader, Win Keys	794D04	Chicony KB2971, Rect. enter (also eMachines)
701D130	Cherry MY8000 G81-8308LPAUS	152E121	Chicony KB-9885, Rec enter, Multimedia (also Systemax)
597D104	Cherry MX1180 G80-1180 LPAUS, Fcc:GDDG80-11801	958D110	Chicony KB-9908 (also em achines)
639D120	Cherry MX8000/G80-8200	669E104	Chicony KB-8861XP, Fcc: KM988KKB8861, Back-L Enter, Numeric pad left side.
799D122	Cherry MX8100, G80-8113L RAUS /02, w/ c/c reader, Win Keys, Glidepoint	665C125	Chyron Maxine KB PESA1124
663D112	Cherry G80-3181HPU POS	740C119	Chyron Super Scribe KB
673D106	Cherry G80-11900 W/Touchpad		
674D13	Cherry POS MX1950 (Universal)		
265E117	Cherry MX3160, G80-3180HQMS/00 Win. Keys, glidepoint "7" enter		
306E107	Cherry MX11900, Fcc:G80-11900LPM FR/07 "7" enter		
104G110	Cherry G230 P/N G85-23000E U-2		
123G125	Cherry SPOS G86-61401EUA DSA, (also W incor)		
143G142	Cherry G86-6341EUADDA-100 (N273) credit card reader		
171G104	Cherry KU0556 - rec. enter		
414G00	Cherry ML5200- FLAT, G84-522		
420G21	Cherry ML4700 keypad, G84-4700PBUS		
605G104	Cherry RS6600, G83-6644LUA EU		
607G129	Cherry LPOS w/credit card reader		

P/N	Description	P/N	Description
48D108	Cirque GKB330/340 with glidepoint Fcc:GYUR33SK (Also Reveal, Lite on ,PC Concepts)	276D107	Compaq RT-685BTW (EURO) split-spacebar Fcc: AQ6CYPRESSC15
395D04	Cirque Glidpoint Touchpad2 model GDB400 Fcc:1GSCC0003	250D104	Compaq RT6L5CTW w/page scanner,win keys 121307-001 FCC:AQ6-LONGBAYZ15
415D108	Cirque CIC360 FCC:L2BACEKEY220 W/Windows and Glidepoint "L"enter (also Acekey)	957C104	Compaq RT-6656TW/6655TW,RT6600TW,235212-101 (also Hitek,AST,Liteon)
183B101	C.ltoh Enhanced 101	326D104	Compaq RT-2156/RT-2257TW w/win keys(also Hitek) Fcc:AQ6MTN71BZ15DIP/ AQ6-71Z15/AQ623K15
311B108	C.ltoh 223/224/324/326/328/334	322D105	Compaq RT-2257TW LA (Euro) w/win keys Fcc:AQ6MTN71BZ 15DIP
587B108	C.ltoh 344	394D85	Compaq 5300 Laptop w/trackpoint #213519 LTE 5280
245B102	Citizen Mate 12	79E101	Compaq RT235BT, Fcc:AQ623K15, Rec Enter
35C101	CMS 386SX/16(also Leading Technology, Cordata,Laser Samsung,Se Jin,Packard Bell,E merson,Data train, Leading Edge)	417D105	Compaq RT231BTW ,247430-001 w/win keys Split space bar Fcc:AQ6-72BC15
592D88	Coded Communications MLT-2000 Fcc:FKGD75	426D104	Compaq RT231BTW full spacebar AQ6-72BC15 KB9860, 166516-001
540A83	Columbia P.C.	80E105	Compaq KB9860,166516-001 (Euro)"7" Enter
862A120	Comex 120 Switch	463D104	Compaq RT5 158TW Fcc:AQ6-8Z15 W/W in
76A66	Commodore Vic 20/64	489D87	Compaq Armada 1540/1550DMT Series2920A Fcc: DGIP5665
09B66	Commodore 64C	518D88	Compaq Armada 4131T Laptop W/touchpad
842A92	Commodore 128	597D104	Compaq MX11800, G80-11801LPAUS Fcc:GDDG80-11800
843A89	Commodore Amiga 1000	160D104	Compaq KB 3923 fcc:E8HKB5923 (also IBM, Chicony)
137B94	Commodore Amiga 500/2000 KKQ-E94YC	631D117	Compaq Presario SK2700 fcc: GYUR55SK
404B85	Commodore PC 5	632D118	Compaq Presario SK2700 (Euro)Fcc:GYUR55SK
403B101	Commodore PC 10 Series III	641D104	Compaq ConcertMaster RT915CTW
509B102	Commodore PC 10F (European)	661D93	Compaq Armada 7330T/7380MT Laptop
963E93	Compal HEL81 (also Nextel)	676D90	Compaq Armada 7700DMT Portable
147G86	Compal - newer version of above	776D98	Compaq Presario #1260 Laptop Fcc:CNTTAI-24639 W/Win Keys, Touchpad, Speakers
100G94	Compal 9720C model: SF191	889D122	Compaq SK2800 Fcc:GYUR66SK, GYUR79SK, Mltmda
*****	Compaqs are also listed under Hewlett Packard	857D123	Compaq SK2800 (Euro),Fcc:GYUR66SK W/win,
489A83	Compaq 286 Portable/Portable(+)	928D95	Compaq Prosigna 150 M/N 1456VQLIN, Fcc:H8NTAI-27108-M5E, rec enter, glidepoint
652A84	Compaq 286 Deskpro(L-Shaped Return Key)	933D90	Compaq Armada 1750, Fcc: CNTTAI-32808-M5E
731B80	Compaq LTE 286 Portable	934D93	Compaq Armada 3500, trackpoint, Win. keys
888A84	Compaq Portable II	960D88	Compaq Armada V300, M/N 1456VQLIOJ, Fcc:H8NTAI-27397-M5E, rec enter, glidepoint
36B84	Compaq Portable III	171E91	Compaq Armada M300, Glidepoint, "7" enter
428B91	Compaq 386 Portable	23E104	Compaq KB9965,w/win, 269513-001, 166516-006
867A101	Compaq 386/286 Enh FCC:CNT8AV106288	988D105	Compaq KB 9965 (Euro) w/w in keys
238B101	Compaq 386-20E Enhance II /386S Fcc:CIGEO35074, AQ6ZG-CCC, 140536-101 CNT47K109232	373E101	Compaq KB9965 us version, Philips#M3180-40010
475B102	Compaq 386-20E/286E/386S (European)	374E102	Compaq KB9965 French version Philips#M3180-40011
535B82	Compaq 2680KB/SLT 286 Portable	375E106	Compaq KB9965 Japanese version Philips#M3180-40012
577B83	Compaq SLT/286 (European)Portable	24E111	Compaq SK2855,SK2850,SK1800, GYUR70SK, GYUR85SK, Multimedia, rec enter
583B92	Compaq 386 Portable (European)	64E112	Compaq SK2855, (Euro), "7" enter Multimedia
247C101	Compaq Prolinea RT-6271T, 141648-101 Fcc: AQ6MEMB74004 (also Hitek)	60E90	Compaq Armada 100, Fcc:H8NTAI-40049-M5-E
290C102	Compaq RT-102 (Euro-S.A.)(also Hitek) Fcc:AQ6MEMB-74004	73E122	Compaq SDM4540UL, KU9978, P/N 179355-007, Kus0060, Multimedia
478C101	Compaq RT-101(+)FCC:AQ6ZG-RT-687XT 119459-001 160650, AQ6MTN4XZ15 (also Hitek,AST,NEC,Dec,NCD,Ads)	72E123	Compaq SDM4540UL (Euro) P/N 179355-1667 Multimedia
208D102	Compaq RT-102 AQ6-CYPRESSC15 (EURO) (also Hitek)	84E93	Compaq Armada 7800 Fcc:CNTSNG-32811-PT-E
596C79	Compaq Contura Model 2820 Laptop Fcc:CNT75MBZ4	94E109	Compaq SK-1689,(Euro) Fcc: GYUR89SK "7" enter, (also Dell, Liteon,AIMC)
622C101	Compaq KPQ-E99AC "Rectangular Enter Key" FCC:EW4KPQ2479A 160648-101 (also Mitsumi,Hitek)	96E112	Compaq SK2860, KB9963, KB9965, SK2865,DT852 Fcc:GYUR86SK, Multimedia, Rec Enter
642C79	Compaq LTE Lite Series 2810 FCC:CNT75MAFA	118E113	Compaq SK2860, KB9963 (Euro) Fcc: GYUR86SK Multimedia, "7" enter
918C101	Compaq Vocalyst FCC: CIGEO3783	238E104	Compaq SK-1688, Fcc:GYUR84SK, Rec enter, W indows
919C79	Compaq Concerto Notebook	376E105	Compaq Sk-1688 (Euro), Fcc:GYUR84SK, "7" enter
913C101	Compaq P/N 120663-001A (also Hitek) Fcc: AQ6-CYPRESSC15 rect Enter key	308E98	Compaq EVO N160,EVO 2150, 900Z, Model #Capra, 1456VQLIT, Fcc:H8NTAI-36177-M5-E
55D82	Compaq LTE Elite 4/50E Series 2850D Fcc:CNT75MB1CD Portable	379E95	Compaq EVO N600C, M/N JO7M 04000, Fcc: 6CTTAI-35763-M5-E
79D76	Compaq Contura Aero 4/33C Series 2830A Fcc:CNT-75MBZE A Potable	361E95	Compaq Armada 110 Laptop, Glidepoint
176C85	Compaq Contura 430C series 2860 w/trackball Fcc: CNT75MB2CC	365E06	Compaq Pocket PC
210D101	Compaq/Cherry MX1800 G80-1838HPU	396E112	Compaq KB-0133, KU3923, 4700, 9009 Rec enter, multimedia
230D105	Compaq RT7A56TW 237743-301 w/window keys rectangular enter FCC:AQ6-MTN41Z 15DIP KPQE99ZC-13 Split spacebar	372E113	Compaq KB-0133 (Euro), "7" enter, Multimedia
253D106	Compaq RT7A56TW (EURO) w/window keys Fcc:AQ6-MTN41Z15DIP split-spacebar	459E90	Compaq EVO N1000C Series PP2140, Trackpoint& Glidepoint
228D105	Compaq RT-685BTW 121838-001A w/win,rect enter,FCC:AQ6-CYPRESSC15,split spacebar		

P/N	Description	P/N	Description
548E109	Compaq KB-9968 Trackball, Rec enter	34C101	CSS 101 Fcc: 1010R2 (also Leading Technologies,Samsung,Se Jin)
607E00	Compaq EVO N180 Laptop (special Order)	251E116	CTL 5800, Multimedia, back-L enter
605E88	Compaq EVO N1000V, N1015, N1020 (Special Order)	738B107	CTM KS90 (European)(also Cherry)
606E85	Compaq Armada M700 (Special Order)	883B111	Cumulus 466
560E100	Compaq N800C Laptop Rec enter, Trackpoint, Glidepoint	851B101	Cumulus GLC 386SX (SEE HITEK FOR OTHER MODELS)
570E91	Compaq NX7000 Laptop Glidepoint, Rec enter w/Win	233C102	Cumulus 386S X(also HQK,Identity)
638E104	Compaq SK2875,SK2885,KB0316, sml4000, 9109 rec enter (also H.P.)	908C93	C & W 93 Key
652E96	Compaq NC4000 Laptop Series PP2170	909C84	C & W 84 Key
690E93	Compaq NC6000 Laptop	509C101	Cybernet 101 (also AIC)
2023B104	Compaq 5185, KB-0311, 5187-5023, RT7H00	662D104	Cybernet Keyboard PC Station (also AIC)
693E115	Compaq model 5185, 5187-5025 (Euro) "7" enter	936D108	Cybernet "Elite" zero footprint, Multimedia
705E90	Compaq NX5000 Laptop with Glidepoint (also HP)	229E105	Cybernet Elite II Zero footprint PC
714E107	Compaq 5107 Fcc: E5XKB5301, 3 buttons top of Numeric keys, rec enter	786E111	Cybernet ZPC-9000
715E108	Compaq 5107 (Euro), Fcc:E5XKB5301 "7" enter	950E100	Dafron WL-8458VT (also Kool)
771E104	Compaq SK-1788 (also Sejin)	*****	Dah Yang ALL MODELS SEE UNITEK/UNIT TECH
778E84	Compaq Tablet PC Series PP3000	945B108	DAS AT1183
826E121	Compaq RT7H10 (also HP)	438B101	Dasher 386SX (also Data General, Emerson,Fujitsu,Earthstation, Sanyo,Vendex,Tatung)
830E93	Compaq NX9005, NX9030 laptop (also HP)	120A90	Dasher SN7 (also Data Gen.)
855E92	Compaq NC6120 laptop	519D81	Data911 (also MDS)
874E108	Compaq 5137, 5188-0989, Fcc:E5XKB5137	523G104	DataCal Arabic keyboard
48G114	Compaq SK2950 (Euro), 5188-6108	709B91	Datacard (Euroean-France)
60G120	Compaq SK2960 (Euro), 5188-6083, HP 5189 URF, 5188-7582 (also H.p.)	797B101	Datacomp DFX121/171m/191(also Aser,Anser, Diamond Flower) FCC: FBX5E9DFK121
482G108	Compaq PR1101U, 505130-371, SK2085 rec enter	30G106	Datacomp DFK192WJP893P Fcc: FBX5E9DFK191
49G109	Compaq PR1101 (Euro), P/N 530105600-563G	31G105	Datacomp DFK192V935D Fcc: FBX5E9DFK191X
1703B082	Compaq Armada 7400 laptop	430B101	DataDesk 101
1422B082	Compaq Armada 7710MT laptop	326C105	DataDesk Mac101E model1069 FCC:E98-1069
1832B087	Compaq Armada 100 S Laptop	26C111	DataDesk Turbocalc III (also Focus)
1676B088	Compaq Presario 1810 laptop	232E83	DataDesk Little Fingers LF2000, Trackball, Back-L enter
148G91	Compaq 6910P laptop	438B101	Data General GG488A (also Dasher,Sanyo,Vendex, Fujitsu,Earthstation,Emerson,Tantung)
306G90	Compaq KBPH-0806, P/N 505055 (Euro)	120A90	Data General D-2 (also Dasher)
307G109	Compaq 07KW02 P/N 5188-8388 (Euro)	119A101	Data General D100/200
388G101	Compaq CQ60 laptop-Keys Only, Rect enter	205A107	Data General 210/215/220/410/460/470/6246/6346
489G86	Compaq Presario V3000, Pavilion CV2000, DV4, DV4-1000, DV4-1100, DV4-1200 Keys Only	12B107	Data General 214/6348 21"
515G87	Compaq Presario 2100/2170/2500 keys only	276B107	Data General 6348 Rev 01-A 19"N860-4735
549G86	Compaq Presario F500, F700, V6000 keys only	532B79	Data General Walkabout G2750/85 p#119-1900
594G101	Compaq CQ72, G72 - keys only	901B86	Data General Walkabout SX Portable G2762A
566C101	Compuadd 2192004(also Maxiswitch)	758B106	Data General Model 18902 (119-2125)5220MT (also Keytronics)
586B101	CompuAdd 286 (also Mitsumi) KPQ-E99YC	645B102	Data General 6312-K (Euro) (also Acer)
231C101	CompuAdd 55153 RT-101(+)(also Hitek)	73B101	Data General 6311-K (also Acer,NEC,Multitech, Cannon,Stone System s,Delta Gold, Tex Instr)
437C86	CompuAdd Express 325 NXL Laptop w/trackball model NB25SXL FCC: IYL1398995	317C101	Data General 5222MK YB/EO3624E (also Keytronics)
9989B084	Compuadd 425TX laptop	71G86	Data Image Studentamate
545C84	Compudyne Slimnote Portable CMPD3 SLX/25 Fcc: FKGSLMNOTE-SX	828B100	Datalux FIRUW
424C101	Compudyne KB-5311 FCC:E8HKB5311 (also Chicony,Addison)	963B100	Datalux TIRUC
80D104	Compuphone 2000 FCC:LVNEY5754-K616	304D100	Datalux CIRU-30/40
722D122	ComputerLab 122 key	246D94	Datalux model MOGUC w/glidepoint
917D101	ComputerLab 101 Key	283D94	Datalux TIGUC
287E122	ComputerLab BTUS012725655 "7" enter	364E93	Datalux MOGUW, glidepoint, rec enter
473G122	ComputerLab CL122	423E93	Datalux TOGUC, Rec enter, Glidepoint
443D104	Compucessory 30210 Fcc:F2QKT95104 (also Qtronix)	728E100	Datalux keyboard
291B101	Computrend SK-8801(also Liteon,Jade,KLH)	661B107	Datamaxx Ext. 4300
400B44	Comterm Portable	750B103	Datamaxx 1200
254B84	Contel 84 Switch/C321	338B101	Datamaxx 1227 (also Keytronics,A GI, Mitsubishi,Goldstar,Premier,Spear Technology,Gateway)
509A87	ControlData 87 Switch 722-30	770B107	Datamaxx 7310(+)
937B101	Copam K450 FCC:DXO6SCK-450	875B111	Datapoint94-7393XX (European)
547C101	Copam K455 FCC:DXOKB453P	876B76	Datapoint94-5330-002 (European)
18B84	Cordata CS 40	934C109	Datapoint94-7391-101
35C101	Cordata 286/386 FCC: 1010DS (also Packard Bell,BSR,CM S,Leading Tech,Laser, Samsung,Emerson,Se Jin,Leading Edge)	128B122	Datastream 122 Switch
965E121	Cortron P/N 524-0063/20-52650	597B84	Datavue Snap 1 + 1 Portable
571B101	Cosmo Keyboard FCC:GXD3PNLB101A	891A77	Datavue Spark Portable
149E88	CPI #861, Wireless Keyboard, RecEnter	442B101	Dataware KB6251/EM(also Zeos,NTC,Wang, NanTan,BS C,Twinhead,Premier,Magitronics)
999D108	Cramer KB-10,Fcc:L2PWPD1BBC, Rec Enter	35C101	Datatrain 101 GJJ4AKEAT-1010DS(also CMS, Leading Tech,Cordata,Laser,Leading Edge, Samsung,BSR,Emerson,Se Jin,Packard Bell)
941B101	CSK-7101/1101 (also Recortec) FCC:GS23TYCSK1101P	798B101	Datatrain 989-002(also Maxar)
322C102	CSK-7102S/1102S(Euro)FCC:GS23TYCSK1101S		
817B101	CSR 286/128 SL (also Focus,Proteus)		

P/N	Description	P/N	Description
426C101	Datatrain SEM-K20N-1 (also Samsung) Fcc:E2XSEM-K20N	1614B087	Dell Inspiron 7000 laptop
346B84	Daytronic 84 Switch	1182B083	Dell Latitude LX laptop
989A84	Daytronic IPC	1024B085	Dell Latitude XP 450CX, XPI P90ST laptop
66A83	Dec VT 100/101/102/103/131	542D90	Dell Inspiron 3000 model#TS30H #32304 Laptop w/Window Keys and Glidepoint
148A18	Dec VT 100-18 Button Aux.Station (\$3.50 Ea.)	09D104	Dell "Quietkey" SK1000REW/SK2000RE W/RT7D5 JTW SK8000, Fcc:GYUR26SK/GYUR43SK (also Liteon)
109A69	Dec Writer II LA36	221D102	Dell SK1000RE (Euro)
599A83	Dec Writer III LA120	137D101	Dell Model SK-MDK w/speakers GYUR13SK
295A105	Dec VT 220/240/Rainbow/ DecMate II/III(+)	146D104	Dell AT101W w/windows keys FCC:GYUM92SK, GYUM905SK
295A105	Dec LK201AA / Dec 320	327D105	Dell AT102W w/window keys(Euro)FCC:GYUM92SK
157B105	Dec LK 207EE/330/340	340D105	Dell SK 1000REW(Euro)GYUR26SK w/window
151C101	Dec LK 443AA/LK441(also Honeywell,Memorex,Tele x)	669D90	Dell Latitude CPI, PPL, CP M233XT
354C101	Dec PCXAL-AA cat#101WN63S-8E FCC:GJK101RX-6 PC7XL-AA (also Honeywell,Te ktronix)	965D93	Dell Latitude Model PPX, PCX-J, Cpx, Fcc: CPTV466GT, Rec enter, glidepoint, win. keys
355C101	Dec PCXAL-AA cat#101RX435-71 FCC:GJK101RX-4 (also Honeywell)	956D91	Dell Inspiron 7500 M/N PPL, touchpad
767B108	Dec VT-420 LK401AA/LK411AA LK-450,VT-520 598- 001-2208, 297-9003-9000 598-0013684 (also Adds)	94E109	Dell SK1689, Fcc:GYUR89SK, (Euro), "7" enter (also Compaq, AIMC, LiteOn)
89B101	Dec 433 PC(EO3443)(also keytronics,Unisys)	146E94	Dell Latitude C500, C510, C600, C610, 4100, 4150 PPO1L, Rec enter, Glidepoint
274C84	Dec PC320P Notebook Portable FCC:ACJ9TG25-3572	177E108	Dell RT7D00, SK8100, SK8110, RT7D20, 07N242 Fcc:7D080C0B, win. Rec enter
519C74	Dec LK-421AA Cat# 74R X33S-3E (also Honeywell) FCC: A09LK421	231E109	Dell RT7D00 (Euro), "7" enter, windows
14C101	Dec PC7XLAA "L" Shaped Enter Key FCC:GJK101RX-6 (also Honeywell,Dell)	863E109	Dell SK8110- Japanese
620C24	Dec LK901 Keypad FCC:2ELK901-AB	45E81	Dell Inspiron 5000E (also Systemax)
478C101	Dec 101 RT-101+ (also Adds,Hitek,NCD,Compaq,Nec,AST)	240E88	Dell Latitude L400, model #PP01S, Fcc:LNQU SA-34266-M5-E
670C102	Dec RT-102(EURO) 119691-013 FCC:AQ6ZG-RT687XT(also Hitek)	343E91	Dell Latitude C400, PP03L, fcc:SZXMUL-36273-FBE
664C86	Dec 325P PCP12 Portable FCC:ACJ9TG25-3573	259E94	Dell Latitude C800, PP01X,
332B101	Dec-200 (also Radio Shack,Panasonic)	446E94	Dell Latitude C840, PP01X, glidepoint, Rec enter
843C85	Dec Hinate 433 w/ trackball	976D107	Dell KWD-820 (also PC Concepts)
912C121	Dec MTXLA-BA P.O.S. Computer	284E112	Dell RT7D10, Fcc:AQ6-7D10 (7 buttons across top)
800D115	Dec MTXLA-BA W/ Credit Card Reader	891D116	Dell itouch 86719-0403, YRB-6 (also Logitech)
70D83	Dec Portable HINOTE Ultra 433 w/trackball FCC:A09-D7XNOTE	472E118	Dell RT7D30, RT7D40, Fcc:AQ6-7D30, Rec, Multimedia
124D104	Dec RT4958TW (US) FCC:AQ6MTN7Z15 w/windows keys (rect.enter key)(also Hitek, AST)	567E119	Dell RT7D30, RT7D40 (Euro) "7" enter
91D105	Dec RT4958TWLA w/windows keys (EUROPEAN) FCC:AQ6MTN7Z15 121166-013	537E105	Dell RT7D20 (Euro) "7" enter
186D101	Dec PCXAL-GA FCC:CIGEO36004(also Keytronics)	587E111	Dell SK8125 Multimedia, Rec enter
414D92	Dec Laptop PCP34 w/trball FCC:DJKPWRE48625SL	592E93	Dell Latitude D500, D600, D610, PP05L, Rec enter, Glide point, Trackpoint. Keys Covered ONLY
572D88	Dec HiNote VP575 laptop TS30G fcc:IRTS31GZ	971E96	Dell D620, D630 model PP18L
916C104	Dec KB5923 Fcc:E8HKB5923 (also IBM, Chicony)	897E90	Dell D510 laptop PP17L, P/N U8327A02, FccE2k24Bnhm
715D89	Dec HINOTE VP TS30H Laptop	1800B87	Dell Inspiron 2500, 8100, 8200 Laptop
558B83	Decision Data 3496(83 key)	1887B85	Dell Inspiron 2600, 2650, PP04L
849A103	Decision Data Enhanced 3496	1887B85	Dell Inspiron 5100, 1100,1150, PP07L
384B103	Decision Data 3596-01 (103 Switch)	2016B87	Dell Inspiron 1000
415B122	Decision Data 3596 (122 Switch)(also HP)	673E101	Dell SK 3210, rec enter, Trackball
71B124	Decision Data 3781	716E90	Dell D505, D520 laptop model PP10L
190B83	Decision Data 3761(83 Switch) (full size keys)	726E104	Dell SK-8115, RT7D50, L100
588B83	Decision Data 3761(83 Switch) (Pyramid Keys)	784E105	Dell SK-8115(Euro)
305C122	Decision Data 122RX-31S-1E(also Honeywell)	1925B104	Dell SK-3106 with credit card reader
344C102	Decision Data 102 Model 3777/3778 FCC:102RX31S-1E (also Honeywell)	856E104	Dell RT7D60 with Credit Card reader
609B101	Dell 101 (also Alps,Samsung)(No Pencil Bar) AT101R/AT103R GYUM97SK/GY13PVAT101	845E119	Dell SK8135, Y-UK-DeI-1, Y-DeI-2
192B101	Dell Enhanced 101	884E120	Dell SK-8135 (Euro)
802A101	Dell 310/325(also Keytronics, AT&T, SamsungArnet,Rita,US101)	103G119	Dell Y-RAQ-DeI2, Vostros Desktop Fcc: JN2212172
14C101	Dell 101WN(also HONEYWELL,Dec)	1874B087	Dell Inspiron 4000 Laptop
628A101	Dell 1397651 (also IBM, Lexmark)	847E88	Dell Inspiron 1200, 110L Laptop
251C85	Dell 325N Laptop Portable	999E98	Dell SK3211, Rec enter -touchpad lower right
483C85	Dell NL25 Portable FCC:DG1D3216	01G101	Dell SK3210 with Trackball
579C101	Dell SK 1000RS FCC:GYUR10SK "Rect Enter Key" (also Liteon,AST)	26G97	Dell Inspiron D820, D830
221D102	Dell SK1000RE (Euro)FCC:GYUR10SK	32G90	Dell Latitude D800/M60
725C102	Dell 102 (EURO-UK)	83G91	Dell Latitude D531, PP04X, Fcc: QDSBRCM1020
648C102	Dell AT102 (Euro) FCC:GYUM97SK (also System x)	118G85	Dell Inspiron 700M, 710M & X1
914C84	Dell Latitude LX4100, Fcc: HFSBLXDELL #07427	120G91	Dell Inspiron E1505, 6000, E1501, 131L
209D87	Dell Latitude Laptop XPI-P75D w/trkball	121G90	Dell XPS M140, 630M, E1405, 640M, 600M
430D89	Dell Latitude Laptop LM TS30G w/glidepoint FCC:11R TS30GS w/windows keys	196G104	Dell SK 3205 with credit card reader
576D88	Dell Latitude PPS, XPI CDP150ST	234G92	Dell E6400 laptop
1774B087	Dell Inspiron 3800 laptop	198G89	Dell E5400 laptop
		219G115	Dell U473 Y-U0003-DeI5
		476G120	Dell Y-0003DeI5, U473D (Euro)
		220G115	Dell Y-RBP-DeI4
		230G104	Dell SK8175, KB1421, L30U Rec enter
		598G105	Dell L30U (Euro)

P/N	Description	P/N	Description
284G116	Dell L20U, SK8165	336E107	E-filliate # 1380207, wind ows, bac k-L enter
309G85	Dell Inspiron 1210-Mini 12, PP40S	530C85	Electrocom MDC 890 (also Digicom)
327G89	Dell Latitude E5500 Laptop	504A51	Electrocom MDT 800 (also Digicom)
332G91	Dell Latitude E6500 Laptop	764E104	Eliminx S-202-12
338G104	Dell SK 8185,KB 2521, KU 1018 rec enter	565C101	Elite SK2000R FCC:GYUR10SK "L" Shaped Enter (also Liteon, Zenith, Ultra,Hewitt Rand)
354G89	Dell E1501, E1705 Laptop - Keys Only, rect. enter	794D104	E-Machines KB2971, Rec enter key
355G86	Dell Inspiron 1520, 1521 Vostros 1500, 1530/1540/1545 Laptop- Keys only	112E104	E-Machines KB2971, back-L enter (also Chicony)
371G107	Dell M6400 Laptop - rect enter	958D110	E-Machines E KB5000 W/rec enter, Multimedia
382G105	Dell Vostros 1710 Laptop -Keys Only, rect enter	178E123	E-Machines EKB5190(A), Multimedia, Rec enter
383G86	Dell Studio 1555 Laptop- Keys Only, rect enter	958D110	E-Machines 7800, rec enter (also Chicony)
439G84	Dell Vostros 2510/15 1C/1310 laptop - Keys Only	2010B104	E-Machines 5143
397G82	Dell Mini 10 - Keys Only	1939B104	E-Machines KB0108 - 18 Internet buttons
441G92	Dell E4300 laptop	391G108	E-Machines KB0511-3 internet buttons, rec enter
486G86	Dell E5410 laptop	409G108	E-Machines KB0705
490G86	Dell Studio XPS1340 Keys only	438B101	Emerson 286 (also Data Gen.,Dasher,Tatung, Fujitsu,Earthstation,Sanyo,Vendex)
505G88	Dell D400 Keys Only	35C101	Emerson 8300 SX FCC: 1010DS (also Packard Bell,BSR,CMS,Samsung,Leading Tech, Laser,Cordata,Se Jin,Leading Edge)
509G102	Dell Inspiron 1764, 1720 Studio 1749,1745,1747 Keys On	541B102	EMAG-COMM 102 Model 88101C (European)
519G103	Dell Inspiron 1720 - keys only	305D88	EPS Technologies Laptop model ARA FCC:EHARA
557G86	Dell Vostros 3300/3400/3500/3700 - keys only	103A70	Epson Hx-20
564G86	Dell Alienware M 15X keys only	498A72	Epson Hx-40
576G85	Dell XT2 table - keys only	541A67	Epson Px-8 Geneva
596G102	Dell Inspiron N5010, M5010-keys only	766A83	Epson Equity I/II/III(83 Keys)
609G84	Dell XPS M 1210 - keys only	123B01	Epson EHT-10
616G86	Dell XPS M 1530 Inspiron 1420, 1520 keys only	911A101	Epson Equity I+/II+/III+/ENH Q203 A 101 Keys
617G84	Dell Latitude E4200	412B72	Epson PX-4
628G63	Dell Inspiron Mini 9 - keys only	563B23	Epson PX-16
634G89	Dell E5420	514B102	Epson Equity III(European)
81C127	Delta Data 8303 (European)	745B101	Epson 386XT(Fujitsu TO26A)
73B101	Delta Gold (also Acer, Stone, System,Cannon, NEC, Multitech, Texas Instrument,Data General)	73C84	Epson NB3s Portable(European)
695E119	Designer KB-558, Multimedia, Back-L enter	74C84	Epson L2 Portable(European)
841E101	Desko Keyboard made in Germany	98C102	Epson A800221/800210/KB03-WG (European)
865E106	Desko Keyboard made in Germany	195C84	Epson NB/SL Port.(Euro)(also Fujitsu)
797B101	Diamond Flower KB -101-E(also Datacomp, Aser, Anser)	217C85	Epson Port.386(also Chicony /Ultra)
727B101	Digicom K-160/K-260 (also Unit Tech,Minta)	450C101	Epson Equity IV N860-4871-T001(also Fujitsu)
460B68	Digicom MDT-870	542C82	Epson Action 486 Notebook(also Mitsumi)
530C85	Digicom (also Electrocom) MDC890	968C88	Epson Action Notebook 650C w/trackball Fcc:11RTS38MS Model TS30AS
504A51	Digicom (also Electrocom) MDT 800	478C101	Epson RT101 AQ6MTN56Z15 120559-001
477D104	Digiponto EPD-FP100 Fcc:KUG-SGC200 W/W in	455D105	Epson FKB8720 (EURO) Fcc: C9SKB8720
483D104	Digiponto EPD-FP100 Fcc:KUG-SGC200 (EURO) W /Win	544C114	Ericsson Keyboard (S.A.)
484D107	Digiponto SG-C 200 Fcc:KUG-S G-C200 (EURO) W /Win	921A85	Esprit 6110(+)
*****	Digital (all Models) SEE DEC	274B109	Esprit 3NL/Opus 2/400(T5503)
479G118	Digital persona U are U fingerprint keyboard 50107-001	567B108	Esprit 108 key
685D104	Digital Research DRKey104	622B97	Esprit 6310 (also Cable Data)
759D124	Digital Research DRKEY124 Fcc: F2Q4NE98 (also Qtronix)	248C97	Esprit 6310N(New full keys)
760B105	Digitran KD0220	102C108	Esprit 6515
122B108	Ditto 320 XL	219C103	Esprit 200 PC Enh.(T5502)
184C102	Donatec 102 (Euro)(also BTC,Facit, Packard Bell,Mitac)	278C102	Esprit PC E400 PCE
717A50	Dreamer Keyboard	538C101	Esprit 400/200-PCE (T5513)119489-001 Fcc:AQ6ZRT687XT, Back-L enter (also Hitek)
445G104	DSI DCKLH104-V2 Left Handed keyboard	560D104	Esprit "WB" SERIES W/WIN FCC:CWTKFRCE
890B102	DTK SPK-101	100D104	Esprit T404C, T405C, (Also Keytronics)
163C102	DTK-SPK-102C	373C105	ETC Peripherals PowerGlide 105 FCC:GMB3ZT-MAK-105(also Power Glide)
40D101	DTK SPK-105E FCC:GOGAPC-21(also APC)	917C86	Eurocom 8200 Notebook
851B101	DTK Grafica MBK-1013 RT-101+(also Hitek) Fcc: AQ6RT101-LC(SPK-103)119411-001	35B101	Everex Step 20PC (also Maxiswitch, Texas Micro, ALR,Gateway,Opus,EasyData Avtech)
327C102	DTK model MBK1013A FCC:F825K4SPK-102	851B101	Everex 116920-001/118235-001 (SEE HITEK FOR OTHER MODELS)
477C101	DTK KB-101N 119976-01(also Hitek,ALR)	38C82	Everex Tempo LX 386SX/20 (Also Zeos)
215C101	DTK EO3601ELDTK M/O 44563460 FCC:CIGEO36004 (also Keytronics)	575D88	Everex Stepnote Plus3500 Series Laptop Fcc: E3EEX-2AQQV-XYDP
784C122	Dupont D2911B	607D90	Everex Stepnote SE Port. W/Win keys & Touchpad
477C101	Duracom 120340-002 FCC:AQ6CYPRESSZ15 (Hitek)	620D88	Everex Stepnote MX W/Touchpad Fcc:EUNDIGNOTE6
425G87	Dynavox 1767	109C102	ExpoTech 811 0205 (also Laser)FCC: IFS80-2269-1
920E123	Dynex DX-MKB101	393G111	EZ See Large Print Keyboard
935E109	Dynex KB-118	208E91	EZZTouch Notebook #34052, Rec, Glidepoint
222G123	Dynex DX-WKBD	209E93	EZZTouch Notebook #2700C, Rec enter, Glidepoint
35B101	Easy Data Model 216 (also Maxiswitch,ALR, Avtech,Gateway,Everex,Opus,Texas Micro)	948A108	Falco 522OE
27G108	Easyline EL993056 (Euro)	152B106	Falco Enhanced AT/ ASCII
438B101	Earthstation I/II FKB-4700(also Sanyo,Vendex Emerson,Fujitsu,Data Gen,Dasher,Tatung)	266C108	Falco 5220 Pyramid Keys(Old Style)
994A101	Earthstation I/II(also Wells American,Hitek)		
99G88	ECS-C225 laptop model S20LL1		
299B99	Edax 99 Switch		

P/N	Description	P/N	Description
786B99	Fame II	370C119	Fujitsu N860-8701-T010-02A(also Sun)
258C101	Fame TH5539 (also APC)	450C101	Fujitsu FKB-4870-401 P/N860-4870-T-401 (also Epson)
184C102	Facit (Euro)(also BTC, Pack Bell, Mitac,Donatec)	947B110	Fujitsu N860-4743-T001 (also MAI)
520D76	Federal APD Powerpad	940C101	Fujitsu N860-8720-T301 (also Wave)
998C104	Fellowes Ergonomic w/windows keys KB7903 (also Chicony)	51D104	Fujitsu 8720 w/windows keys N860-8725-T601 FCC: C9SKB8720
108D104	Fellowes 99900, KB5911	455D105	Fujitsu FKB 8720 (Euro) Fcc:C9SKB8720
723D105	Fellow es KB3963, EZ Multimedia key (also Chicony)	46C64	Fujitsu N860-1406-T001 Palmcomputer
532D104	Fellowes 99902, KB2961	727D107	Fujitsu FKB8730 W/Mousekeys Fcc:C9SKB8730
931D106	Fellowes KWD805 (Euro), EZ Multimedia	874D90	Fujitsu Life book E351, Fcc:5BQJPN-25675-M5-E w/ win keys, Rec enter
112E104	Fellowes 99148/98914/KB2971 (also emachines)	923D60	Fujitsu M/N PD-KB02, N860-8577-T002
1958B105	Fellowes KB-9938, 98915	924D60	Fujitsu M/N PD-KB100W, KB9975, Rec enter
1976B104	Fellowes KWD-855	989D91	Fujitsu Life book L440, Rec enter, Glid epoint
05G122	Fellow es KWD855 part #59494, Rec enter	50E87	Fujitsu FMWKB 3A, Rec enter, wind ows
263G122	Fellowes KU0420, 9893301, KG0570, E8HKG0570	124E88	Fujitsu Lifebook CPO47430
87G115	Fentek KB8861 P/N KBSSTPS2BN Fcc:KM988KKB 8861 back L enter	125E91	Fujitsu Lifebook CPO47801-01
613C105	Filenet Keyboard	226E92	Fujitsu Lifebook P/N CPO82849-01, Fcc:5BQUPN-35271-DT-E, trackpoint, recenter
729E122	Firefly 171939 - rect enter	413E92	Fujitsu Lifebook CPO82849-01, 5BQUPN -35271-DTE
151G116	Firefly Borealis KU-0533	425E90	Fujitsu FKB8738-101, 3 buttons - arrow keys, Rec enter
93B66	Fisher Porter 66 Switch	535E86	Fujitsu Lifebook CP145814
923B142	Fisher Provue Desktop	594E91	Fujitsu Lifebook CP162681, Fcc: EJECNOOB8687
187C142	Fisher provue Console	762E86	Fujitsu Lifebook B142, CPO12888
259C91	Fisher Provox Micro desktop CPN11B8000X042 (also Ke ytronics)	829E90	Fujitsu Lifebook E8020
49C113	Fischer Porter DCI System SIX	22G84	Fujitsu P7120 P/N CP254695
302C114	Fischer Porter DCI System 6 (EUROPEAN)	34G117	Fujitsu N860-8708-T010/20 (also Sun)
599D108	Fisher Rosemount LK401 P/N 122530-001	39G94	Fujitsu C1410 Laptop
999B101	Focus FK-1001 Compact	70G93	Fujitsu Lifebook S7110 laptop
819B108	Focus FK-2000(+)(also Magnatron ics)	1609B086	Fujitsu Lifebook E330
26C111	Focus FK-3001 (also Datadesk)	1637B085	Fujitsu N860-7663-T051
817B101	Focus FK-2001 (also CSR, Proteus) (101 Keys, 2 Keys on both sides of spacebar)	137G87	Fujitsu T-4220 part#CP336660
497C102	Focus FK-2001 (102 Keys, 3 keys on both sides of spacebar)	558G82	Fujitsu Life book B6320 - keys only
52D104	Focus 2001W Fcc:FSQ4VYFK2001 W/Win keys	561D84	Funktentsbrt KPT-84, Fcc:YKNKPT-84 Mini
761D107	Focus FK2001 Fcc:FSQ4VYFK2001 Back-L enter Three Extra keys above directional keys	802B102	Gamma System(Latin America)
969B130	Focus FK-5001(5 Keys Above Num Pad)	338B101	Gateway 2000 E03435(also Keytronics, AGI, DataMax, Mitsubishi, GoIdstar, Priemier, Spear Te chnologies)
198C129	Focus FK-5001(4 Keys Above Num Pad)	35B101	Gateway 2000 101 Key (also M axiswitch, Everex, AL R, Opus, Avtech, Easy Data, Texas Microsystem s)
202D104	Focus SK-5002W Fcc: GYUR30SK	851B101	Gateway 2000 101 key RT-101+ (SEE HITEK FOR OTHER MODELS)
196C102	Focus FK-6000	987B124	Gateway 2000 "ANYKEY" Model 2191011-xx Fcc: HWYKEY1 (also Maxiswitch)
864C103	Focus FK-6200 EZ Key FCC:FSQ100138	17D124	Gateway 2000 "ANYKEY" w /window keys FCC: D7J2194-001-XX 2194002
95D104	Focus FK-6200 E-Z Key w / window s keys FCC:FSQ100138 4 keys right of spacebar	707C125	Gateway 2000 "ANYKEY" (EUROPEAN)
554C99	Focus FK-7000Pw/Trackball FSQ4VYFK7000P	563C101	Gateway 2000 101 Keys 2189013 "Rounded Edges" FCC:D7 J2189-001-XXX
203C111	Focus FK-8000	583C85	Gateway 2000 Colorbook Laptop C8486SX33 FCC:EF7A232J33
198C129	Focus FK-9000(also called 5001)	701C101	Gateway 2000 2189013-0-006("L" shaped enter)
53D103	Focus FK7200 E-Z Ball FCC:FSQ101048	700C102	Gateway 2000 2189013-14-001 (European)
93D104	Focus FK7200 E-Z Ball w /window s keys FCC:FSQ101048 4 keys right of spacebar	924C101	Gateway 2000 2194013 (smaller than 563C101)
38E108	Focus FK7200 w/Win, Trackball, Back-L enter Fcc:FSQ101048, 3 xtra keys above directional	947C104	Gateway 2000 w/windows keys 2194014-00-002
588D126	Focus FK8200 W/Win Keys Fcc:FSQ028058	984C104	Gateway 2000 w/windows keys 2196001-00-002 "L"enterkey FCC:D7J2196001
590D104	Focus FK5200 W/Win Keys Fcc:FSQ811169	446D104	Gateway 2000 2196002 Fcc:D7J2196001 (Maxiswitch)
51E127	Focus FK9200 EZ Pro Fcc:FSQ918058	237D104	Gateway 2000 2196003-XX w/win keys rect enter
461B68	Formeter F2P	337D87	Gateway 2000 Solo 2100 FCC: HFMSQX
851B101	Fountain 386/20,25	05D88	Gateway 2000 Solo Port W.Win PP2-P3C
860A131	Foxboro 131 Switch	445D116	Gateway 2000 MULTIMEDIA #7000598, 7001025 #7001211,7001602 Fcc:EO6150US011-C (also Keytronics)
155C85	Foxboro PO400QB	694D104	Gateway G9900 P/N 7001024 Fcc: GYUR61SK
852B102	Fujitsu FKB 4700-102	878D116	Gateway G9900H,7,001603,7001456, Multimedia
438B101	Fujitsu FKB 4700 (also Data Gen, Dash er, Earth station, Emerson, Sanyo, Vendex, Tatung)	645D105	Gateway G9900-2D Fcc: GYUR61SK (Euro) (also Liteon)
152D104	Fujitsu FKB4725 w/windows FCC:C9SKB4725	666D104	Gateway EO6350US001-C,701049,7001459,7001628
742D105	Fujitsu FKB4725-662 (Euro) "7" Enter, W in	667D98	Gateway M/N KBDNPG005ABWW FCC:CMYKPKQ7119 DESTINATION KEYBOARD & REMOTE
319C101	Fujitsu 3COMM FKB-4707-101	671D86	Gateway Solo 2500 Portable
596B101	Fujitsu 4800	829D89	Gateway Solo 2500 W/ Win Keys, Trackpoint
326B102	Fujitsu Model 260	672D90	Gateway Solo 9100 Portable
114C101	Fujitsu FKB4850-101 N860-4850-T101	724D89	Gateway Solo 3100 Portable
745B101	Fujitsu TO26A/Epson 386XT		
920B123	Fujitsu Atrium (POS Keyboard)		
654A84	Fujitsu 84 Key(also Radio Shack)		
181C100	Fujitsu N860-4201-T001		
195C84	Fujitsu N860-7305-T904(also Epson)PORT.		
337C118	Fujitsu N860-8701-T001(also SUN)		

P/N	Description	P/N	Description
765D82	Gateway Solo 51 50 Portable	301C122	Harris Adacom PC122 US(also Hitek,Harris)
101E90	Gateway Solo 5300, Windows, Glidepoint	467C122	Harris Adacom F190-22T
143E96	Gateway Solo 9500, Multimedia, Rec enter, Glidepoint	71A101	Hazeltine 80 Model 20
144E90	Gateway Solo 9300, Rec enter, Glidepoint	98A108	Hazeltine 80 Model 30
145E90	Gateway Solo 1100, Rec enter, Glidepoint	309A83	Hazeltine Corstar Model 20
246E94	Gateway Solo 1150, Rec enter, Glidepoint	310A104	Hazeltine Corstar Model 30
1446B085	Gateway Solo 2300 laptop	991B89	Hazeltine TC101005-1
948D104	Gateway "Winnie the Pooh" Childrens Keyboard	992B94	Hazeltine TC4011 16-1
81E116	Gateway SK9920, RT3602, #7003604, 7004349, Multimedia, Rec enter	584B101	Headstart/Magnavox KKB5181(also Chicony, Hyundai,ARC,Identity)
126E104	Gateway SK9921,RT3602,P/N 7002557, 7002739	579G110	Hello Kitty keyboard
141E117	Gateway SK6205H (G), Ergo, Multimedia	529B102	Hewlett Rand HR 5339R (also BTC, Packard Bell Goldstar,Mitsuma,Tatung,KLH)
142E111	Gateway SK9910U, MILL ENNIUM Keyboard, Multimedia, Rec enter	565C101	Hewlett Rand SK-2000R FCC:GYUR10SK (also Liteon,Zenith,Ultra,Elite)
454E94	Gateway 450SX4, M405 Laptop, Rec enter, Glidepoint	*****	All HP (Hewlett Packard - see also Compaq)
499E105	Gateway SK9921 (Euro) "7" enter	05C108	Hewlett Packard/Apollo A1630-82001
519E94	Gateway 600YG2 Laptop, Rec enter, Glidepoint	54C106	Hewlett Packard/Apollo 7121 Rev 1
549E97	Gateway Solo 1450 Laptop Fcc:HFS145015318, Rec enter, Glidepoint	769A55	Hewlett Packard 71B
584E103	Gateway M500B1, 505XL Laptop Fcc:PU5MS2119	45A92	Hewlett Packard 85
709E104	Gateway SK-1510, 7004953 - rect enter	146A71	Hewlett Packard 86/87A
2033B104	Gateway KB-0401	772A76	Hewlett Packard 110
770E122	Gateway KR0350, fcc:E8HKR-0350	438A107	HP 150/2392/2397/46010/46020/46021
808E104	Gateway KB2961, KB0447, 7005393, Rect. enter	459C107	Hewlett Packard 46021B #ABA
532D104	Gateway 7005396 (also Chicony)	52C106	Hewlett Packard 1401A 700/43
814E93	Gateway M275 laptop	336B106	Hewlett Packard 1402A/C1421A
931E89	Gateway M250 laptop	415B122	HP 1404A/1410A(also Decision Data)
880E89	Gateway M460 laptop P/N 1MA15081898	801B102	Hewlett Packard 1405A (Latin America)
173G92	Gateway TB-120 laptop, E-155 (also MPC)	232C101	Hewlett Packard 1405B/C1429B
301Gxx	Gateway KB0532 special order	341C102	Hewlett Packard 1405B(European)C1429B
386G108	Gateway KB0817, internet buttons, rectenter	34A68	Hewlett Packard 2621A
477G84	Gateway 2013G laptop Keys Only (also Acer)	219A100	Hewlett Packard 2622A/2623/2624/2627
501G100	Gateway NV56, NV59, NV79 Keys Only	486A100	Hewlett Packard 2628
531G110	Gateway KU0833	118A105	Hewlett Packard 2640/2645
550G86	Gateway MT6000/MT6733/MT6456/6457/6458/6728/6729/6730/6916/6919- keys only	640C105	Hewlett Packard C3342-60201/C3344-60201, #105946-01 EO3616TIOSABA(also Keytronics)
559G103	Gateway NV73A - keys only	100A41	Hewlett Packard 3390A
277G89	Gearhead mini KB1500U	518A46	Hewlett Packard 3392A
281G107	Gearhead KB1000W	126A71	Hewlett Packard 9816 Series 200/98203A
552G118	Gearhead KB5500W	303A105	Hewlett Packard 9825-B
611G107	Gearhead KB2200B	490A106	Hewlett Packard 98203B/805 Ext(European)
520E105A/B	General Electric Logiq Book M/N 2349933 "7" enter	702A105	Hewlett Packard 9826
943E116	General Electric Gem Ultrasound Vivid I	691A103	Hewlett Packard Vectra 46030A,C1406A
1977B107	Genica GN-151	969A101	Hewlett Packard Vectra Enh/ C1429A,C1405A(US)
931D106	Genius KWD805 (Euro), Multimedia,"7" enter	98B109	Hewlett Packard 700/92/93/94/60/1400A
299E104	Genius KWD701 win.,back-Enter, (also PC Concepts)	144B105	Hewlett Packard 700/44(also Texas Instr.) C1417A/C1408A
204G104	Genius slim star 110 (Euro), GK-07006/U	966B115	Hewlett Packard 9000/HP9020A
203G117	Gigaware USB #26-460	150C106	Hewlett Packard C1408A(Euro)C1417A ABF
451E87	GoBook II	523C102	Hewlett Packard A2840A ABE (Euro,S.A.) Fcc:CIGE O3614 (also Keytronics)
851B101	Goldstar 116626 (see Hitek -other models)	546C101	Hewlett Packard Vectra VL A2840-60201 Fcc:CIGE O3614 (also Keytronics) C3757-60201,C3346-60201
529B102	Goldstar 5339R (also BTC, Packard Bell, Mitsuma, Tatung, KLH, Hewlett Rand)	27C80	Hewlett Packard 95LX/200LX Palm Computer
338B101	Goldstar EP3435(also Keytronics, Datamax,Mitsubishi, AGI, Gateway, Premier, Spear Technologies)	749C109	Hewlett Packard C3340-60201 D/M3428 (also Keytronics)
922E90	Gold Touch SKR4200U - split keyboard	915C106	Hewlett Packard C3342-60205 C1081CABF(Euro)
708A112	Graphon G250	988C106	Hewlett Packard C3343-60201, EO3619USA
554A57	Grid Compass 1109	20D104	Hewlett Packard 3537 w/windows keys P/N 5182-5521 CIGE03633, C4725-60201 /3707, Recenter
83B72	Grid 1520/1530	99D105	Hewlett Packard 3537 w/windows keys (EURO) #5182-5521 FCC:CIGE03633
921B77	Grid 1550 Portable	158D86	Hewlett Packard Omnibook 430
365C78	Grid 1550 with mouse, portable laptop	391D116	Hewlett Packard SK-2501,SK2501K Fcc:GYUR38SK Multimedia keyboard (also Liteon)
982B84	Grid 1720 Portable (also Panasonic, Tandy)	459D117	Hewlett Packard SK2501 (euro) Fcc:GYUR38K
557E105	Gyraton Mobile Keyboard Fcc:JJ4-GP221-001, GP1190, GYM1100CKNA, Multimedia, Rec enter	466D104	Hewlett Packard SK2502 C4732-60101 D5728,Fcc: GYUR41SK
833E104	Gyraton GC1105, GC15CK Fcc:JJ4-AS00900	837D104	Hewlett Packard SK2502-C C4739-60101, Rec enter
76G119	Gyraton GC15FK, GC1205FKM, GP130, GP9120 Fcc: JJ4AS00890	536D105	Hewlett Packard SK2502 (Euro) Fcc:GYUR41SK C4735-60108, EO6333KLA
543G86	Gyraton AS04126	862D105	Hewlett Packard SK2502-C (Euro) C4739-60108
36C101	Handok-101 KB5191(also Leading Edge, Chicony,Kris Tech,Auva)		
672E65	Happy Hacking Lite II keyboard, KB-0010, rec enter		
19B93	Harris F178-13E(93 Switch)		
20B109	Harris F178-12E(109 Switch)		
112B122	Harris F-180-11E(122 Switch)		
214B122	Harris 122 RK335(Also Lee Data Data, Dell,Idea,Memorex)		

P/N	Description	P/N	Description
467D119	Hewlett Packard SK2505, Multimedia II Fcc: 5182-8850, 5183-7375	812E121	Hewlett Packard 5187 (Euro) Fcc: E5XKB5187, p/n 5187-8430
839D119	Hewlett Packard SK2505-C P/N 5183-7376 W/Win, Multimedia, Rec enter	831E85	Hewlett Packard Tablet PC TC1100
566D120	Hewlett Packard SK2505 (Euro) Multimedia	860E97	Hewlett Packard NC6230, NC6220 laptop
404D86	Hewlett Packard Omnibook 425 w/win keys Laptop FCC:B94F-1033	890E92	Hewlett Packard NC8000 Laptop
448D88	Hewlett Packard Omnibook2000CT Fcc:B945500	906E75	Hewlett Packard Jordana 728 mini keyboard
513D104	Hewlett Packard FDA-104EB Fcc:F42FDA-104EB	973E93	Hewlett Packard NX6325, NC6320 laptop
574D105	Hewlett Packard FDA-104EB (Euro) Fcc:F4ZFDA104EB	36G94	Hewlett Packard NC6400 HSTNN-C18C Fcc: B94WM3945ABG
512D116	Hewlett Packard FDA-116CA Fcc:F4ZFDA-116CA	60G120	Hewlett Packard SK2960, 5188-6083 (Euro) 5189URF, 5188-7582 (also Compaq)
577D90	Hewlett Packard Omnibook 3000CTX W/Glidepoint	61G113	Hewlett Packard EW213AA, M/N RKM128 Fcc: 10WRKM128
859D90	Hewlett Packard Omnibook XE, Win, Rec enter, Glidept.	66G119	Hewlett Packard SK2960, 5189, KB0630, 5188-6077 KB0911
908D93	Hewlett Packard Omnibook 4150, Glidepoint, Rec enter	90G86	Hewlett Packard 2710P, 2730P laptop HSTNN-W26C
589D104	Hewlett Packard C4735-60101 D/M:3818 Fcc:EO3633KU5001-C, KB9970, C4744-60101	91G88	Hewlett Packard 2510P laptop HSTNN-Q30C
378E104	Hewlett Packard KB9970, C4744-60201 (Same as above but keys lower)	98G89	Hewlett Packard 6710B laptop
678D107	Hewlett Packard RT2858TW 4-1/8" Spacebar 5183-6247, 5125 (also Hitek)	112G105	Hewlett Packard 8710P laptop
689D107	Hewlett Packard RT2858TW 4-5/8" Spacebar, 5125	116G89	Hewlett Packard 6510B, 8510B laptop GF918AT#ABA
679D108	Hewlett Packard RT2858TW (Euro) 5183-6249	126G88	Hewlett Packard NX6310 laptop
696D105	Hewlett Packard C4735-60302, D/M 3830 (Euro) Fcc:EO6333KCF201C	148G91	Hewlett Packard 6910P laptop
728D117	Hewlett Packard C4734-60501, SK2501A Multimedia	154G90	Hewlett Packard 6720 laptop
888D117	Hewlett Packard SK2511A, C4742-60101 Multimedia	212G90	Hewlett Packard 6730B laptop
15E118	Hewlett Packard SK2511A (Euro), Multimedia	213G89	Hewlett Packard 6530B laptop
748D111	Hewlett Packard #5129, P/N 5183-7399 Multimedia 3 Keys to left of spacebar are same size	231G94	Hewlett Packard 8530P laptop
877D111	Hewlett Packard RT2856TW, P/N 5183-7399 Left Control key larger than 2 keys to right.	232G111	Hewlett Packard 8730W laptop
749D112	Hewlett Packard #5129 (Euro) "7" enter Multimedia	239G91	Hewlett Packard 6930 laptop
950D126	Hewlett Packard #5183-9980, SK2506, 6511-S, RT5302, 5184-9648, Multimedia 6511-SU	226G116	Hewlett Packard 5309URF Wireless Product#GM322AA
949D127	Hewlett Packard P/N 5183-9972 (Euro), Multimedia	292G86	Hewlett Packard 6730S Laptop
47E91	Hewlett Packard Omnibook 6000, 6100 Touchpad	274G108	Hewlett Packard Wireless RK713A, SK806A 505129-001, FQ480AA#ABA
138E111	Hewlett Packard SK2530, (Euro), P/NC4759-60108 "7" enter, Multimedia	324G106	Hewlett Packard Probook 4710S
165E125	Hewlett Packard SK2560, 5181, 6511-Z, 5185-1596, 5187-0341 Multimedia, Rec enter	326G107	Hewlett Packard KU-0841, KB2101, 5335U, KG0851, KBRF1921, P/N 505060-371
168E126	Hewlett Packard SK2560 (Euro), Multimedia, "7" enter	351G90	Hewlett Packard 4410T, D40 Laptop, P/N FM974UT#AB Fcc: QDSBRCM1041
189E125	Hewlett Packard Pavilion #5308 (Euro) #5185-2411	359G84	Hewlett Packard 2140 Netbook, Rect enter
245E98	Hewlett Packard Omnibook XE3, rec enter, glidepoint	380G86	Hewlett Packard DV5 Series Laptop Keys Only rect enter
294E123	Hewlett Packard SK2565, #5308, rec enter, multimedia	387G89	Hewlett Packard DV6000 Laptop, rect enter
295E110	Hewlett Packard SK2530, SK2585, 6511PK, C4259-60101 rec enter, multimedia	424G88	Hewlett Packard DV5000, ZE2000 laptop
298E107	Hewlett Packard SK2502C, C4739-60124, (Euro), "7"	442G101	Hewlett Packard DV9000 Keys Only
316E107	Hewlett Packard KB9970 (Euro), C4744-60228 "7" ent	443G101	Hewlett Packard DV7-1000 laptop Keys Only
337E72	Hewlett Packard Jordana 720 laptop, Fcc:5WWSNG-35048-DT-E	470G102	Hewlett Packard 4520S laptop Keys Only
380E96	Hewlett Packard Omnibook XE4100, CRVSA-02T1-60 Rec enter, windows, glidepoint	480G116	Hewlett Packard USB NY4 19AA - Back L enter
516E107	Hewlett Packard 5107, P/N 5187-1734, Fcc:E5XKB5301 Back-L enter, (also BTC)	487G92	Hewlett Packard Elitebook 8440P
714E107	Hewlett Packard 5107, 5187-3549, Rec enter	507G108	Hewlett Packard Elitebook 8540P
522E128	Hewlett Packard 5219 (Euro) Fcc:E5XKB5209	527G103	Hewlett Packard 6550B
396E112	Hewlett Packard KB9009, DC167B (also Compaq)	499G84	Hewlett Packard NX6110, NC6110, NC6120 Keys Only
638E104	Hewlett Packard SK2875, KB0316, KB0816, SK2880 KB9109, KG0133 rec enter (also Compaq)	512G108	Hewlett Packard KU0841, 505060-161 (Euro)
639E116	Hewlett Packard 5183, KB-0228, 5187-1767, Fcc: E5XKB5183	532G91	Hewlett Packard G62 - keys only
1672B107	Hewlett Packard 5201 (also BTC)	533G91	Hewlett Packard 620 - keys only
730E109	Hewlett Packard KB0316 (Japanese) (also Philips)	553G91	Hewlett Packard DV6-3000 - keys only
731E105	Hewlett Packard KB0316 (German) (also Philips)	567G101	Hewlett Packard Envy 17 - keys only
748E106	Hewlett Packard KB0316 (Korean) (also Philips)	571G86	Hewlett Packard Probook 4510, 4415S, 4416S
1960B104	Hewlett Packard 5209, KB-0218, 5187-6105	585G102	Hewlett Packard 4720S
1790B104	Hewlett Packard 5308	595G82	Hewlett Packard Mini 110 - 533549-001 keys only
1999B104	Hewlett Packard 5219URF	212B15	HHT500
881E127	Hewlett Packard 5219CRF, 5187-7076, Fcc: 5XKB5219CRF, Rec enter	695A101	Hirez 100 XL
757E06	Hewlett Packard iPaq H3600 series	571C105	Hitachi Flora 3010/KB1100
838E108	Hewlett Packard NX9600	224D83	Hitachi C-100T Model720 w/trackpoint Laptop p/n C1042A-001, FCC:MMD-PCK-5NS01-01
826E121	Hewlett Packard 5187, 5187-7583, 5187-7584, RT7H10, KB0602	619D84	Hitachi MX-133T port Fcc:HFSMPX
		160B84	Hitek AT 84 keys 112980-005 (also Vendex)
		367B101	Hitek 101(+) 115039-002 (also Arch Rival 386SX)
		154C108	Hitek 117652-001 N-108LK(also NCD)
		78C101	Hitek 116545-001 (also Liberty)
		70C106	Hitek 117155-101 (also Tandem, Adds, NCR, Hitek)
		129C105	Hitek 117085 (also NCR)

P/N	Description	P/N	Description
851B101	Hitek RT-101(+) 117342-011/117532 rev.c.d, 118057 117342-001 rev.B,C,D/117926/116920-001, 117994 CMA650F2/AQ6MEMB-74004,RT-6251T,118420, 117994-001,118413-002,118054-011,118614-001 119616-001,RT6255T,AQ6ZGRT6271T,AQ6RT101LC RT-8200,RT-8255C,AQ6ZRT827XX,AQ6-OAK-Z15 (also NMB, Everex, Gateway, Phillips, Astrix, Matrix, DTK, Cumulus, Fountain, Goldstar, Model America)	920A122	Honeywell 122 Switch (also Telex)
652B101	Hitek RT-101(+) 116305-003, 117825 AQ6RT7251 (also Micronics, Arch Rival)	214B122	Honeywell 122 RK335 (also Lee Data, Harris,)
177C105	Hitek 116429-001 (also Liberty, Tektronix)	784B92	Honeywell 92 key
188C122	Hitek 810-12966NMB (also Idea, NMB)	483B115	Honeywell Bull HD57
782B122	Hitek 122 116528 (also Idea)	10B101	Honeywell 101 (also Microswitch) 101RX43S-79
231C101	Hitek 117700-001 (also CompuAdd, Memorex/Telex)	227B83	Honeywell 83 Switch
711B101	Hitek 116130, N101PS, 117541 (also NCD, Northern Telecom, APC)	327B108	Honeywell 108 Switch
247C101	Hitek 141648-101 (also Compaq)	352A101	Honeywell TDC 2000(\$30 SET) Incl.353A44
290C102	Hitek 118742-014 Rev.B (also Compaq) RT-102 FCC:AQ6MEMB-74004(European S.A.)	201B108	Honeywell 7814
622C101	Hitek 160648-101 (also Compaq, Mitsumi)	976B105	Honeywell 105ST-13(also Bell & Howell)
301C122	Hitek 118285-101, 118997-001 (also Harris, Idea)	726A116	Honeywell PC8916 (also NCR)
774B101	Hitek CMG65001 (also AST, Versys)	03C107	Honeywell M22 (also Bull, Memorex)
994A101	Hitek RT-101FT (also Wells America, Earthstation) AQ659ZRT-101A, 115034-0019 (also Televideo)	519C74	Honeywell 74RX33S-3E (also Dec)
477C101	Hitek 119135-001 FCC:AQ6ZG-RT-667XT, 120340-002 (also ALR, DTK, Duracom) 119249, 119976, AQ6ZGRT667XT "L" Shaped Enter Key AQ6CYPRESS RT-6855(+), RT-6800	151C101	Honeywell 101RX33S-6E (also Dec, Mem-Telex)
478C101	Hitek 119459-001, 119127-001 "Rectangular Enter key" FCC:AQ6ZG-RT-687XT (also Compaq, AST, ADDS, AQ6MTN4XZ15, 119999, RT-6255(+), RT-6652T	354C101	Honeywell 101WN63S-8E (also Dec, Tektronix)
670C102	Hitek RT-102 119691-013 FCC:AQ6ZG-RT687XT(EURO)	355C101	Honeywell 101RX435-71E (also Dec)
521C122	Hitek 117543, 116387 122 keys (also I/O Devices) PC122 119954-00	51C84	Honeywell 84RX435
538C101	Hitek RT-6671 119088-001, 119489, 119967 (also Adds, Esprit) FCC:AQ6Z-RT687XT "L" Shaped Return Key" AQ6-CYPRESS RT687ST 119689 RT-6656(+)/RT6256T	53C101	Honeywell 101RX435("L" shape return)
508C102	Hitek RT-102(+) RT6251 (France, Euro) 118423-001 FCC:AQ6ZG-RT6271T	14C101	Honeywell 101WN (also Dell)
722C101	Hitek RT-8755C+ P/N 120022-201 FCC:AQ6MAPLEZ15	493C102	Honeywell 102WN (Euro) FCC:GJK102RX-6
802C122	Hitek 118997-001 (also Idea)	305C122	Honeywell 122RX-31S-1E (also Dec, Data)
898C106	Hitek 120049-001 (also Adds)	344C102	Honeywell 102RX-31S-1E (also Dec, Data)
936C101	Hitek 230851-001C (also AST, Liteon)	383C101	Honeywell 101WN-63S-11E FCC:GJK-101WN-5 (also Zenith)
913C101	Hitek 120340-002, 184315-101 FCC:AQ6-CypressC15 (also Compaq) Rect. Enter Key	411C101	Honeywell 101RX43S-72e FCC:GJK-101RX-5 (also Zenith)
957C104	Hitek RT-6655/6656TW w/wind ow keys FCC: AQ6MTN4XZ15 Rect. Enter KEY (also AST, Liteon, Compaq)	997C102	Honeywell 102RX-43S-222E
124D104	Hitek RT-4958TW (US) w/wind keys rect enter key Fcc:AQ6M TN7Z15 (also Dec, AST)	300B84	Hitek 84 Switch KB084
91D105	Hitek RT-4958TW (Euro) w/wind keys 11121166-013 Fcc:AQ6MTN7Z15 (also Dec)	233C102	HQK RB-2001 (Taiwan) (also Cumulus, Identity) Fcc:HQK2VHKEYMOUSE
125D104	Hitek/NMB RT6856TW #247429 w/wind ow keys RT6600W, rect enter key FCC:AQ6CYPRESSZ15	64D103	HQK 103 FCC:BITS 6001 (also Ultra)
262D106	Hitek/NMB RT6856tw (EURO) FCC:AQ6MTN4XZ15	73D102	HQK RB2001 (102 keys)
232D105	Hitek/NMB RT8255C+ w/wind keys & split-spacebar RT-8200W, FCC:AQ6-OAKZ15 121296-001	174D105	HQK TC9500 w/wind FCC:HQK-BITS-6001 Pencilbar
565D104	Hitek RT8255CW(+) W/Wind, Full Spacebar, Fcc:AQ6-OAKZ15 (also NMB)	175D106	HQK TC9500 w/wind (EURO) HQK-BITS-6001
322D105	Hitek/Hurricane Systems RT-2257WLA (EURO) w/wind keys FCC: AQ6MTN71BZDIP (ALSO COMPAQ)	298D105	HQK BITS-6001 w/wind keys (also PC Concepts)
326D104	Hitek RT-2257WLA w/wind keys (also Compaq) RT-2200W, FCC:AQ6M TN71BZDIP	389D106	HQK 9001 FCC:HQK BITS9001 Turbo-trak w/wind "L" enter single size left shift key
405D102	Hitek RT-102T Model 122421-001, Rect enter	425D105	HQK 9001 Turbo-trak same as above full size left shift key
463D104	Hitek RT-5158TW Fcc:AQ6-8Z15, #122546-001	456D106	HQK KB-9001R(+) Fcc:HQK BITS9001 pencilbar single shift keys left and right
641D104	Hitek RT915CTW CONCERTMASTER (also Compaq)	508D104	HQK KB-8801R(+) Turbojet w/wind (EURO & US)
102E118	Hitek RT9258TW, Fcc:AQ692K15, Rec enter, Multimedia	686D109	HQK TurboTrak KB9002R3+ W/Wind Keys
203E104	Hitek RT2900TWIL, Fcc:AQ6-RT2900	810D108	HQK Turbo XWING KB3001RE+ #161Z108
785E103	Hitek RT2300, AQ6-2300	811D109	HQK Turbo XWING KB3001RE+ #161Z109
752E87	HK mini keyboard HK-2208	161E108	HQK BITS9001, Back-L enter (also TurboTrak)
573G104	HK214	211E132	HQK KB9801R+, Multimedia, Back L Enter
561C102	Honeywell 102WN63S-7EN (also Zenith) Fcc:GJK-101WN5 (EURO)	314B107	Human Design System #85-1A
		167B107	Human Design System 107 Switch 87-6A
		355E90	Hyperdata Notebook P14N, win, glidepoint
		639E116	Hyperdata T2C Laptop
		37G95	Hyperdata GL30
		947A102	Hyundai 102 (also BTC, Minto, Packard Bell)
		584B101	Hyundai 286N/386D/386SE/KB5181 (also Identity, ARC, Chicony, Magnavox, Headstart)
			*****IBM is now Lenovo*****
		433B139	IBM Matrix
		138A83	IBM Standard P.C.XT/5531/5291
		470B104	IBM 3290
		434B121	IBM 3180-1
		628A101	IBM ENHANCED P.C./PS-2 Model 30/50/60/80 1397651, 1395100, 1390120 (also Dell, Lexmark) 1392090, 1390131, 1391401, 1331109, 1378162, 1397735, 52G9658, 52G9700, 82G2383, 82G3278, 1YL60g3571, 42H1292, 71G4644, 1395162
		628A101	IBM Valuepoint PS 2, 1394950
		672C109	IBM PS2 w/trackball 139907 FCC:1YL1398150 (also Lexmark)
		821C102	IBM PS-2 w/trackpoint P/N 06H4173 Model M13 92G7461, FRU-06H4842
		400A84	IBM P.C. Original AT
		965A84	IBM Model 25 (Space Saver) 1391472 1370475, 1395682, 1392934
		723B101	IBM PS-1 1395300, 42H0468, 8131276, 73G4614 Fcc: 1YL1398418, 3153

P/N	Description	P/N	Description
946B102	IBM PS-1 (S.A.)(European)	100E106	IBM KU-9958, SK8811, 32P5000, SK8806 rec. enter
76D104	IBM PS-1 (EURO) (104 keys)	305E107	IBM SK8811 (Euro), "7" enter
725A102	IBM PS-2 European Version(102)AT3/30/50/60/80 1391413, 1391506	215E104	IBM/Unicomp UNIO46, PS-2 w/windows, Rec enter
690A88	IBM Laptop Portable	264E115	IBM M9, P/N 92F6271, win, c/c reader, "7" enter
316C84	IBM PS-2 L40 Laptop Portable	281E119	IBM SK8805, SK8809, rec enter, multimedia
490C87	IBM Portable Laptop 350 Type 2618 FCC: AN02618M486	360E120	IBM SK8805, SK8809 (Euro) "7" enter multimedia
731C88	IBM Thinkpad 360/365 Notebook Type 2620	297E94	IBM Thinkpad A22E, Type 2655, trackpoint, rec enter
840C82	IBM Thinkpad w/Trackpoint 2603-17N FCC:IYL2603	340E102	IBM Thinkpad A30, A31, A150, type 2652, Multimedia Fcc: ANOVNCBDC8021B
444D88	IBM 560 Laptop W/ Trackpoint	431E96	IBM Thinkpad R-31, Type 2656, Trackpoint
465D88	IBM Thinkpad 380D Type2635 Fcc:ANO9611TBOON	318E107	IBM M-13, P/N UNIO4G6 (also Unicomp)
690D90	IBM Thinkpad 380D (Euro)	416E94	IBM KPH0035, Rec enter, Trackpoint
755D89	IBM Thinkpad #600, Glidepoint, rec enter	421E104	IBM KB-0225, KB1021, 32P5100,SK-8820, 89P8300 KB1021, 31P7415 Rec enter
854D89	IBM Thinkpad #390 Type 2626 W/Trackpoint	478E105	IBM KB-0225 (Euro), "7" enter key
869D91	IBM Thinkpad #1412 W/Win, Trackpoint, Rec. enter	504E98	IBM Thinkpad R40, Type 2681, Rec enter, Trackpoint, Glidepad
162E96	IBM Thinkpad #1161, Rec enter	550E98	IBM Thinkpad T40, R51, T42, T43, Type 2373, Type 2888 Trackpoint
632B102	IBM 3151/3192/3162/3163/3164 102 keys 1390653, 1395665, 1390670, 1392595 1390940, 1386304, 1390606	551E98	IBM Thinkpad T30, Type 2366, Glidepoint, Trackpoint
610A87	IBM 3178 6052101	564E96	IBM Thinkpad T20, Type 2647
67A87	IBM 3101/3278 w/PF pad	624E96	IBM Thinkpad G40, Type 2384-32U
560A75	IBM 3101/3278 wo/PF pad	755E122	IBM SK8815, SK8812 89P8800
711A101	IBM RT	761E114	IBM SK-8835, KUF0452 rec enter, glidepoint
533A122	IBM 3161/3179/3180/3270(Pyramid keys) 1390238, 82G2383, 82G3278	825E97	IBM SK8845 Thinkpad
814A122	IBM 3191/3192/3196/3197(Flat) 1390572, 1395660, 1390702, 1390576, 1390876	930E96	IBM Thinkpad X41- TabletPC Type 1867
386B104	IBM 3192/3472 (104 Switch)	938E96	IBM R50E laptop
513B122	IBM 3476/3471/3477 1397852, 1394100, 1395662 1394308, 1395160, 1397000, 1397050, 1395660 1394801, 1395661, 1397953, 1394167 (Lexmark)	942E49	IBM M7, #92F6320, FRU93F1918
101C111	IBM 4683 Computer P.O.S.terminal	976E95	IBM R60E
789A83	IBM 5251	972E99	IBM T60 1951-45
308C103	IBM 3151/3152/3162/3163/3164 (EUROPEAN) 1390637, 103 KEYS	29G90	IBM/Lenovo 3000/C100
513C84	IBM 1397901 Mini-Keyboard model M4(also Lexmark)	85G137	IBM POS Part# 13G1249 C/C reader, Trackpoint
798C87	IBM 1379590 Mini-Keyboard Model M4-1 w/trackpoint FCC:IYL1379590, PS-2E	125G97	IBM Tablet X60
616B125	IBM Polydent (European)	138G98	IBM /Lenovo T61 Type 7659-12U
889B65	IBM Wheelwriter III "TYPEWRITER"	271G105	IBM KB0623
893B59	IBM Selectric III "TYPEWRITER"	135B100	ICL M91
894B57	IBM Selectric II "TYPEWRITER"	683B122	Idea Courier 12000 (also Memorex, Telex)
393A62	IBM PC JR. OLD STYLE	214B122	Idea 701626/27/28 (also Lee, Harris, Hon eywell memorex)
553C62	IBM 7527 Data Collection Terminal	782B122	Idea 116528 IDE-K 16428 (also Hitek)
548C50	IBM POS model 100	987A110	Idea 701146-004 (also ITT 1778)
785C18	IBM PS-2E KEYPAD ONLY 1379550 model M4-1	188C122	Idea/NMB 810-12966nmb(also Hitek,NMB)
39D101	IBM Aptiva FRU-06H5305 FCC:J2S101WN-3	388C103	Idea UK English 103 PT#B13707-002(Euro)
62D102	IBM Aptiva (EURO) FCC:J2S101WN-3	301C122	Idea B12917-002(also Harris,Hitek)118285-101
160D104	IBM KB8923 FCC:E8HKB5923(also Chicony)	802C122	Idea B12917-002/118997-001 (also Hitek)
986C101	IBM KB6923,6323 FCC:E8HKB5323 (also Chicony)	54D102	Idea 102
151D102	IBM KB5323 (Euro) (also Zenith, Chicony)	233C102	Identity HQK-RB-2001(also Cumulus, HQK)
916C104	IBM KB6923,6323 w/windows (also Chicony)	584B101	Identity KB5181 (also Chicony, Hyundai, Magnavox Headstart, ARC)
220D105	IBM KB8926 (Euro) FCC:E8HKB5923 w/win keys (also Chicony)	135C101	Identity ZBKB101 SR (also Monterey)
215D92	IBM SUREONE 4614 Formed Keys	735B105	IDT-105
216D12	IBM SUREONE 4614 Universal	450E117	Ifree GL3001, Fcc:OR7GL3001, Multimedia, Trackball
411D110	IBM PS-2 w/trackpoint & trackball	283G119	Ihome IHK210MB
385D112	IBM PS-2 w/trackpoint & trackball (Euro)	264G118	Ikey PM-5K-PS2
502D116	IBM KB-7993 MULTIMEDIA W/Win	859E114	Illuminated Keyboard KB606SL/BK
751D117	IBM KB-7993 (Euro) Multimedia, Win Keys	958D110	Inland KB9908 (also Chicony)
548D104	IBM KB-7953 KB9910 W/Win Keys	591E104	Inland Keyboard
695D105	IBM KB-7953 (Euro) W/Win Keys	278G107	Inland Pro 70009
269E103	IBM KB-9910 (Euro) "7" enter	287G110	Inland 70120 Slim Wireless
725D107	IBM KPD8923 W/Win Keys & Trackpoint	265C105	Insight VT-220 KM-0220 (Euro, UK)
993D119	IBM KB9930 Multimedia, rec enter	192A101	Intecolor (ISC) F8000/F8000GF8001R/8801R/8800/ Intecolor 3800 (101 Switch)
985D120	IBM KB9930 (Euro), Multimedia	470A117	Intecolor (ISC) (117 Switch)
02E85	IBM Spacesaver Model 25, "7" enter	527A112	Intecolor (ISC) (112 Switch)
18E88	IBM Thinkpad 760ED, Type 9546, Fcc:ANOGCF2704AI Rec enter, trackpoint	571A107	Intecolor (ISC) CT220 (107 Switch)(also Paramax)
20E81	IBM Thinkpad 240, Type 2609, Fcc:409TAI-25871-M5E Rec. enter, trackpoint	25C114	Intecolor 103314-CT220
82E96	IBM Type 2621, Rec enter, Wins.	328E113	Intel M/N ISO11469, Fcc: EJM123112960 Multimedia, rec enter
88E94	IBM Thinkpad A20, Type 2628, T23	963E93	Intel EL81NB laptop
		122D105	Interex model MAC105A FCC:F2Q90105ADB
		999D108A&B	Interface s KB-10, Fcc:L2PW PD1B BC, Glid epoint
		37C101	InterF atron 101 IF
		541D132	Interfatron "IFKEYMAC" Fcc:LANPROXPROX2
		526B85	Intergraph Low profile #FT1S0380B
		07C51	Intemec 1700

P/N	Description	P/N	Description
622E80	Intermec 6651	72B84	Key Supply 84 Switch
291A79	Intersil ISB 80-02	860B102	Keytec Mony D data (Brazil)
388D105	Intertec/APC NBK-2104S/C #875644 (EURO) Fcc: GOGAPC-21	718A84	Keytronics 5150
617B122	I/O Devices Model 1181	537A99	Keytronics KB515 1/52 EO 33540 51(also Sperry)
521C122	I/O Devices 2596(also Hitek)	644A87	Keytronics KB5153
279G109	IO Gear Wireless GKM551R	802A101	Keytronic KB 101/MB101/VA101 E03417 (also,Rita , US10 1,AT&T,A rnet,Samsun g.)
398G93	IO Gear GKM561R	84B101	Keytronic 101(+) E03435 (L Shape d Enter Key)
294G119	iOne Scorpius N1	465C101	Keytronics KB-101(+) "L" Shaped enter Key Fcc:CIG8AVE03417
451G90	lone Scorpius P6	338B101	Keytronic E0343 5/XT/AT- Rec enter, (also Gatew ay,AGI Da tamaxx,Mitsu bishi,Goldstar, Premier,S pear Tech nologies)
452G90	lone Scorpius P7	847B101	Keytronics EO-3600 Q KT2000 (also AT&T)
946E104	iRocks KR6810 illuminated keyboard	153C103	Keytronics EO 360 8Q-FC(also AT&T)
202G104	iRock s KR6820 illumina ted keybo ard	131C102	Keytronics EO-3608 Q306E(also AT&T)
580G104	iRocks KR6130	848B101	Keytronics EO-3601QF1/E03601QL(also AEG)
698C102	IPC Dynasty Model IPC7849R(euro)(also BTC)	215C101	Keytronics/DFIE03601E/3601EL Fcc:CIGEO3600
491B100	ISC Systems Model 4900	215C101	Keytronics FLASH 101/KT2000
763B12	ISC model 6330 Keypad	677B102	Keytronics EO3602 KT2000 (EURO)
556C101	ISNJK-258 (made in Malaysia)	236C102	Keytronics EO360 2Q(Euro)(also AT&T)
386C101	ISNJ-168 (also Sunshine,NTC,NanTan)	971A102	Keytronics Switch (Euro UK)E03418
955E87	Itronix IX270 laptop	89B101	Keytronics EO3443(also Unisys,Dec)
291B101	Jade 101 SK-8801(also Liteon, Computrend,KLH)	62B122	Keytronics 122 Switch/KB 3270 PLUS FCC:CIG8AVE03448
518C101	JKB-6151B (also SR-9151B)	177B23	Keytronics Adder Pad old model
803E91	JKWL03	641B23	Keytronics Adder Pad EO32 18XTAT-1
811A84	Kaypro P.C. (also BTC)	484B105	Keytronics Mac Pro
168A76	Kaypro T-2/T-4	228C106	Keytronics Mac Pro (Euroean)
523E109	KB-122 Fcc:D8 40902 Back-L enter	436B102	Keytronics Quicksilver
585E107	KB-1307	606B85	Keytronics Switch 85
581E104	KB-6 (also Kensington)	943A101	Keytronics 101-1 (E03370)(also AT&T,Radio Shack,Phillips)
916C104	KBD-WIN95 Fcc:E8HKB5923	814B109	Keytronics EO35 56051 (also Pitney Bowes)
426G107	KBJ-006UB	106C126	Keytronics EO35 56054 (also Pitney Bowes)
742C102	KBM-102 FCC:J6G-KTIC-KBM102 (also SIG)	989B84	Keytronics Notebook Portable A4 UO4003001
685D104	KDS MCK600W Fcc: KXJMCK701W (also Ortek, PC Concepts)	908B84	Keytronics KB5184WP
840B95	KEB 95 Key (European)	201 C85	Keytronics Port.EO400 600 2US (also Memorex/Telex)
939C105	Kensington #64330 Mac (also Macally)	259C91	Keytronics EO354 6051 (also Fisher)
124D104	Kensington #64340 (also Dec)	271C102	Keytronics EO341 7202 (also AT&T)
581E104	Kensington 64340A, 64340HD,K64376 Back-L enter	272C98	Keytronics EO3555 001 (also AT&T)
696E104	Kensington 64331, K64338 Key layout Pyram id shape, Back-L	295C100	Keytronics KBTRAK101 M/O#092895-01 Fcc: CIGTRAK101 w/Trackball
849E104	Kensington K64350	635C101	Keytronics KBTRAK010SV (EURO) w/trackball FCC:CIGKBTRAK-101
336E107	Kensington K64370	296C101	Keytronics KBTRAK-PRO M/O#089155-03 FCC: CIGTRAKPRO
850E123	Kensington K64333	317C101	Keytronics "Eurotech" M/O 092355-01 EO3624E, EO3636US001-N, Fcc: CIGEO3600 Also Data General
1970B104	Kensington Comfort Slim K64332	347C102	Keytronics "Eurotech 102" (European) EO3602ESV DOC-102
958E127	Kensington K64379	758B106	Keytronics M/N EO359400,M/O081009 (Also Data General)
19G112	Kensington Slimtype#64365,K64366, Mac rec enter	504C101	Keytronics EO5000 M/N 096025-04 FCC:CIGEO5000
253G90/254G17	Kensington Slimblade Media K72279US	428C102	Keytronics EO5002FR (Euro)FCC:CIGEO5000
276G104	Kensington K64370A , PK1100U	520C138	Keytronics #501013528 FCC:CIG8AVE03417 (also AT&T)
434G119	Kensington K6 4390, M01006k Pilot Board Laser W ireless	543C85	Keytronics EO4006US FCC:CIGEO4006
528G104	Kensington Profit Washable 01067	523C102	Keytronics EO36 14SP (Euro,S.A.) FCC:CIGEO3614 (also Hewlett Packard)
623G108	Kensington Slimtype K72357US, JME8277U	546C101	Keytronics EO3614US (also Hewlett Packard) FCC:CIGEO3614
1888B107	Kensinko MCK-2000 (also Ortek)	567C28	Keytronics Abacus Mac KEYPAD M/O 104203-02
628C102	Keyboard Computer KC-286 (Euro)	640C105	Keytronics EO3616TIOS ABA (also Hewlett Packard)
408C73	Key Communications KBAK9448A-250042	694C84	Keytronics Block Keyboard
864D104	KeyPlus KB121 Fcc:D840902 Back L- enter	739C104	Keytronics Natural Keybo ard(also Micro soft) M/N EO3786US FCC: CIGEO3786
656D139	KeySource International KSI1292 POS (Euro)(W ombat)	745C105	Keytronics EO2968053 (also Bell & Howell)
657D159	KeySource International KSI1290A POS (Euro)(W ombat)	749C109	Keytronics EO3617US M/O 53832418(also HP)
804D103	KeySource Intemational KSI2196, SKR1196WT6A	757C101	Keytronics Protbuch 5105 FCC:CIGEO5100
805D160	KeySource International KSI1290 W/ CC Reader	762C107	Keytronics EO3470KTC FCC:CIGEO3470
242E120	KeySource International KSI8500, rec enter	780C102	Keytronics M/N 5102FR FCC:CIGEO5100 (EURO)
573E160	KeySource Internatio nal KS 11290-A (also W ombat)	915C106	Keytronics EO3616FRABFA M/N 106092(also HP)
618E100	KeySource International KSI-1196I,GJJSWK8095WS		
787E100	Keysource International KSI1401 (also W ombat)		
2013B100	KeySource International KSI-1445, 1448		
643D89	Keysource Intemational KSI-2107		
986E160	Keysource Intemational KSI1390-2NPB		
1895B142	Keysource Intemational SKI1293		
166G104	Keysource Intemational KSI-1451, 1457GFB finger print reader		
227G86	Keysource Intemational KSI8630		
328G89	Keysource Internation al KS2109 (Euro) Fcc: GJJSPR8695WT		
357G159	Keysource International KSI1391 3NPD back L enter		
613G104	Key Source International KSI 1457GYHB -Senseo left		
907E120	Keys U See P-21 (Also Scorpius)		
97G116	Keys U See		

P/N	Description	P/N	Description
890C104	Keytron ics KB101 (+)-C w/wind ows keys "L" enter key FCC:CIGKB101PLUS	946E104	KR-6810 illum inated keyboard (also iRocks)
891C104	Keytron ics KB101 -C w/wind ows keys rect. enter key FCC:CIGEO3418	36C101	Kris Te chno logies KB5191(also Chic ony,Hand ok,Auva,)
23D104	Keytron ics EO360 1QL-C,E03601 QLPS2 -C W/W in KT2000 "L" enter key FCC:CIGEO3600W	659D104	KTX KB9000 Fcc:LCACE KEY1 (also ACEKEY)
31D104	Keytron ics 3600QL-C w/wind ows keys rect. enter key FCC:CIGEO3600W	313C101	Kurt Check SR-8151B FCC:FPWSR-8151B996B59 Kustom Electronics MCT-30(Mobil term)
29D104	Keytron ics Eurotech-C,LT-DESIGNER Rec Enter, Win FCC:CIGEO3600W	654B16	Kustom DXT Mob il terminal keypad(up per)
30D104	Keytron ics Eurotech EL-C w/wind ows keys 3601ELCN-C "L" enter FCC:CIGEO3600W	653B56	Kustom DXT Mob il Terminal Keyboard (lower)
19D104	Keytron ics EO3602-ELSV -C w/wind ows keys Eurotech-FC-C,Eurotech-SP-C (EUROPEAN)	415E124	Labtec Y-SN28 (also Professional)
77D105	Keytron ics 3602QFR-C (EURO)w/wind ows	2027B104	Labtec Y-SM46
75D105	Keytron ics EO6102FR-C (EURO)w/wind ows	585E07	Labtec Y-SR47 (also Logitech) 867307-0403
100D104	Keytron ics Connectkey-C w/wind ows keys LT-CLAS SIC double back space, ba ckward "L"Enter FCC:CIGEO6100	864E104	Labtec Y-SAC64, 867571-0403 (also Logitech)
112D104	Keytron ics EO6101D-C , KT-800, Tag-A-Long FCC:CIGEO6100, back_l enter, win keys (Toshiba)	78G119	Labtec Y-RAC66 Fcc: 10WRKM88 (also Logitech)
165D104	Keytron ics Lifetime LT-WIRELESS "WL" EO62051R-C	525E83	Landel Mailbug LT301, Fc c:CNM LA-27707-DT-E
166D104	Keytron ics Lifetime "LTP" w/touchpad M/N EO6230US201-C	22D108	Lanix SK720P Fcc:GYUR59SK (also Liteon)(Euro)
167D104	Keytron ics Lifetime "WLTP" w/buchpad	67G105	Lanix KB0402 (Euro) Part#03514
168D104	Keytron ics Lifetime "WL TB" w/track ball	167G123	Lanix KU-0512 (Euro)
169D104	Keytron ics Lifetime "LTTB" w/trackball Model # EO6205T-BHW -C	165B105	Lanpar Vision II
433D107	Keytron ics Lifetime Trakpro Touchpad SV (EURO) w/wind ow keys	831B103	Laser Pal 286(also Leading Technology) FCC: BNX84-H80-2269-1
431D108	Keytron ics Lifetime LT Trackball SV (Euro) w/wind ow keys	479B102	Laser 102 ("L" Shaped Enter Key)
186D101	Keytron ics PCXAL-GA FCC:CIGEO36004(also Dec)	480B102	Laser XT (Rectang ular Enter Key)
226D105	Keytron ics 6100Z FCC:CIGEO6100Z (Euro)	354B90	Laser 128 EX
368D104	Keytron ics KT800 Rec enter FCC:CIGEO6100Z	35C101	Laser 386SX-T FCC: 1010DS (also Packard Bell,BSR,CMS,Leading Tech,Cordata,Leading Edge, Samsung,Emerson,Se Jin,Data train)
445D116	Keytron ics EO6150US011C MULTIME DIA (Gate way)	109C102	Laser L386SX Slimline(also Expotech) FCC:IFS80-2269-1
551D110	Keytron ics (Voyager) mode IEZ-1000 W/W in	138D57	Laser PC5 Portable
552D104	Keytron ics (Pilot)Model#EO5305RS Fcc:FKD46AK280W (Also Monterey)	803B102	Latin America 102(Delta Tech)
578D105	Keytron ics K280 (Euro) Fcc:FKD46AK280 (Also Monterey)	655A83	Leading Edge Model D DC2014
553D104	Keytron ics EO5305US0-15C, Fcc:FKD46AK288W (Also Monterey)	15B101	Leading Edge D-2/D-3 Enhanced DC3014
617D105	Keytron ics EO5305 (Euro) Fcc:FKD46AK288 Also Monterey	110C101	Leading Edge Model DC2214
649D101	Keytron ics Clientec	36C101	Leading Edge KB5191(also Chic ony, Handok,Kris Tech,Auva)
666D104	Keytron ics EO6350US001-C P/N7001049	204C101	Leading Edge SMK 1030 (also Se Jin, Sherwod) DC3611
884D104	Keytron ics F-Scan-KSC (FS/SC-K) With Windows, Trackpoint, CC Reader	35C101	Leading Edge CDC 2003 EAT1010 (also CMS, Leading Tech,Data train,BSR,Se Jin,Packard, Bell,Cordata Laser,Sa msun g,Emerson,)
885D104	Keytron ics F-Scan-K001US (FSCAN K), EO3812US001, With Windows, Trackpoint	475C101	Leading Edge AK1012 FCC:JJJAK-1012S
886D104	Keytron ics M/N EO3634K1USNP-C, S-Card-001US With Window keys, CC reader	492C101	Leading Edge 5369 (also BTC)
77E123	Keytron ics KB5331,EO5351, M/N EO5331USIMM-C, Multimedia, Back L enter	831B103	Leading Technology 5500/7000 DX(also Laser)
371E104	Keytron ics EO5366BTOPS-2C, Fcc:FKD46AK5300 (Also Monterey)	34C101	Leading Technology 50006800SX GJJ4AKEAT-1010R2(also Samsung,CSS,Se Jin)
495E120	Keytron ics EO4601-C, Multimedia , back-L enter	35C101	Leadi ng Technology 6000SX Data train FCC: GJJ4AKEAT-1010DS(also CMS, Cordata,Laser,Samsung,BSR,Emerson) Leading Edge Se Jin,Packard Bell)
496E104	Keytron ics EO4601-C, Win in keys back L enter	312C102	Leading Technology PC PARTNER FCC: BN X84h80-2269-1
978E107	Keytron ics KT300USB13US	329A85	Lear Siegler ADM#5
117G104	Keytron ics KT-400- U2	503A84	Lear Siegler ADM #11 Pyramid Keys
950A101	Kimtron Enhanced	325C84	Lear Siegler ADM#11 full keys(also Zentec)
291B101	KLH SK8801B (also Liteon,Jade, Computrend)	836A107	Lear Siegler ADM#12(+)ADM#11(+)
529B102	KLH 101 Plus(5339RO)(also Packard Bell, BTC,Goldstar,Mitsuma,Tatung,Hewitt Rand)	251B122	Lear Siegler ADM#42
615G103	Klip Extreme KKS-050E	918A87	Lee Data 87 Keys 343700102
1865B105	KM2601/3501	938A90	Lee Data 90 Keys
935B102	KMB 88102 (S.A.)	214B122	Lee Data 122 Keys(also Harris,Memorex, Honeywell,Idea)
57B73	Kodak Ektachem 700/UK102	515B124	Lee Data 2280
918B101	Kodak Ektachem 500/700C/550/750 (also AID)	*****	Lenovo - see also IBM
423C102	Kodak Ektachem 500/700C/250(also AID)	438G95	Lenovo SL510, model 28473ZU
721C102	Kodak APC(EURO)CC:E8HKB-5311(also Chic ony)	466G92	Lenovo SL410, Type 2842
347C102	Kodak Ektachem Analyzer model #9501RC#250	496G92	Lenovo SK8855
950E100	Kool WL-8458VT (also Dafron)	511G80	Lenovo Idea Pad S9, S10 - Keys Only
939B84	Kontron IP Lite Portale	517G98	Lenovo X200 table t - keys only
		518G98	Lenovo T510 laptop type 4349
		534G101	Lenovo G550 - keys only
		554G104	Lenovo JME7053
		566G99	Lenovo T410S, T400 - keys only
		586G104	Lenovo KUF0452 No Glide point
		483A101	Liberty Freedom 100
		351A103	Liberty Freedom 110
		153B107	Liberty DG
		186B101	Liberty 101 Enhanced #116406
		78C101	Liberty 116545-001(also Hitek)

P/N	Description	P/N	Description
177C105	Liberty 116428-001(a Iso Hitek, Tektronic)	986D108	Lite-On SK-1500 (Euro) Fcc: GYUR63SK 3 buttons on top, "7" enter
598C102	Liberty UK 102 PC (Euro 102)	70E107	Lite-On SK1500 C, Rec enter
949A103	Link 125	94E109	Lite-On SK1689, Fcc: GYUR89SK (Euro) "7" enter (also AIMC, Dell, Compaq)
16B84	Link P.C. Term	196E120	Lite-On SK720-H (Euro), GYUR59SK, "7" enterkey
17B84	Link Alloy PC	545D105	Lite-On Sk7100, Fcc:GYURSK7100P (also PC Concepts)
692B102	Link MC2/MC5 3 lights EPC (also Alpha Micro) Wyse 84035830/50-120-000-102	502E42	Lite-On SK7510 (also RTI)
539B105	Link MC5(raised above F keys)	07G104	Lite On SK2355 (also MPC)
579B105	Link MC5(flat above F keys)(also Wyse) ANSI 50-120-000-101 (also Ansys TO300 European)	110G107	Lite on EZ9900 back L enter
840A101	Link MC5 ASCII P/N 50-120-000-100 (also Altos, Wyse)	980D104	Little Tykes Kybd. #1721, win keys "L" enter
511B102	Link 50-120-000-103 (also Radio Shack, Brother)	499D89	Litton Data Systems "LKEY0010" "PVT1"
118C105	Link MC27 105 Keys220	859E114	Logisys Illuminated KB606SL
119C113	Link MC27 113 Keys	735D104	Logitech M/N RT7R5XTW Fcc:DZL122799 Rec. Enter
250C103	Link IEPC (Euro)p/n 50-120-000-104	435D121	Logitech SK2500, YSB-3, Fcc:GYUR40SK Multimedia (also PC Concepts)
352B105	Link MC-3-220 (also NEC)	890D104	Logitech Sk-720,YSA2, 867061-0100 Deluxe 104, Fcc:GYUR49SK
618A105	Link 105 (also Wyse, Triad)	891D116	Logitech iTouch, Cordless, Y-RB6, RT-7R00,RT7R20, YSE-8,Y-BC9, YBA9 Fcc:DZ1201252, 1124254-101A, 867074-0100,967018-0403,RT7R10, 867061, 867196 -0703, 867039-0100,867063-0100 Multi. (also Dell)
27D108	Link 108 50-120-320-001	897D117	Logitech iTouch Pro #YRB7, YRJ7, Y-RAU7, 867039-0100, DZL211255 Ergo w/win Multimedia
817D105	Link P/N 900244-67 (also Wyse, Triad)	110E107	Logitech Y-SG13, YRC14, RT7R01, 867090-0100, DZL221407, RT7R11V:58TW, Rec enter, Curve space bar, 3 keys above directionals
244C101	Linksys 386 SX/25	26E107	Logitech YSF-11 (also Acekey)
543D104	Linkworld Model 104DYW54-114 Fcc:J2S104DLY	304E122	Logitech Y-RF21, Y-RE20,Y-RJ21 RT7R03V:5XTW, DZL211498, Cordless, Multimedia
516D105	LinkWorld Model#105DYW76-596,KB-6001 Fcc: J25104DLY	408E124	Logitech Y-BF38, RT7R26 V:58TW, Y-BE22, RT7R24, Y-RJ20, ERGO,ELITE, 967231-0403, 867223-0100 Multi, Rec enter
660D104	Linkworld Model 104DAW15-19 Fcc:J2S104DAW	424E123	Logitech Y-RF21, Y-RE20 Fcc: DZL211498, ERGO
675D104	Linkworld Model 104DYW66-485 Fcc:J2S104DLY (also Unicomp)	477E115	Logitech Y-RH35, Y-SR34, RT7R06,access du o 967305- 0403, 967225-0403, 967228-0703, 867221-0100, Fcc:JNZ128481
861D104	Linkworld Model 104DAW24-100 Fcc:J2S104DAW, Rec enter	580E111	Logitech Y-ST39, Y-RAD67, 867575-0403, Rec enter, Multimedia, Win.
926D104	Linkworld Model 104DYW10-100 Fcc:J2S104DLY Rec enter	585E107	Logitech Y-SR47 (also Labtec)
349E108	Linkworld Win98, rounded keys, curve spacebar	725E107	Logitech Y-SP32, ACK-270A, Curve spacebar, back-L enter (Also Ace key)
291B101	Lite-On 101 Enh SK8831/SK8821/SK8801B-IU SK8802R (also Computrend,Jade,KLH) FCC: GYURO55K	739E104	Logitech Y-SU45, 867378-0403, 867560, 967334-0403 rec enter
724C102	Lite-On SK8802R (EURO-UK)FCC:GYU30H-SK-8802H)	740E109	Logitech Y-RQ57, 867397-0403, 967407-0403, fcc:JNZ201774, Cordless Desktop Express
555C101	Lite-On SK-8801EN FCC:GYURO9SK	1600B105	Logitech Y-SD5, SK6201
15C101	Lite-On SK-0002-1U	1991B107	Logitech Y-SQ33, SK2910
286C101	Lite-On SK-8843-IU FCC:GYUSK-8843(also Alton)	758E135	Logitech Y-RR54/LX-700, RT7R33 fcc: DZL131836M Multimedia, rec enter
445C101	Lite-On 4100R model Sk4100 RIU FCC:GYURO2SK(also Arche)	759E127	Logitech Y-RQ53, LX-500, RT7R31, fcc:DZL131139 Multimedia, rec enter
579C101	Lite-On SK1000RS FCC:GYUR10SK Rectangular Enter Key (also Dell,AST)	769E119	Logitech Y-RQ52, LX-300, RT7R14, Y-BH52, 967234-0703, 867395-0100, 867401-0100, RT732,967415-0403, DZL131836
565C101	Lite-On SK2000R FCC:GYUR10SK "L"Enter (also Zenith,Ultra,Elite, Hewitt Rand)	783E103	Logitech Y-SU61, 867462-0403,868026-0403 rec enter
753C101	Lite-On SK-3000R FCC:GYUR09SK(no pencil Bar) (also Silitek)	822E128	Logitech Y-RR53 (Euro), RT7R31, Fcc:DZL131838 "7"
936C101	Lite-On SK-1200 #230851-001C(Also AST,Hitek) FCC:GYUR15SK	861E113	Logitech Y-RK56A (Euro)
970C104	Lite-On SK-1100CW w/window keys "L"enter FCC:GYUR26SK (also PC Concepts)	864E104	Logitech Y-SAC64, 867571-0403 (also Labtec)
579D105	Lite-On SK1100CW (Euro) W/Win	870E115	Logitech RU58, 867400-0403, Fcc: 03L-PT03-K2F
09D104	Lite-On SK1000REW/SK2000REW w/windows Keys FCC: GYUR26SK (also Dell)	877E115	Logitech EX110, Y-RR71, SK7207,LX310, Y-SAE71, SK2930, Y-RAZ71, 868026-0403, 7207C
48D108	Lite-On SK6000 (also PC Concepts) FCC:GYUR33SK	895E114	Logitech Y-RK49, 867318-0403, Fcc: JNZ201587
957C104	Lite-On RT6655TW FCC:AQ6MTN7Z15(also AST,Hitek)	892E135	Logitech Y-YRAM74, MX3000 867616-0100 Fcc:DZL134041
285D104	Lite-ON SK2000REW-KK2003WR IU w/win keys FCC: GYUR34SK "L" shaped enter	917E123	Logitech MX5000, Y-RAH72, RT7RB1, 867615-0403 DZL201974
391D116	Lite-On SK2501 FCC:GYUR38SK Multimedia (Also Hewlett Packard)	918E96	Logitech Dinovo Y-RW42, 867431-0100 Fcc: DZL201801
435D121	Lite-On SK-2500 FCC:GYUR40SK Multimedia (also PC Concepts)	923E111	Logitech Y-SZ49, 867449-0403, Rec Enter
621D122	Lite-On Sk-2500 (Euro) Fcc:GYUR40SK (also PC Concepts)	945E117	Logitech Y-RAK73, S510,S530, Fcc: DZL202065 Rec enter
692D101	Lite-On SK710 Fcc:GYUR12SK (also ATR)	948E112	Logitech Y-RAJ56A - Rec enter (also AOPEN)
498D104	Lite-On SK710 W Fcc:GYUR29SK W/Win	951E129	Logitech G15 Gaming keyboard model Y-UG75 Rounded internet buttons
822D108	Lite-On SK720P Fcc:Gyur59sk(also Lanix)(Euro)	18G104	Logitech Deluxe 250, Y-SAF76U,Y-UT76 Rec enter
694D104	Lite-on G9900 P/N 7001024 Fcc:GYUR51SK (also Gateway)		
645D105	Lite-On G9900-2D (Euro) Fcc:GYUR61SK		
713D88	Lite-On SK7500 Website Keyboard Fcc:GYURSK7500		
202D104	Lite-On SK5002W		
764D104	Lite-On Tucson 2000 (SK2001) Fcc:GYUR37SK Win Keys, Back L enter (also Maxiswitch)		

P/N	Description	P/N	Description
23G123	Logitech MX3200, M/NRAV80,RT7R16, Rec enter	35B101	Maxi-Switch 101 Enh/ME101 2 18603XX/ 2189001 XX/2189013("L"shaped Enter) 2191-0001-XX (also Everex,AL R,Gateway,Opus, Avtech,Easydata,Texas Microsystems)
24G120	Logitech LX710, M/N Y-RAP78, 867667-0403	689B101	Maxi-Switch 101 Enh. rectangular enter
40G112	Logitech 350, Y-UM76A,Y-JL76, 867771-0403, Laser 1500, Y-RAS79	987B124	Maxiswitch "ANYKEY"(also Gateway) 2189014-XX
62G132	Logitech G11 Gaming Keyboard, 868004-0403 Y-UG75A	953B102	Maxiswitch/PrintaForm (S.A.)
81G103	Logitech Classic 200, Y-UR83	221C101	Maxiswitch 218617(VFS#35B101 w/keyhole)
92G117	Logitech "Wave" Y-RCP140, K350, MK350, MK550 Y-UV90, Fcc: JNZYRPC140	345C124	Maxiswitch Maxi-Pro II 2189022-00-211 FCC:D7J2189022-XX
101G104	Logitech Y-SW45	406C105	Maxiswitch Portable 2186185-00-21
155G107	Logitech Deluxe 660, 650, Y-RAR76 -rec enter	566C101	Maxiswitch 2192004 FCC:D7J2192-004 (also CompuAdd)
157G93	Logitech Y-RAY81 DiNovo Edge, 967685-0403	148D123	Maxiswitch 2189037-00-003 (also NCD) Model N123NA
177G105	Logitech Y-SAF76-Euro "7" enter	446D104	MaxiSwitch 2196002 Fcc:D7J2196001 (Gateway)
205G104	Logitech Y-UR83, classic 200 (euro)	537D105	MaxiSwitch (MagiPro) Euro Fcc:D7J2196-001
207G104	Logitech S520, Y-RBBA97	540D104	MaxiSwitch "MAXISOUND" 2195012-00-001 W/ Windows and Speakers
208G114	Logitech MX5500, RT7RBZ, Y-RBF91, 820-00814	764D104	MaxiSwitch Tucson 2000 (SK2001) Fcc:GYUR37SK Win keys, back-L enter (also LiteOn)
209G106	Logitech Illuminated Y-UR95, 820-081268, LZ845BD	285C139	MCK-142 PRO 139keys only (also Ortek)
270G121	Logitech Pro2800, Y-RBM79, Pro2400, K320, Y-R0010	693B101	MCK-101 (also Oemax,Ortek)
316G115	Logitech MK300, Y-R0002, MK320, Y-R0009	360D89	Mega Image 911CD/ Samsung 911CD/Ocean PC FCC:A3LS500 w/ touchpad and win keys
345G111	Logitech MK700, Y-R0006, MK710	42B100	MEI Keyboard (also Qume)
321G102	Logitech EX100, Y-RBH94, MK250	628B102	Memorex/Telex 102 (European UK)
369G128	Logitech G15 Gaming keyboard Y-UW92 Rectangular internet buttons, Rect enter key	214B122	Memorex 1477 122RX43S-46E(also Honeywell, Lee Data,Idea,Harris)
370G133	Logitech G19 Gaming keyboard, model Y-U0005 820-001975, rect enter, screen on top	578B101	Memorex/Telex Freedom 1(European UK)
374G109	Logitech DiNovo for Mac, Y-R0001, rec enter	308B122	Memorex 1196/1192
375G113	Logitech Wave 450, Y-U0001, rect. enter	683B122	Memorex/Telex C/P#211292 (also Idea)
423G101	Logitech K300, Y-U0004	450B101	Memorex/Telex 101 214114-006
407G100	Logitech K340, Y-R0005	757A87	Memorex 2178
481G130	Logitech G110, Y-U0007, 820-002713 rectenter	758A122	Memorex 2179
483G104	Logitech K120,MK120, Y-0009, 820-003288 rect enter	03C107	Memorex M-22 (also,Honeywell,Bull)
498G114	Logitech 600, Y-UQ85, 820-000025 rect enter	164B83	Memorex 2051
544G111	Logitech MK200	846A87	Memorex 87 Switch L97990451
545G141	Logitech G510 Gaming Board Y-U0010	902A88	Memorex #96272125 (European UK)
546G114	Logitech MK520, K530, Y-R0012, 820002864	903A88	Memorex #96272471 (European UK)
597G107	Logitech K800 Wireless Illuminated, Y-R0011	506B87	Memorex Model 589584/2078
621G112	Logitech Media K200	282B122	Memorex 122 Switch
196D101	LT-5000 AUS-101 FCC:JNPLTK-8049-5M	48C102	Memorex/Telex 211760-001
338D101	LT-6800 FCC:JNPLT-6800	121C104	Memorex/Telex 104RX33S C/P211761-001
994B122	Lynk Lynklite III	151C101	Memorex/Telex 101RX33S-6E(also Dec, Honeywell)
513B122	Lynk 901022-50 LX-122US (also IBM, Lexmark)	201C85	Memorex/Telex Port EO4006002US (also Keytronics)
16C102	Lynk 102	231C101	Memorex-Telex 101 #961459-001 AQ659ZMT (also Compuadd,Hitek)
665D103	Lynk 90100500 (Euro)	653D105	Memorex TS1000 (also Belkin)
939C105	Macally MK105 FCC:12MACALLYMK105X	810D108	Memorex TS1000 108 key (also Belkin)
899D105	Macally ikey Rec enter	359E120	Memorex MX5200, multimedia, windows, rec enter
961E108	Macally iKeylim	641E104	Memorex MX5000, TS1500
429G109	Macally BT key	749A58	Memotech MTX 512
442B101	Magitronics D-K 172 FCC:FMA44HKB6251 (also NTC,Zeos,NanTan,BSC,Twinhead, Premier,Dataware,Wang)	603D88	Metrobook II Laptop w/touchpad
498C102	Magitronics DK-170/DK171-B FCC:IYNKPT-102	684D90	Metrobook VL Laptop Fcc:A3LS590
388B101	Magnatronic 101	615C84	Microbit MB3724 CC Reader FCC:GUM 35B-19442-DT-N
819B108	Magnatronics FK2000(+)(also Focus)	202D104	Micro Innovations,multimedia SK-5002W FCC:GYUR30SK (also Liteon,Reveal)
725B101	Magnatronics K158 (also Unitek)	108D104	Micro Innovations KB5911(also Chicony)
726B101	Magnatronics K159 (also Unitek)	978D108	Micro Innovations KB1001R+, Ergo. "L" enter (also PC Concepts)
584B101	Magnavox/Headstart KKB5181(also Chicony, Hyundai,ARC,Identify)	590E108	Micro Innovations KB200i, CH#91120374 Back-L enter Three keys above arrow s
454B91	MAI Basic IV model 4309	876E117	Micro Innovations KB982W, Fcc: 10WRKM074XXX
01B91	MAI Basic IV/Model 4313 400646-001	161E108	Micro Innovations KB400i, KB420BL(also HQK)
947B110	MAI Basic IV DT4315-001(also Fujitsu)	406G103	Micro innovations KB1405LSR
948B111	MAI BASIC IV DT4315-002	530G116	Micro Innovations KB575M
815B92	MAI Basic IV 400646-052	XXXXXX	Micron ALL MODELS SEE HITEK
816B92	MAI Basic IV 400589-002 model 4312	538C101	Micron RT6656(+) Fcc:AQ6-CYPRESS (also Hitek)
431C82	Marquardt 7065 FCC:IYZ7065	875D89	Micron (TREK R) NBKU375 Laptop W/win, Glidepoint
796C72	Marquette Electronics 401574-002	140E104	Micron #5121, FCC:E5XKBM104M10UC (also BTC)
797C61	Marquette Electronics 411656-001	148E95	Micron N870-004CL6-M1-700, Rec enter, Glidepoint
648E110	Matias Corp. SMK-Power989, The Tactile Pro, Fcc: KM9-356M9ASMK	652B101	Micronics PC4X(also Hitek,Arch Rival)
282G107	Matias USB2.0 FK105	856B103	Micro Peritericos (Brazil)
350G106	Matias FK205 folding kybd., rect enter		
525G108	Matias Tactile Pro FK302, FK204, FK304, FK305, FK306		
316D84	Maxilian DX		
792A84	Maxi-Switch AT (also Telex)21 86020xx		

P/N	Description	P/N	Description
150G107	Micros KB819EB	136B105	Microtem 4525
501E86	Micro slate Wireless FDC34 02, Rec enter, (also W ombat)	171B109	Microtem VT 100
739C104	Microsoft Natural #58221 M/N EO3786US FCC:CIGE O3786 (also Keytronics)	170B105	Microtem 5510-VT220
98D105	Microsoft Natural (EURO) #58221 FCC:CIGE O3786 (also Keytronics)	18C103	Microtem 103 key
529D104	Microsoft Natural "Elite" M/N EO6401PS2, KU0045 X08-76725	969C85	Midwest Micro TS30CS FCC:11RTS30CS
687D105	Microsoft Natural "Elite" (Euro) M/N EO6401PS2	978B84	Milttope 84
461D82	Microsoft "MININOTE" PORT MINI Laptop	992E125	Mitsuko KM9801
915D123	Microsoft Natural PRO M/N RT9401,RT9403,RT9402, RT943 1 MS# X01-94432 Ergo, W in keys, Rec enter, Multimedia	809D86	Mini Keyboard 5510M
916D114	Microsoft RT9410, RT9443, Internet, MS#X04-80803 X08-76763, X09-71487 Rec enter, Multimedia	727B101	Minta 286/386/486/P9(K-160/K-260) (also Unit Tech, DigiCom)
932D115	Microsoft Internet RT9410 (Euro), MS #X04-80845 Ergo, Multimedia, windows, "7" enter	947A102	Minta 286/386(5339) (also BTC, Packard Bell, Hyundai)
12E123	Microsoft Internet Pro # R9420V:5FTW, MS#X04-86289 RT9421, RT9441, Rec enter, multimedia	477B101	Mitac 101
63E124	Microsoft RT9420 (Euro)	662B101	Mitac Colonret 101/Kb5201
327E125	Microsoft RT9450, RT9461 win, multimedia, rec enter	669C102	Mitac 5182 FCC:E8H51KKB-5182(also Chicony)
329E104	Microsoft KU8933, rec enter, (also Wyse)	184C102	Mitac 5349(Euro)(also BTC, Pack Bell, Facit, Donatec)
448E119	Microsoft Wireless Multimedia 1.0A Keyboard, 10 14, WBR0168, WUR0335, X09-66570, KB0168 C3KKB9, Rec enter key, X08-78035	25E88	Mitac #6133, windows, glidepoint (notebook)
449E120	Microsoft KB0 168 (Euro) Wireless multimedia	351B84	Mitek K2AX
447E119	Microsoft RT-9470, ERGO, Wireless Optical	808B44	Mitel SX-2000
663E106	Microsoft RT-9480, Basic 1.0A rec enter	185B101	Mitsubishi Enhanced 101
742E128	Microsoft 1031 multimedia (22 Internet buttons)	704B101	Mitsubishi 101+ MP-82KB A"L"shape return
928E121	Microsoft 1031, KC0405 (15 internet buttons) X800152	338B101	Mitsubishi 030 MP-82KB A(also Keytronics, Datamaxx, AGI, Goldstar, Premier, Spear Technology Gateway)
1988B102	Microsoft Optical Elite Desktop, 1002, 1011, 1027, 1045 RT9490, Elite for Blue tooth, Finger wheel left (127)	529B102	Mitsuma Mini(5339R)(also BTC, Goldstar Packard Bell, Tatung, KLH, Hewitt Rand)
805E124	Microsoft Wireless Comfort 1.0, 1008, 1027, 1029, 1045, x08-00015-001 Slide Rule left side	586B101	Mitsumi 101 (also Compu add) KPQ-E99-YC
857E113	Microsoft RT2300, Wired 500 keyboard, X08-801382-002	403B101	Mitsumi 101 KPQ-E99-YC (Rect. Enter)
878E122	Microsoft Ergonomic 4000 Model 1048, KU0462	255C101	Mitsumi KPQ-E99AC FCC:EW4KPQ2479A "L" Shaped Enter Key"
879E113	Microsoft Comfort Curve 2000, Model 1047, KU0459	656C102	Mitsumi KPQ-E99AC (EU ROPEAN) 102 Keys
904E120	Microsoft Remote Media Center Model 1044 X802485-002	485C101	Mitsumi KKR-E99AC/KPQ-E99ZC-12 FCC:EW4KKR4018/CMYKPQ6640 "L" Enter Key
996E117	Microsoft 6000 V2, WUR0571, 1074, 1052, 1028 MS#X806612-001, 4000 - non ergonomic	643C102	Mitsumi KKR-E99AC (EU RO) 102 Keys
997E110	Microsoft 3000, WUR0563, MS#X806594-001 Fcc:C3K1066	542C82	Mitsumi 50921006 (also Epson)
25G112	Microsoft 700 Cordless, M/N 1060-square internet buttons	622C101	Mitsumi KPQ-E99AC (Rectangular Enter Key) (also Compaq, Hitek) 160648-101
69G129	Microsoft Wireless 5000 (Euro) 1074, WUR0577 X806619-014	12D104	Mitsumi KPQE99ZC-13/ KPQEA4ZA model ZW FCC:KPQ7461 w/window keys "L" enter FCC:CMYKPQ6987
197G123	Microsoft Wireless 1000 model 1356 x816851-001	538D104	Mitsumi KPQE99ZC-13 (rect. Enter Key)
206G116	Microsoft Reclusa KUH0612	113D104	Mitsumi KPQEA4YA-15 w/window s keys FCC:CMYKPQ7067
235G108	Microsoft Wired 600 - M/N 1366	131D105	Mitsumi KPQE99ZC-13(EURO) FCC:CMYKPQ6987
240G127	Microsoft 6000 V3, Aero edition - model 1123, 114, 1374	314D104	Mitsumi KPQ-EA4AA-18 FCC: CMYKPQ-7103
241G127	Microsoft Digital Media 3000 model 1343, x815082	584D105	Mitsumi PCK104-SKB (Euro) Fcc:CMYKPQ7615
365G127	Microsoft 3000 Wireless Desktop model 1379, rec enter	601D104	Mitsumi KFK-EA4XA Fcc:CMYKFK7741 Back-L enter
293G119	Microsoft 7000	881D104	Mitsumi KFK-EA4XA Fcc:CMYKFK7741, Rec enter key
334G101	Microsoft 7000 entertainemnt board model 1073	982D105	Mitsumi KFK-EA5XA Fcc:CMYKFK7741, "7" enter
373G104	Microsoft Wired 400 v1.0, rect enter	339E119	Mitsumi KFK-EB9HY Multimedia, back L enter
384G113	Microsoft Optical Desktop 700 v2.0, M/N 1132 X814717-001 oval internet buttons, rectenter	515E105	Mitsumi KFKEA4SA (Euro), Fcc: CMYKFK7835 "7" enter
390G103A/B	Microsoft Sidewinder X6, KU0753, x817172-017 Keypad (B) can be attached left or right	1886B087	Mitsumi KFK E87YY
606G119	Microsoft Sidewinder X4, 1431, KU0951	476C101	MKB-931 (Taiwan) FCC:KFJMKB931
432G101	Microsoft 8000 Wireless Entertainment Board	280D104	MKB-951 w/win keys FCC:KFJMKB-951
404G125	Microsoft Wireless 5000, 1394/1387/1364/WUG0872	519D81	Mobil Data Systems Data 911
437G104	Microsoft Wired 200, 1406, X821411-004	818B63	Mobil Data Terminal 9100-10/9100-11/D3013A
622G75	Microsoft ARC keyboard model 1392	62C72	Mobil Data Terminal 9100-20
624G108	Microsoft Wireless 800, 1455, WUG1008, x821893-001	519D81	Mobil Data Terminal MDS-2000
778C105	Microspeed KB105M FCC:FUUA DBKEY001	851B101	Model America 116626 (SEE HITEK FOR OTHER MODELS)
931C104	Microspeed KB295 SKR-2033 rect. enter 9724-M (also Sejin)	34B105	Modgraph 105 Switch GX 2000
401D89	Microspeed KB-086-P wireless w/track ball w/win keys FCC:GJJSWK-8695WT	730B102	Monterey K104 (also Actebis, M Tek) FCC:FKF456K-104
643D89	Microspeed KB200 (also Sejin)	91C101	Monterey K104(101 key Version)
102A67	MicroSwitch #12343	92C101	Monterey K108 FCC:FKD45AK108 (also CeleM)
10B101	MicroSwitch 101/Honeywell	9766B81	Monterey K109
471B102	MicroSwitch 102(European)(also Victor)	135C101	Monterey K208 FCC:FKD46AK208 (also Sunshine, Protouch)
857B88	Microtech HF88 (Brazil)	140D104	Monterey K-208 w/win dows keys
		283C81	Monterey KB-MINI-81K FCC:FKD46AK110P (also Sunbouch, Protouch)
		610C102	Monterey K-208 (EURO, S.A.) FCC:FKD46AK208
		260D105	Monterey K-208 w/win (EURO) FCC:FKD46AK208
		552D104	Monterey K-280 W/Win Fcc:FKD46AK280

P/N	Description	P/N	Description
553D104	Monterey K-288 W/Win Fcc:FKD46AK288	608C83	NCR 2850
578D105	Monterey K-280 Euro Fcc:FKD46AK280 W/Win	827C109	NCR P.O.S. model 7450 F/K-100
617D105	Monterey K-288 Euro Fcc:FKD46AK288 (also Keytronics)	41E108	NCR 7452, P/N 497-0411737, C/C reader
840D122	Monterey K-360 Fcc:FKD46AK360 With Win keys, multimedia keys, Back-L enter	891E111	NCR 5932-51 497-0432900
867D107	Monterey K-288 Fcc:FKD46AK288, Back-L enter, win keys, 3 extra keys over directional keys	401A67	NEC 8201/8300 portable
918D108	Monterey K-288 (Euro) same as above	889A85	NEC Multi-speed portable PC 1601/1602/1602-2EL
919D105	Monterey K-220 (Euro) Fcc:FKD46AK220	324B93	NEC Powermate Portable
921D108	Monterey K-289 (Euro) Fcc:FKD48AK288	37B101	NEC Powermate I/II/III/APC 412 FCC:7ZAPCH412, 410E
61E108	Monterey K-292 (Euro) Fcc:FKD46AK292	73B101	NEC Powermate APC/286/286+ model HA410 (also Data General, Acer, Stone, Delta, Cannon, Multitech, Tex. Instr)
14E107	Monterey K-290 Fcc:FKD46AK290 (also AOPEN)	93C98	NEC/Jalpas SO740-03KB
279E107	Monterey KB-855 back-L enter (also AOPEN)	352B105	NEC Visalink 220 (also Link)
371E104	Monterey AK5300 Fcc:FKD46AK5300 (also Keytronics)	113C78	NEC Ultralite PC17-02 Portable
599E107	Monterey K297, Fcc:FKD46AK297 (also AOPEN)	180C78	NEC Ultralite 286F PC-22-01 Portable
2037B107	Monterey K-293	661C85	NEC Ultra Versa 50E 440-1531 laptop Model PC-450-1521 FCC:A3DP51S
761B102	MOS VTS II Postal Keyboard	478C101	NEC ready 433ES (also Compaq, Hitek, Dec, AST, NCD) #158-050550-000
627E90	Motion Computing KB-1011	658C102	NEC FE-100-S102 (EURO) 102 Keys
444A67	Motorola KDT 480	738C83	NEC Versa V/50 FCC:B7ZP7
620A86	Motorola Four Phase 7200	996C83	NEC Versa S/33 Portable laptop PC-120-412201 FCC:EF7PC130S1033
50B14	Motorola Hand Held	106D88	NEC Versa 2000C PC-6010-11402MW FCC:EF7PC600601RT1
97B91	Motorola FT 45/KP409	247D85	NEC Versa 4050H6040X Laptop w/ glidepoint PC-6110-71602 A3DP8/A3DP55
646A105	Motorola AA220 (also Ampex)	916C104	NEC 5923 (also Chicony, Reveal, SIG, IBM)
564C72	Motorola (MDI) 9100-386/9100T/9100WS	509D104	NEC KB8963 #158-052288-000 W/Win
818B63	Motorola (MDI) 9100-10/9100-11/3013A	591D80	NEC MobilePro 700 Minilaptop W/Win
62C72	Motorola (MDI) 9100-20	593D80	NEC MobilePro 750 Minilaptop W/Win
197C14	Motorola 9100 series monitor numberpad	795D78	NEC Mobilepro 770 Fcc:BSTJPN-3352 DTE
384D81	Motorola Mobil Term.MW-520 w/glidepoint	796D78	NEC MobilePro 800, 880
173E84	Motorola BLT, Touchpad, Rec enter MW520 Backlit	803D90	NEC Ready 220T Laptop W/Glidepoint, Win
175E82	Motorola BL82, Glidepoint, Rec enter	507E78	NEC Mobilepro 900, Model MP9000
224E10	Motorola CDM-4550-LS	545E78	NEC Mobilepro 900 Rounded Corners
500E87	Motorola MW800, P/N 4080364L12, Glidepoint	905E106	NEC PC9800 model 699526
745E84	Motorola /TG3 BLT, KBA-BLT	1573B104	NEC SK1300
746E82	Motorola /TG3 BL82, KBA-BL82A	46G92	Neoware M100 laptop
828E93	Motorola ML900 with Fingerpad	741D96	Netsurf Fcc:NFD5KM9701-T, Back-L glidepoint
201D104	Mouse Systems KWD203 Fcc:Liakwd-200	814D105	Netier ACK210 Fcc:L2BACEKEY210 (also ACEKEY)
916E90	MPC Transport X3100 laptop	963E93	Nextel EL80
07G104	MPC SK2355 (also Liteon)	441D104	Nimble NBK2104-5/S Fcc:GOGAPC-21 curve spacebar
1925B104	MPC SK3105 (also Dell)	254D105	Nimble FCC:MDTNBK-110X "L" enter
173G92	MPC E-155 laptop (also Gateway TB-120)	255D105	Nimble FCC:MDTNBK-110X "7" enter
*****	ALL Mtek models SEE MONTEREY	860D109	Nimble NBK-2104-5/S, Fcc:GOGAPC-21, Win keys Back-L enter, Curve Spacebar (also APC)
798A98	Multitech 98 Switch	909D109	Nimble SPK-2000 (F-21YQ) Fcc:GOGAPC-21 (also APC)
961A97	Multitech KB 097AT (also Acer)	193E125	Nimble F21GQ, Fcc:GOGAPC21 "7" enter, (also ACE, PC Concepts, Softkey)
73B101	Multitech KB101 (also Acer, Stone System, Delta Gold, Cannon, MultiTech, Texas Instrument, Data Gen eral)	544B121	Nixdorf Ct08 (European)
442B101	NAN TAN KB6251EA (also Zeos, Magitronics, BSC, Twin Head, Premier, Dataware, NTC, Wang)	545B126	Nixdorf Ct05 (European)
870B101	NAN TAN KB 6151EA (also NTC, Unitek)	729D105	NK-33 W/Win, Back-L enter, Curve Spacebar
710B97	NCD N-97	730D104	NK-33 W/Win, Back-L enter, Curve Spacebar Universal shift keys
711B101	NCD 100 (Northern Telecom, Hitek)	930D109	NK-688 Fcc:NZHNC-33, windows, Curve Spacebar
154C108	NCD-N108LK (also Hitek)	1679B108	NK-558 ***** NMB Technologies -See Hitek *****
478C101	NCD N-101M 119063-001 (also AST, Hitek, NEC, Dec, Compaq)	565D104	NMB Tech. RT-8255CW+ W/ full spacebar
14D107	NCD-107	232D105	NMB Technologies RT-8255CW+(also Hitek)
148D123	NCD model N123NA (also Maxiswitch) 2189037-00-003	599D108	NMB LK401 P/N 122530-001 (also Fisher Rosemount)
711B101	NCD N-101PS (also APC, HITEK)	478C101	NMB RT3555+ Fcc:AQ6MTN56Z15 (also Compaq, Dec)
611A95	NCR PC-4/PC-6	168C127	Northern Telecom NT 4X81DA "TOPS MP"
726A116	NCR PC-8/916 /Enhanced (also Honeywell II)	711B101	Northern Telecom Keyboard (also NCD, Hitek)
560B101	NCR 916/Cherry G81-3000 RS3000 G83-3077-SBU	70B101	Northgate 101
81B100	NCR 4940 (also Adds)	237B101	Northgate Omni 102
996A112	NCR 112 Switch	313B107	Northgate Omni 102 (+)
475A75	NCR 2830 Indust. Grade Term. (75 keys)	312B103	Northgate NEW 102
476A82	NCR 2830 Indust. Grade Term. (82 Keys)	564B119	Northgate Ultra
129C105	NCR ANSI 117085-001 (Also Hitek)	13C116	Northgate Ultra-T
295B101	NCR 2950/4940 Class K140	618B108	Northgate Omnikey "N" 101-N
584C84	NCR 3150 Model 0110 Laptop w/Trackball FCC:83LS39355SC	619B102	Northgate Omnikey "I" 101-I
516B101	NCR 101 Workstation 3299-K430	891B101	Northgate Omnikey 101-NI
843B108	NCR 7052		
500B98	NCR 7930		
986B112	NCR 7070 VDU (P.O.S.)		
70C106	NCR 3413-K440-V001 (also Adds, Hitek)		

P/N	Description	P/N	Description
892B104	Northgate Omnikey KA102	947A102	Packard Bell 286(also BTC,Hyundai,Minta)
192C120	Northgate Omnikey Ultra-F	184C102	Packard Bell(EURO)(also BTC ,Facit, Mitac,Donatec)
315D117	Northgate Omnikey Ultra-TP w/win keys FCC:GT6OMNIKEY	35C101	Packard BellM1US06A-P9 FCC:KEAT1010DS also(Leading Technology,DataTrain,CMC BSR,SE Jin,Cordata,Laser,Samsung, Emerson Leading Edge)
375C83	NP-92 Portable FCC:GS6NP-902S	332C101	Packard Bell BPCS#120019 (Also BTC,Reveal) FCC: E5XKBM111
701E90	N spire model#CL50, rec enter, Glidepoint	710C101	Packard Bell 5130 BPCS #120032 FDA1021 (also BTC) FCC:E5X5R5BTC
443B101	NTC KB6451EA (also Zeos,Nan Tan)	647C102	Packard Bell 5149(EURO) 102 Keys(also BTC)
870B101	NTC KB6151EA (also Nan Tan,Unitek)	833C85	Packard Bell Statesman(+) 810414 Type NTB003 FCC:DGHH4805 (also Zenith)
442B101	NTC KB6251 EA (also Zeos,Nan Tan,Magitronics, BSC, Twin Head,Premier,Dataware,Wang)	08D105	Packard Bell 5131C/SK2100W/FDA1051 (also BTC) FCC:E5XKBM10510/E5XKBM10610
220C101	NTC KB 6351	512D116	Packard Bell FDA-116CA MULTIMEDIA Fcc:F4ZFDA116CA
402C101	NTC KB 6551 FCC:FMAKB6551(also Unitek)	52E117	Packard Bell FDA-116CA (Euro)
386C101	NTC FCC:ISNJ-168(also Sunshinne)	119E07	Palm Pilot IIe (also 3Com)
120E64	NTS Dreamwriter 200, NTS C200 Fcc:NFJES250	286E07	Palm Pilot Visor
121E64	NTS Dream writer T100, T110, T400, T400/IR, IR	602A83	Panasonic Senior Partner Portable
122E64	NTS Dreamwriter IT, Dreammax 700, Fcc:NFJC600	878B77	Panasonic Portable KXD4925
1711B064	NTS Dreamwriter 325	982B84	Panasonic Business Partner 150 Port. (also Tandy 1110 Portable,Grid 1720)
748A84	Oak Switch 84 Position	253C85	Panasonic CF170 Portable
121B105	Oak Switch V T 220 Style	332B101	Panasonic 8899183-AUI(also Radio Shack,Dec)
431B98	Oak Switch 5-64951-049	25D84	Panasonic CF-41 Laptop w/trackball
746C105	Oak 5-64995-195 (also Bell & Howell)	453D89	Panasonic CF-25 w/touchpad/WIn Fcc:ACJ9TGCF-25
360D89	Ocean PC 911CD/Mega Image 911CD/Samsung Portable Laptop FCC:A3LS500 w/touchpad	474D89	Panasonic CF-62 Fcc:CF-62EXE4AAM W/Glidepad
693B101	OEMMAX Mac 101 MCK-101(also MCK,Ortek)	558D89	Panasonic CF-35 W/ touchpad
694B31	OEMMAX (Multi-key pad)31 keys	622D90	Panasonic CF-45 Fcc:ACJ9TGCF45
626C32	OEMMAX (Multi-key pad)32 keys	626D84	Panasonic CF-M31 MiniLaptop
186G107	OG-KBJ790A	711D89	Panasonic CF-71 Laptop
169C101	OKI HMB 35957-14	712D89	Panasonic CF-27 Laptop
170C101	OKI HMB 35957-70	914D90	Panasonic CF-47 Laptop W/Win, Glidepoint
410B95	Olivetti 3/ANK2465	571D91	Panasonic "LET'S Note" AL-N4 MiniLaptop Fcc:AL-N4T512J5 W/ Trackball
399B87	Olivetti ETV3000/EVT 260	22E89	Panasonic CF17/CF-M34 Laptop W/Win, Glidepoint
363B102	Olivetti M24/ANK 2462	27E89	Panasonic CF37 Toughbook Fcc:4X2USA-33859-MM-E Windows, Glidepoint
364B99	Olivetti M40/M48/M64/Ank 1427	169E90	Panasonic CF-48, Glidepoint, Rec enter
610B102	Olivetti 240/280 (European)	362E89	Panasonic CF-72 Glidepoint, rec enter, windows
144C101	Olivetti ANK-27-101	394E87	Panasonic CF-28, CF-29, CF-38, Rec enter
454C102	Olivetti ANK-27-102N (Euro)	921E90	Panasonic CF-29 Full See I
750C101	Olivetti ANK-28-101	493E90	Panasonic CF-50 Toughbook
888B60	OmniFax	576E90	Panasonic CF-73, CF74 Glide point
795B65	OmniNote	670E90	Panasonic CF-VKBL01 (PDRC keyboard)
06C84	OmniNote Model 2100 new	674E87	Panasonic CF-T2 Fcc:ACJ9TGCF-T21
854E07	Omnitech 50.OMTKB.001	756E90	Panasonic CF-51 glidepoint
768B106	Online (also Soroc)	1954B082	Panasonic CF-18, CF-19
88A93	Ontel 93 Switch Keyboard	888E85	Panasonic CF-T4, Fcc:ACJ9TGCE-T41
35B101	Opus 8140(also Maxiswith,Everex,ALR Gateway,EasyData,Texas Micro,Avtech)	93G90	Panasonic CF-52
626C32	Ortek MCK-32S Keypad Only FCC:GM8MCK22LT	131G85	Panasonic CFT7
694B31	Ortek MCK-31S Keypad only 31 keys	156G90	Panasonic CF30
285C139	Ortek MCK142 PRO FCC:GM8MCK142PRO(also MCK)	185G87	Panasonic CF-W5
310E143	Ortek MCK142 Pro Fcc:GM8MCK142 PRO (143 keys)	304G84	Panasonic FT-T8 Laptop
693B101	Ortek MCK-101(also MCK,O em ax)	571A107	Param ax (also Intecolor)
552C101	Ortek MCK-101FXw/Template Compartment FCC:GM8MCK-101SX	397C101	PC Accessories Model KB20030 w/Trackball Fcc: E8HKB-5581A (also Chicony)
373C105	Ortek MCK-104 PRO FCC:GMB3ZT-MAK105 (also ETC, Power Glide)	443D104	PC Accessories P20035 Fcc:F2QKT95104
225D104	Ortek MCK701W w/win keys FCC:GM8MCK101M	776C102	PC Concepts Model 7001 Ergo Keyboard Fcc:LIAKB-7000 (also Ace,Addison,Chicony)
570D18	Ortek MCK 18 Keypad	970C104	PC Concepts SK1100 CW w/windows keys "L" enter Fcc:GYUR26SK (also Lite-On)
693D85	Ortek MCK84 Fcc:GM8MCK84PAD (also Suntouch)	48D108	PC Concepts "WAVE" ERGO w/window keys and Wrist rest,Model SK6000(also Lite-On, Reveal)
685D104	Ortek MCK600 W Fcc:KJXMCK701 W (also PC Concepts)	357D109	PC Concepts SK6000 (Euro)ERGO Fcc:GYUR33SK
546D106	Ortek TKB970 (also Adesso)	225D104	PC Concepts #61596 Model SK701W
975D107	Ortek MCK701 W, Fcc:KJXMCK701 W, "L" enter, Curve spacebar	282D106	PC Concepts Mac Wave Ergo 61500(EZ-9000) US version FCC:MWIEZ-9000
68E122	Ortek MCK800 (also TrueTouch)	309D101	PC Concepts Standard 101 model F-21 Fcc: GOGAPC-21 (also APC)
366E86	Ortek MCK-84/MCK-86 Fcc: GM8MCK84 KBPAD, "7" enter key	298D105	PC Concepts Turbo-plus w/window keys Fcc:HQK-BITS6001 #61590(also HQK)
529E101	Ortek MCK-91, MCK-90 (also Adesso)	435D121	PC Concepts Quantum 2000 Multimedia SK2500 Fcc:GYUR40SK(Also Liteon)
1888B107	Ortek MCK-2000 (also Kensinko)		
530A88	Osbourne Executive		
975B59	Osys (European)		
41C34	Osys Mapec 03062 (European)		
231B102	Packard Bell Enhanced		
438B101	Packard Bell FKB4700 (also Fujitsu,Data General, Dasher)		
529B102	Packard Bell Legend IV (also BTC, Goldstar,Mitsuma,Tatung,KLH,Hewitt Rand)		
701B101	Packard Bell 101 Key		
464B84	Packard Bell KCLEA907L		
427B101	Packard Bell Enh 101 (also BSR)		

P/N	Description	P/N	Description
201D104	PC Concepts KWD203 Fcc:LIKWWD-200, #61595	400D28	Preh MC35 Keypad
545D105	PC Concepts "SURFBOARD" Wireless SK7100 W/Win., Multimedia Fcc: GYUSK7100P	417C01	Preh M84W Universal
546D106	PC Concepts "EZBOARD" W/ Glidepoint #62970	510C84	Preh M84WX
547D109	PC Concepts "WAVE2000 Convertible) SK6100W W/ Trackball Fcc:GYUR24SK	605C114	Preh M128WX
621D122	PC Concepts SK2500 (euro) Fcc:GYUR40SK (also Liteon)	750D128	Preh WX128
685D104	PC Concepts MCK600W Fcc:KJXMCK701W (also Ortek, KDS)	554D104	Preh M128WX 90402-011
975D107	PC Concepts #6159698, Fcc:KJXMCK701W, "L" enter Windows, Curve Space bar	292A67	Preh AK87
976D107	PC Concepts #6184098, M/N KWD820, "L" enter	776E09	Preh MC128WXWANISLMI #90320-200-0000
977D104	PC Concepts #63142 M/N KUB835, Rec enter,	777E111	Preh MC128WX #90319-000-0000
978D108	PC Concepts #6151398, Turbo Stream, KB1001R+ Ergo, windows, "L" enter, (also Micro Innovations)	982A20	Preh NK20 (4 X 5)
193E125	PC Concepts F21GQ (Euro) (also Ace, Nimble, Softkey)	291B101	Preh Series 2000 Enhanced
299E104	PC Concepts KWD-701, back-L enter (also Genius)	524C00	Preh M128WX Universal
538B102	Peacock 102 (European)	551B40	Preh 8 X 5 keypad
942B122	Pendar 122K (European)	767C44	Preh M84WX Special Configuration
44E122	Perfect Choice PC-200024, Multimedia	759C20	Preh 4 X 5 Keypad
438E123	Perfect Choice PC-200055, Multimedia (also APC)	892C16	Preh 4 X 4 keypad
439E125	Perfect Choice PC-200048, (also APC)	594D119	Preh Commander PC-POS 90313-001/000 W/ Credit Card Reader
85C114	Pericom MG-200-058(European)	767D25	Preh MC25 W/ LCD #90321-001
187A64	Perkin Elmer 550B	05E110	Preh MC128WX, #90320-201-0000, CC Reader, Rec enter
465A130	Perkin Elmer 7500	158E125	Preh MC128WX WN#90319-000 (all keys formed)
450G119	Perrix Periboard 506/711, W2026TB	159E84	Preh MC84WXWNM1 90325-003
453G80	Perrix Periboard 509/709	221E117	Preh MC128WX, #90319-052/0000
962A102	Philips 102 Switch	235E39	Preh MC84WX S N M3 #90325-013/0000
646A105	Philips TA35588(also Ampex 220)	280E110	Preh MC128WX #90319-000/0000
539B105	Philips P-2707(European)(also Link)	398E126	Preh MC147WX, #90320-601/5555 win, rec enter
869B99	Philips P2855 (European)	399E106	Preh MF112C, #90320-411/0000 "7" enter
851B101	Philips 117532 RT101+(2813-015) (SEE HITEK FOR OTHER MODELS)	400E140	Preh MC140WX #90327-000/0000
943A101	Philips 2814 (EO 3370)(also Keytronics, Radio Shack, AT&T)	503E50	Preh MC80, WXWNSLK5, 90318-044/0000
230C102	Philips P2814-043 (European)	589E49	Preh M84WX C1n01 90311-005/1001
10B101	Philips P2814-000 Fcc:GJK35U101WN-2	676E80	Preh MC80WX 90318-000/0000 all keys formed
183E88	Philips Web-TV KW1133/00F-US	919E68	Preh Commander
373E101	Philips M3180-40010 (also Compaq)	960E110	Preh Alpha MC128WX
374E102	Philips M3180-40011 (French) (also Compaq)	129G127	Preh MC13100 Rec enter
375E106	Philips M3180-40012 (Japanese) (also Compaq)	484G133	Preh MC147, Intellidesk
730E109	Philips M3180-40015 (Japanese) (also HP)	495G132	Preh MC147
731E105	Philips M3180-40014 (German) (also HP)	338B101	Premier101 EO 3435(also Keytronics, AGI, Gateway, Mitsubishi, Data maxx, Goldstar, Spear)
748E106	Philips KB-0316 (Korean) (also HP)	442B101	Premier250 KB6251 (also NTC, Nan Tan, Wang, Zeos, BSC, TwinHead, Dataware, Magitronics)
813C137	Pioneer P.O.S. w/cc reader model KB137-2	546D105	Primekey TB640 EG95PK (also PC Concepts)
814B109	Pitney Bowes F192011(also Keytronics)	272B110	Prime PT 250K
904C101	Planar INS-1180	353C103	Prime EPC-UK (also Qume)
106C126	Pitney Bowes J684000/EO3556054 (also Keytronics)	953B102	Printaform AT/M axiswitch (S.A.)
595B101	P.O.C. Echo 386	955B84	Printaform XT/BTC (S.A.)
282E107	Posiflex KB-3100 Series, C/C reader	783C101	Professional Key-Board TK-M501C FCC:IZITK-105M
655E125	Posiflex PST7000/6000/1000	69E126	Professional P/N154758, Fcc:IZITK105M (Also Truetouch)
502C103	Positron model 912112-1	268E109	Professional PS2-3421, Fcc: IZITK-105M
628D105	Positron (Express) #912112-7 W/Win Keys	415E124	Professional Y-SN28, Fcc: IZITK-105M, "7" enter Multimedia, (also Labtec)
359D105	Power Computing 55118	619E109	Professional KB-AK2002R, Fcc: IZITK-105M (also Alaska)
373C105	Power Glide 105 FCC:GMB3ZT-MAK-105 (also ETC, Ortek)	712E125	Professional multimedia fcc: IZITK-105M
398C104	PowerSource Computer Sys Keycat II Trackball FCC:HMN-2YZ Keycat	915E105	Professional KW D-701 (Euro) "7" enter (also Solidus)
424C101	Precision Instruments KB101RM Fcc:E8HKB5311	790E107	Professional P010 Fcc: IZITK105M (also BenQ)
653D105	Precision KB6868	859B103	Prologica SP-16 (Brazil)
997D109	Precision KB6868, P/N F8E206, back-L enter 3 keys above directionals	817B101	Proteus 2001(also Focus, CSR)
187B113	Preh Commander P.C.	135C101	Protouch KB101PT(also Monterey, Mtek, Sunshine)
446B114	Preh Commander PC-AT3	923B142	Provue Desktop/Fisher
623B103	Preh Commander PC-19R	187C142	Provue Console/Fisher
971B79	Preh Commander M84AN/90307-007(Euro)	259C91	Provox, Fisher Micro desktop CPN11 B8000 X042(also Keytronics)
495C86	Preh MF87 Keyboard 90300-085/0006AT	80B36	Psion Organizer II
629A101	Preh 101-CD102EX	634C56	Psion HC100 Hand Held Computer
397D00	Preh 90318-000 MC80	621E58	Psion Notebook Pro 3100
398D63	Preh 90320-000 MC80 Alpha MC1WX	705B101	Qtronics 301
362D00	Preh 90319-000 MC128	680B101	Qtronics 30BP with Ball Control
396D111	Preh 90320-200 MC128 Alpha	213C94	Qtronic KT-30/QX301(double Keys on Numeric Pad)
02D77	Preh 90313-000 PC-POS	799C101	Qtronic QX-301(EURO) FCC:F2Q4NEKT-30
399D111	Preh 90314-000 PC-POS JR.	839B32	Qtronic Mighty Keypad
		311D18	Qtronic 18 key keypad QX-018
		599C101	Qtronic QX-601R-AT FCC:F2Q-QX601
		726C102	Qtronic X681R (Euro-UK)

P/N	Description	P/N	Description
727C83	Qtronix Scorpius 83 Model QX883R FCC:F2Q-QX-883	254C101	Radio Shack 2500SX/25 (also SeJin,AST,Samsung,Trigem)
736C98	Qtronix KT-60Mw/trackball FCC:F2Q-KT60 (also Reveal)	511B102	Radio Shack/Tandy DT110 (also Link)
754C22	Qtronix numeric pad QX-022 FCC:F2Q-022P	903B115	Ram tek (115 Keys)
187D101	Qtronix QX-101 FCC:F2Q-QX101	589B91	Rand on Colleague Portable
236D102	Qtronix-Scorpius 901(compact)F2Q-QX901L	455G130	Razer Trantula Gaming Board RZ03-0007
402D105	Qtronix Scorpius 95 model KT95M FCC:F2QKT95104 w/Trackball & win keys	993A86	RCA 86 Switch
422D104	Qtronix KT305 Scorpius FCC:F2Q4NERT-35	941B101	Recortec 7101N(also CSK)
423D108	Qtronix Scorpius 35 FCC:F2Q4NERT35W W/ Trackball	964B140	Reuters/Rich AK123KT (European)
443D104	Qtronix (Scorpius 104) Scorp104 Fcc:F2QKT95104	865C101	Reveal KB100 FCC:BTC55SERIES(also BTC)
655D105	Qtronix Scorpius (Euro) Fcc:F2QKT95104	332C101	Reveal KB101 (also BTC, Packard Bell)
691D32	Qtronix Mighty Keypad Scrprius32 QX032H	736C98	Reveal KB500 Trackball Kybrd FCC:F2Q-KT60 (also Qtronix)
759D124	Qtronix Scorpius 98N plus, Fcc:F2Q4NE98 Multimedia, Win Keys, Back-L enter	916C104	Reveal KB5923/KB195 (also Chicony, SIIG) w/window keys FCC:E8HKB-5323
952D107	Qtronix Scorpius 98A, Fcc:F2Q4NE98A, Scorpius 980A Plus, Fcc: F2QNE980 Win, Rec enter	776C102	Reveal KB600 Ergonomic
197E107	Qtronix Scorpius 2KP/2KU/2KH, Rec enter	48D108	Reveal KB695 (also Lite-On, PC Concepts)
222E110	Qtronix Scorpius990P, Multimedia, rec enter	202D104	Reveal KB395 SK502W (also Liteon, Micro Innovations) FCC:GYUR30SK
239E124	Qtronix Scorpius 980T Plus, Fcc:F2Q4NE980, Multimedia, trackball, rec enter	802A101	Rita 2010/E03417 (also Keytronics, AT&T,Amet,Dell,Samsung,US101)
249E108	Qtronix KB-985P (Euro), Fcc:F2Q4NE98A	563G114	Rocketfish RF-BKTB2
401E107	Qtronix Scorpius KII rec enter	712A54	Rockwell Collins Aim 65
241E108	Qtronix Scorpius KII+ (Euro), "7" enter	502E42	RTI SK7510 (also Lite-on)
404E107	Qtronix Scorpius KII+, Rec enter, Win Keys	511D94	Sage MicroSystems AUTOMOTIVE Keyboard
949E110	Qtronix Scorpius K3NT	35E91	Sager 3300C, Fcc:L4PK3100CX13, Rec enter
96G107	Qtronix Scorpius 35 keyboard, Back-L enter trackball	229G109	Saitek Edipse II model KU0603
208B84	Quantel 52301 (84 Switch)	346G108	Saitek Edipse KU0418, KU0573
638C68	Qualcomm Mobil Computer Model CV90-3656-1 PCIM6014	449G116	Saitek Edipse Cyborg #PK17U, Eclipse III, KU0832, PK24U
382D70	Qualcomm Omnitrac#10-8575-21	740A106	Samsung 106 Switch
699C69	Qualcomm Omnitrac#2000	426C101	Samsung SEM-K20N-1, SEM-K20S (also Datatrain) FCC:E2XSEM-K20N, 20S
713E68	Qualcomm Omnitronics CV90-53152-4	802A101	Samsung No vell (also Keytronics, Arnet,AT&T,Dell,Rita,US101)
868E80	Qualcomm MVPE computer	129B101	Samsung KKB-5161 (Chicony)
989E69	Qualcomm Omnitrac# CV90-52689	35C101	Samsung 101 Fcc:1010DS (also Packard Bell,BSR,CMS,Leading Tech,Leading Edge,Cordata,Laser,Emerson,Se Jin)
916C104	Quantex KBD Win95 (also Chicony)	34C101	Samsung 101 FCC: 1010R2 (also Leading Technologies,CSS,Se Jin)
421G167	Quest V2708	336C101	Samsung 1010SI FCC:GJJ4AKEAT-1010SI (also Se Jin)
457E85	Quickpad IR, Wireless Keyboard	254C101	Samsung SKR-1032(also Radio Shack,Sejin)
458E85	Quickpad PRO	584C84	Samsung Sens 700 Laptop
456A85	Qume 101/102A QVT101 301453-01	360D89	Samsung SENS 500/Mega Image 911CD/ OceanPC 911CD Portable Laptop FCC:A3LS500 w/touch pad & win keys
587A91	Qume 103	533D90	Samsung SENS Pro 520 Laptop Fcc:A3LS520
778A103	Qume 108	585D104	Samsung SEM-DC8H Fcc:E2XSEM-DC8H (Acer)
566A102	Qume 109/119	708D104	Samsung SEM-DT45/DT35 Fcc:E2XSEMDT45
927A102	Qume 109(+)/119(+)/101(+)	95E105	Samsung SEM DT-35 (Euro), "7" enter
588A107	Qume 202	323E104	Samsung SEM -C19V2 (also System ax)
554B105	Qume 203(+)/323EV	898E91	Samsung X25 Laptop M/N NP25C0003/CHN, Fcc: 6CTTA I-36146-M 5-E
80C101	Qume QVT31	468G83	Samsung NP-N310 laptop
208C102	Qume 303496-04(Euro)	441B101	Sanyo MSC0990(European)
257C105	Qume ANSI 363498-11	438B101	Sanyo Multimedia FKB4700 (also Dasher,Data Gen,Fujiitsu, Earthstation,Emerson,Vendex,Tatung)
42B100	Qume 303908-11 POS QVT-191 (also MEI)	148C127	SASI P.O.S. KB1028
353C103	Qume QVT82 (Euro)(also Prime)	554E93	SASI EX-10KB Cash Register Keyboard
380C102	Qume QVT82 (US)P/N 303688-11	255B53	Satec 53 Switch
807C101	Qume 303687-11	809B86	Scantech 86 Key
965C105	Qume 303686-11 "7" enter key	907E120	Scorpius P21 (also Keys U See)
955C101	Qume 303496-01	589G107	SealShield SSKSV107- Washable keyboard
89A67	Radio Shack TRS -80 Model III/IV	34C101	SeJin GJJeat-1010R2 (CSS,Samsung,Lead tech)
379A72	Radio Shack 100 Portable	35C101	SeJin GJJeat-1010DS(also,Leading Edge, Datatrain,Cordata,Laser,BSR,Packard Bell,Emerson,CMS,Leading Technology)
674A72	Radio Shack 102 Portable	336C101	SeJin 1010SI FCC:GJJ4AKEAT-1010SI (also Samsung)
650B57	Radio Shack Color III	204C101	SeJin SMK 1030 (also Leading Edge,Sherwood)
385A101	Radio Shack Data Term .100(also Wyse,Altos)		
649A90	Radio Shack Tandy 1000/2000 EX/SX		
429B76	Radio Shack Tandy 1400 Portable		
654A94	Radio Shack Tandy 3000(also Fujiitsu)		
943A101	Radio Shack 1000/3000 Enh. (also Keytronics,AT&T,Phillips)		
890A82	Radio Shack TRS-80 Model 16B		
332B101	Radio Shack Tandy 1000SL(also Panasonic, Dec) FCC: AAQ99R25-4032		
982B84	Radio Shack/Tandy 1110 Portable (also Panasonic portable 150)		

P/N	Description	P/N	Description
254C101	SeJin SKR-1032 (also Tandy,AST,Samsung, Trigem) FCC:GJJSKR1032B	923C106	SIIG Supertouch(+) model JK-AND-012 FCC:GM8M CK106TB
692C102	SeJin SKR-1032B-GEA (EURO)	453E91	SIIG KB1941 (also BTC)
931C104	Sejin SKR-2033 w/windows FCC:GJJSKR-2033 (also Microspeed)	551G91	SIIG JK US0312-S1 Mini Multimedia
78D101	Sejin SKR-1033 FCC: GJJSKR-1032ZP4	753C101	Silitek SK3000R FCC:GYUR09SK (also Lteon)
16D86	Sejin SPR-8630 Mini "J" mouse GJJSPR-8630	861B70	Sisco Term inals (Brazil)
195D101	SeJin SKR1032BP FCC:GJJSKR1032BP	523E109	Skylink KB122
346D105	SeJin SK2233 w/win (Euro) FCC:GJJSKR2233	851B101	Smart And FRIendly386/40 (SEE HITEK FOR OTHER MODELS)
931C104	SeJin SK2233 w/win FCC:GJJSKR2233	1915B103	Smart EZ-8000
429D86	SeJin Mindpath SWK-8630 FCC:GJJSWK-8630 Wireless w/window s keys	516C101	Smith Corona 6311-KE(also Acer 6311-W)
432D101	SeJin SKM-1040 LEFT HANDED KEYBOARD FCC:GJJSKM-1040	938B101	SMK 101 (also Azuka)
618D101	Sejin EAT10 10P2 Fcc:GJEAT1 010BR (a lso Telme x)	182C111	Sodick 111 Key
643D89	Se Jin SPR-8697/W6 Wireless (Eu ro) (also W omb at)	229D105	Softkey GOGAPC-21 F-21-J
757D101	Sejin EAT1010 Fcc:GJJSKM-1030BS Back-L enter	756D105	Softkey F-21J (X) Fcc:GO GAPC-21 L-enter
926D104	Sejin 104DYW10-100 Fcc:J2S104DLY (also Linkworld)	792D109	Softkey F21XQ Fcc:GOGAPC-F-21
250E89	Sejin SW K-8650 WT, P/N SPR5096W T6A, win, trackball	915E105	Solidus Peripherals KWD701 (Euro), "7" enter
620E86	Sejin SWK-8650 W, SPR5096W S6A, Liberator II rec enter w with windo ws	356G89	Solidtek ASK3962 mini keyboard- touchpad rect enter
656E89	Sejin SWK-8695WT, trackball, windows, rec enter	176G88	Solidtek ASK3000H, ASK3001H
671E89	Sejin SWK-3000WT, Trackball cutout, Curve Spacebar	1961B108	Solidtek PSK-5000H
657E89	Sejin SWK-8695WS, rec enter, pointing button	446G79	Solidtek ASK3462-3410
771E104	Sejin SK-1788 rec enter, windows. (also Compaq)	454G77	Solidtek ASK3100SU/3152
968E86	Sejin SPR-8695U	248D104	Sony KB7923 FCC:E8HKB5923 (also Chicony)
985E89	Sejin SWK-8650W	16D86	Sony 8630 WEB-TV
987E89	Sejin SWK-3000US	206E86	Sony PC G-531A Laptop, Fcc:AK8JPN-35452-M5-E
256D101	SG-1000 FCC:KUG-SG-1000	391E107	Sony PCVA-KB1P/MA, PCVA KB1P/UB Multimedia, windows, rec enter
476D107	SG-1000 Fcc:KUG-SG-1000 (EURO)	390E108	Sony PCVA-KB1P/MA (Euro) multimedia, "7" enter win
446C77	Sharp PC-3000 Portable	654E108	Sony PCVA-KB4 P/U (Euro) "7" enter
83E63	Sharp (Handheld PC) Monilon Tripad PV-6000, Fcc: VADC HN-40029-FB-E	635E89	Sony Vaio PCG-9J4L, rec enter
792B105	Sherwood ANSI	744E108	Sony Vaio PCVA-KB4P/U rec enter
811B102	Sherwood EPC (102 Keys)	2004B104	Sony Vaio PCVA-KB7P/U
204C101	Sherwood EPC P/N KS-EPC-RD (also Sejin,leading edge)	15G116	Sony Vaio PCVA-KB9p/M P/N 14786221 (Euro)
887B103	Sherwood I-EPC	1934B083	Sony Vaio PCG-1B1L laptop
812B101	Sherwood ASC II	491G86	Sony Vaio VGN-SZ, SZ-120, SZ-220, SZ320, VGN Series - KEYS ONLY
667B97	Siemens PC 16/32(European)	492G82	Sony VPC-CW Series - KEYS ONLY
702B102	Siemens PC 32/20(European)	493G82	Sony Vaio CPG3C2L, VGNCS, PCG3xxx- KEYS ONLY
854B126	Siemens MTS 2000 (European)	494G107	Sony Vaio VGP-BKB1 Fcc: AQ6VGPBKB1 Bluetooth
855B123	Siemens Coros 2000 (European)	510G86	Sony Vaio PCG-F, PCGFX, PCG9xxx KEYS ONLY
985B127	Siemens 282D-K90-V320 (Euro)	572G103	Sony VPCF12AFM - keys only
968B126	Siemens 232D-K320-P320 (Euro)	288A76	Sorex 530
402E104	Siemens KBPC S EU, Fcc:SS01TASTK252, Rec enter	480A96	Soroc 550
61C126	Siemens-Nixdorf SINIX G80-2507HAD (European)(also Cherry)	850A106	Soroc Elite 550
381C119	Siemens-Nixdorf POS computer w/CC reader	768B106	Soroc Plus One (also Online)
985C102	Siemens Nixdorf MF2-LC S-26381-K252-V120 (EUROPEAN)	338B101	Spear Technologies EO 3435 (also Keytronics,AGI,D atama xx,Goldstar, Mitsubishi,Prem ier,Gateway)
110D105	Siemens-Nixdorf KBPC-P-NOR/S26381-K210-V145 w/windows keys (EUROPEAN)	617A84	Sperry PC
624D115	Siemens-Nixdorf POS (Euro)	405B101	Sperry 101 Enhanced
791D118	Siemens-Nixdorf POS W/ CC Reader CRTA5702	892A95	Sperry Univac
623E73	Sigmat ion III	945A113	Sperry UTS 400
742C102	SIIG KB-M102 model 1914 Fcc:J6GKTIC-KBM102 KB-1922, cooltouch kids, Fcc:J6G-KTIC-KB-M102	631A105	Sperry 1220/IPC
916C104	SIIG KB 1927 w/window keys (also Reveal,Chicony)	537A99	Sperry F4862 (also Keytronics)
283C81	SIIG Minitouch KB1903- FKD46AK110P (also Monterey, Sun)	518C101	SR-9151-B /JKB-6151-B FCC:FPWSR-9151B
22D105	SIIG Truetouch fo MAC FCC:KJXB205	313C101	SR-8151B FCC:FPWSR-8151B(also Kurt Check)
457C101	SIIG Supertouch FCC:FK3459SKB101K (also Suntouch)	03D101	SR-7151B rect enter FCC:J75SR-7151B
609C101	SIIG W avetouch 101KB JK0012 (also Acer)	73B101	Stone Systems (also Acer, Stone, Delta,Cannon,, NEC, Multitech) Texas Instrument,Data General)
910C105	SIIG SMK105Mac105KBGB JKML0011 FCC:KM9-3S6M9ASMK105	692B102	Stratus MC5 (also Link,Wyse,Alpha Micro)
921C100	SIIG Supertrak(+) model JKAPE012 FCC:GM8M CK106TB	232B84	Suntouch 84 Switch
922C110	SIIG Mactouch(+) model JK-MR-0012 FCC:SIIGSKB200MP	282C84	Suntouch JR.SIIG model K84JR FCC: GM8CK-84KBPAD
		283C81	Suntouch JR.SIIG model KB-MINI-81K FCC: 46AK110P(also Monterey,Mtek)
		457C101	Suntouch SIIG Model K101 FCC:FK3459SKb101K
		693D85	Suntouch MCK84 Fcc:GM8MCK84PAD (also Ortek)
		215B95	Sun Keyboard 95 Switch
		555B107	Sun 4
		337C118	Sun model type 5 N860-8701-T001-03A (also Fujitsu)
		370C119	Sun model type 5 N860-8701-T010-02A (also Fujitsu)

P/N	Description	P/N	Description
810C119	Sun Model type 5C N860-8703-T010 FCC:C9SKB8703 (also Fujitsu)	668B109	Televideo 965ASCII
911C118	Sun N860-8703-T001-03A	629B108	Televideo 965 ANS/MT220 9320(also Wyse)
953C102	Sun model EO3616US FCC:EO3713	994A101	Televideo KB200 FCC:AQ659ZRT-101A 115034 (also Hitek,Wells,Earthstation)
212D119	Sun Model type 5C,Class B FCC:C9SKB8703	630B102	Televideo 965 Enhanced PC
894D119	Sun Type 6 M/N N860-8705-T010-Q2A	142C110	Televideo 965 ASCII NEW
699E118	Sun Type 6, N860-8706-T401/10, rec enter	242D110	Televideo 110 Key
34G117	Sun Type 7, N860-8708-T010/020, 320136701	222D110	Televideo (Dec style) 110 key "7" enter
135C101	Sunshine KMB-101 FCC:FKD46AK208 (also Monterey)	308B122	Telex 19 1/1192 (also Memorex)
386C101	Sunshine FCC:ISNJ-168(also NTC)	907B88	Telex Cat 1191D
359D105	SuperMac ACK-310 w/win FCC:L2BACK310	504B122	Telex 179
648C102	Systemax SE9000 (also Dell) (EUROPEAN)	837A88	Telex 078/079/080/1191/4108
45E81	Systemax SW 14-500C Laptop, M/N N30W (also Dell)	343B88	Telex 88 Switch
152E121	Systemax KB-9885, Multimedia, Rec enter (also Chicony)	188B88	Telex FC 501
323E104	Systemax SEM-C19V2, Fcc:E2XSEM-C19V2, back L	792A84	Telex 84 Switch (also Maxiswitch)
788E104	Systemax Standard	579E64	Telxon #21987-000
119E07	3Com Palm Pilot III (also Palm)	555A88	Texas Instrument PC Professional
528E47	3Com #1102, P/N 655-0008-03	163A60	Texas Instrument 743 KSR Printer
278A92	Tab Products 92 Switch	441A84	Texas Instrument 820 KSR Printer
788A84	Tab Products 84 Switch (692-0132)	90A88	Texas Instrument 911
648B105	Taiwan Clone VT-105	669B55	Texas Instrument 700/1200 BPS Printer
636C80	Tanac Keyboard Computer	225A88	Texas Instrument 913
230B84	Tandata 410	754A103	Texas Instrument 924
61B101	Tandem 6526	144B105	Texas Instrument 928/also HP
841B107	Tandem 6528 (European)	398A103	Texas Instrument 931
633A106	Tandem 6530	190A105	Texas Instrument 940
70C106	Tandem TS-530(also Hitek.Adds)	283A108	Texas Instrument 5130
387C105	Tandem G80-1191 -HBU (also Cherry)	35B101	Texas Microsystems (also ALR, Easy Data, Maxiswitch, Everex, Gateway, Opus, Avtech)
367B101	Tandon RT-101A (also Hitek)	672B101	Texas Instrument 386/33 (also AST)
85B102	Tandon Enhanced 101	73B101	Texas Instrument 101A(also Acer, Nec, Multitech, Cannon, Stone System s, Data General, Delta Gold)
714B102	Tandon/Cherry G80-1251-SAD (European)	702C83	Texas Instrument Travelmate 4000E FCC:A9248625E
200C106	Tandon/Cherry G80-1207-HAD/04(Euro)	460D85	Texas Instrument Extensa 450T Fcc:HLZEXTENSA
*****	TANDY ALL MODELS SEE RADIO SHACK	658D86	Texas Instrument Travelmate 7100 Laptop(also Acer)
664D104	Tangent 6511-M Fcc:JVP6511M (also Acer)	514E17	Thales Artema P4432-052
258E107	Tangent 5126T, Fcc: EXKB5126TH0610 (also BTC)	534D113	Tip-Pro 5160 M2000 #16380
234B93	Tascom 93 Switch	88B82	Toshiba T-1000
651B107	Tatung 107 Keys	279C82	Toshiba T1000 XE/SE -1200XE
529B102	Tatung TCS 8120S (also Btc, KLH, Goldstar, Packard Bell, Mitsuma, Hewitt Rand)	550B81	Toshiba 1100(+)
438B101	Tatung FKB4700(also Data General, Dasher, Earthstation, Emerson, Sanyo, Vendex, Fujitsu)	838A82	Toshiba T-1200
684B102	TB 102G (European)	377C84	Toshiba T-1800 (Euro) ALL Euro 1800 & 1900 SERIES
932E94	TCW Q500 15" notebook	794C85	Toshiba T-2400 (EURO)
180G110	TCW MS163K laptop	859C85	Toshiba "SATELLYTE"(EURO)w/trackpoint
353G103	TCW MS163K Laptop-Rect enter	541C82	Toshiba T-1850/1900-200 FCC:CJ6UK190 U.S. ALL 1800 & 1900 SERIES
440G101	TCW SP15-UJA	928A81	Toshiba 3100-20
358B105	Tektronix 105 Switch	280C86	Toshiba T3100SX
231A102	Tektronix 4107/4109	549B85	Toshiba T-3200
824A86	Tektronix 4205/4207	533B92	Toshiba 5200 (European)T3200SX
354C101	Tektronix 101wn 63S-45E(also Dec, Honeywell)	453C91	Toshiba 5200/100
177C105	Tektronix VT-220 (also Liberty, Hitek)	378C102	Toshiba T-6400
505B114	Teledesk TD1600 HAC	974C85	Toshiba Satellite T2100/260 21XX/2100 2115/2130/2135/2150/2155/2130CS FCC:CJ6UK727
618D101	Telemex EAT1010P2 Fcc:GJEAT1010BR (also SeJin)	879C83	Toshiba T2400CS/250 w/trackpoint (US VERSION) FCC:CJ6UK273
605D87	Telepad Portable w/ Touchpad	81D83	Toshiba Tecra 700CT/CS
288B106	Teleray 200HP	82D83	Toshiba Protege 3400/3600/3600CT/610CT
195E105	Television GP101DB, Fcc:FBX5E9GP101, Rec enter	92D82	Toshiba T-4700CT/200 FCC:CJ6UK454
748B120	Telescan II	101D82	Toshiba 110CS/110CT/115CS/200CDS/205CDS/410 410CDS/415CS/420/425/430/435CDS/REC ENTER
499A88	Teletype Model 40	102D82	Toshiba 100/100CS/100CT/105/105CS/400/400CS 400CDT/405 RECT. ENTER
124A67	Teletype Model 43	393D85	Toshiba 220CDS/225CDS/305/310/315/320/325 445CDT/445CDX/465CDT/465CDX PA1240UVCD
164A80	Televideo 910/912	112D104	Toshiba Desktop 7130/7160/7200 Fcc:CIGE06100 Z (also Keytronics)
04B111	Televideo 970	233D85	Toshiba Tecra 500CS/500CDT/trackpoint
603A75	Televideo Personal Terminal	234D87	Toshiba Protege 300CT/650CT trackpoint
575A111	Televideo 905/955		
570A111	Televideo 921 (also AM PEX)		
538A125	Televideo 922		
86A101	Televideo 924/925/950		
751B110	Televideo 935		
87B113	Televideo 9220		
881A84	Televideo Telcat		

P/N	Description	P/N	Description
235D85	Toshiba 710/720/720CT/730 w/trackpoint	217C85	Ultra 386SX-20mhz Port.(also Chicony, Epson) Portable
287D104	Toshiba EO6150SU0002C FCC:CIGEO6100Z wristrest builtin (also Keytronics)	565C101	Ultra SK2000R FCC:GYUR10SK "L"shaped Enter (also Liteon,Elite,Hewitt Rand,Zenith)
557D87	Toshiba 520CDT/750CDT W/ Trackpoint	761C101	Ultra KB 5331 FCC:E8HKB-5311(also Chicony)
581D80	Toshiba Libretto 50CT/70CT/810	64D103	Ultra 103 FCC:BITS 6001
604D88	Toshiba 460CDX/2 Satellite Pro (Euro)	270D107	Ulysse 600 (Euro)port
614D87	Toshiba 530CDT	675D104	Unicom p 104DYW66-485 Fcc:J2S104DLY
648D84	Toshiba Libretto 100CT/2.1 (Euro)	318E107	Unicom p M-13 P/N UNI04G6 (also IBM)
670D87	Toshiba Tecra 8000 Port.	1802B104	Unicom p 104DYW69-53
709D87	Toshiba 330CDS/4000CDS/4010CT,4010CDT PA1273U-S2C	38G104	Unicom p Model M P/N UB40P4A, Rect enter
721D118	Toshiba KB9805 Multimedia (also Chicony)	88G104	Unicom p ACPOP46, M+5V - Rec enter
844D87	Toshiba Satellite 1555CDS, 2100CDS, 2590CDT, 2060CDS,4100XDVD,4030 Model# PAS206U-A With Trackpoint, Win Keys, Speakers, 2-buttons Over Trackpad	89G112	Unicom p UB404L6 - Trackball, rec enter
845D85	Toshiba Satellite 4030 Rec enter, win keys, speakers, trackpoint	633G105	Unicom p UB4ZPHA
16E90	Toshiba Tecra 8100, 2805, M/N PT810U, Rec enter	691B94	Unisys F4725-25 (VT1120)
34E89	Toshiba Satellite 1625CDT, PS162U-48986, Trackpoint	752B101	Unisys Postal Keyboard(US)
42E90	Toshiba Satellite 2210CDT,2250XCDS 4260,2670DVD PS221U-490J0, PS225U-M91J08	89B101	Unisys 101/E03443 (also Keytronics,Dec)
113E90	Toshiba Satellite 4320, 4310XCDT, M/N XS432P604L8B	241B110	Unisys B25 K-2
219E82	Toshiba 2800-S202, P/N PS280U-0013NB	258B113	Unisys T27 K-5
234E99	Toshiba 1800-S203, P/n PS181U00CFC2E, 302E90	151B105	Unisys F4862
302E90	Toshiba 1805	322B105	Unisys F5197-00
325E91	Toshiba #6000, trackpoint, rec enter	771B101	Unisys PW2
432E89	Toshiba Satellite 1200-S121, Glidepoint	579B105	Unisys TO300 (Euro)(also Link)
706E91	Toshiba Tecra Laptop with trackpoint and Glidepoint	137C98	Unisys B-21-512
379G104	Toshiba L350, L355 laptop, rect enter - keys only	801C112	Unisys B-39/B-28/K-5
381G86	Toshiba A300, A305, L300, M300 Laptop - keys only	132D105	Unisys PCK104-SKB (EURO) Fcc: E8HKB5323 (also Chicony)
472G87	Toshiba A, P, M, G Series Laptop - Keys Only	403B101	Unisys PCK-101-KBD KPQE99YC Fcc:EW4KPQ2479D
500G104	Toshiba L505, L505D - Keys Only	516D105	Unisys 105DYW76-596, KB6001, Fcc:J25104DLY (euro)
502G85	Toshiba Protege R500/R505/R600 - Keys Only	538D104	Unisys PCK104SKB Fcc: CMYKPQ7615/KPQE99ZC13 (Rect. Enter)
504G103	Toshiba Satellite PSC08U-02D010 Keys Only	584D105	Unisys PCK104-SKB (Euro) Fcc:CMYKPQE99ZC13
506G103	Toshiba P105-S6024 Keys Only	291E104	Unitech K2726, C/C reader, back-L enter (also Acekey)
548G107	Toshiba Satellite L350, L355 - keys only	517E105	Unitech K2724S/ACK720 (Euro) (also Acekey)
560G86	Toshiba M640 - keys only	571E102	Unitech KP3800, Fcc: KP3800T2PWE
601G101	Toshiba Satellite L655D, L650D - keys only	572E104	Unitech KP3700, Fcc: KP3700T2PWE
630G104	Toshiba A660 - keys only	725B101	Unitek K-158/258 (also Magnatronics)
378D105	Tranz 2000/Bilink N7 Portable	726B101	Unitek K-159 (also Magnatronics)
595D88	Trogon TG-8200 Laptop W/ touchpad, Win Keys	727B101	Unitek K-160/K-260 (also Digicom, Minta)
714D92	Trogon Model GREEN 735 Laptop	820A84	Unitek K-150 (DAH YANG)
849D89	Trogon Model GREEN 759 Laptop	951A101	Unitek K-156/256 (DAH YANG)
901D90	Trogon Model#MP993 W/ glidepoint	86C101	Unitek K-251 (DAH YANG)
957D90	Trogon Model B20KBD W/win, "7" enter	870B101	Unitek K-256(also Nantan,NTC)
981D89	Trogon No #'s Rec enter, glidepoint, win keys	43C102	Unitek K-261(EURO, S.A.)
381D105	Tulip SR9151B FCC:FPW9151B (Euro)	314C102	Unitek K-258 (Dah Yang)
XXXXXXXX	TURBO-JET see HQK	402C101	Unitek K-258CM FCC:FMAKB6551(Also NTC)
518E108	TurboKitty Keyboard	315C102	Unitek K-260/K-261 (U.S.)
338C105	Triad G80-3314-HAU(also Cherry)	791C101	Unitek K-270
618A105	Triad 101329(KB85) (also Wyse,Link)	268C80	Unitek UTA portable laptop
817D105	Triad P/N 900244-67 (also Wyse,Link)	789C85	Unitek ACK-500 Mini(also Acekey)
254C101	Trigem SKR-1032 (also Sejin, Radio Shack,AST)	790C101	Unitek ACK-200 FCC:H2UACEKEY002 (also Acekey)
811E125	True Basic TXT3500	791C101	Unitek FCC:L2BACEKEY700 (also Acekey)
887E117	True Basic TXT2700	114D101	Unitek K2724 w/credit card reader
780E117	Truebasic TXT-2500 (Euro)	08G119	Unotron Washable - WS5100K
781E108	Truebasic TXT-2200 (Euro)	256G104	Unotron S6000K
782E126	Truebasic TXT-2800 (Euro)	479G118	U are U by Digital Persona Fingerprint Board Model 50107-001
68E123	Truetouch P/N 154796, Multimedia, Hot Keys	802A101	US 101 (also Keytronics,AT&T,Samsung, Dell, Rita, Arnet)
69E126	Truetouch P/N 154758 Fcc:IZITK105M (also Professional)	229C101	US 101 DS-1000 FCC:H77DS101-3000MS
447B102	Tulip ATK030249 (European)	970C104	US Logic SK110CW GYUR26SK (also LITE-ON)
995D104	Tulip 9151B, Fcc:FPW9151B-68W, P/N 11-500001-00	160B84	Vendex Headstart (also Hitek)
442B101	TwinHead 101KB6251(also BSC, Magitronics Zeos, Nan Tan, NTC, Premier, Dataware, Wang)	438B101	Vendex Headstart XT FKB4700 (also Data Gen, Dasher, Fujitsu, Earthstation, Emerson, Sanyo, Tatung)
592D88	Twinhead Slimnote 8 MCT-2000 Laptop	285G122	Verbatim KG0570
789D109	Twinpath KB9000(E) Fcc:LFCACEKEY1 (also Acekey)	107C79	Veridata Turbolite 110 Port.(Euro)
191D118	Type 5 ModelS5-100 FCC:K6XS500	458C80	Veridata Execulite 386S/25e
49E111	Ultimate Technology M531	573D81	Versapoint Wireless VP6200 W/Glidepoint
55E120	Ultimate Technology M630	330G120	Versapoint VP6510 Fcc: IBA-WCUTOD-KB
626E69	Ultimate Technology M531, p/n CO9285	419G91	Versapoint VP6210
		512B102	Versys 102 Key(3 Lights)
		774B101	Versys RT-101+ (also Ast,Hitek)

P/N	Description	P/N	Description
256B102	Victor 102	841A102	Wyse 60 PC 286/386 Enh (3 lights) model #840358-1 (also Am dek, A rnet) (raised above Function Keys)(3 raised LEDES) J6GKTIC-KB-M102
471B102	Victor/102 Microswitch (European)	692B102	Wyse 60/900840-1(also Link,Alpha Micro) (Flat Above Function Keys)(3 raised LEDES) #840358-30, 50-120-000-102,900866-01
242B113	Videcom 113 Switch	657C103	Wyse 60 (EURO) Flat above "F" keys
337B122	Videcom 122 Switch	618A105	Wyse 85 840366-1 (also Link,Triad)
843E117	Viewsonic KU206 VSACC27936-1M	579B105	Wyse 185
742B106	Visa 33 (European)	527C108	Wyse 285 ANSI 901028-01
202B108	Visentech System 230	572A83	Wyse 1100
919B113	Visentech System T227	348D101	Wyse 901857-01, 901867-01, ASCII,909073-01
427G119	Visikey 110-EVIK	368D104	Wyse Win term FCC:CIGEO 6100Z (also Keytron ics)
577G120	Visikey Large Print keyboard	160D104	Wyse 901861-26, Win term,KB8923 (also IBM)
706B63	Viskase 63 Key	353D102	Wyse 901865-99 EPC
952A80	Visual60	817D105	Wyse P/N 900244-67 (also Link Triad)
946A106	Visual241	285E101	Wyse ASCII, 598-0011717, rec e nter (also Ad ds)
94C95	Visual383	329E104	Wyse KU-8933, 901716 (also Microsoft)
136C108	Visual 108 Switch	505E104	Wyse 7932M, rec enter, (also BTC)
137A94	Volker Craig 94 Switch	889E105	Wyse KU8933 p/n 901715-34 "7" enter
619C114	VS-211KB	957E105	Wyse KB2971 (Euro) 770407-05
408G103	VT model KCOB1	106G88	Wyse X90 laptop p/n 909520-31L Fcc:ncivnt6656gevox
841D88	V-Tech Equalizer Laptbp W/ Mouse	132G87	Wyse X900L p/n 909521-41L, XPE, MTC
842D84	V-Tech Wizard 2.0	111A76	Xerox 820-6060 Series
349G112	Vuescape 6100-100, K5520 - rec enter	964E93	Xslim minikeyboard KL-5UP
169B104	Wang PC 280	930C85	Xtrapro portable
155B105	Wang 2110/2110A	651A95	Zenith 100/120
90B101	Wang 4230/4230A	454A84	Zenith 148/150/151/152/248
839A101	Wang PC/4250/Professional	290B101	Zenith 101 Enhanced
156B109	Wang 724-3770 PC200/300/724	189B78	Zenith Supersport PC/184
225B105	Wang 723 PC200/300/723	594B79	Zenith Supersport 286
626B104	Wang 720(725-8073)	284C80	Zenith Minisport ZL2
478B106	Wang 4205 VS-I (European)	281C81	Zenith Mastersport 386SX
10B101	Wang 310/7257660	403C82	Zenith Mastersport 386SL-60 modelZWL-320-06 Fcc: IFO STINGRAY
117C101	Wang 725-7943 (see#725-6927) GS23TYCSK1101S	565C101	Zenith SK2000RE FCC:GYUR10SK "L"Shaped Enter (also Liteon,Ultra,Elite,Hewitt Rand)
442B101	Wang MEC-101S (also NTC,Dataware BSC,NanTan Twinhead,Premier,M agitronics)	356C82	Zenith Z note Portable 325LC PS235
598E88	Wasp Technologies WKB-1000, winsows, C/C Reader	835C85	Zenith Z-note FLEX NT B005 FCC:IFO-NT0005 M/N UBC-0043-00
940C101	Wave N860-8720-T301(also Fujitsu)	601A63	Zenith 171
252B84	Wedge Microstation II	383C101	Zenith IB-10 FCC:GJK-101WN-5(also Honeywell)
994A101	Wells American RT(also Earthstation,Hitek, Televideo)	411C101	Zenith ZKB-3 101RX43 S-72e FCC:GJK101RX-5
04E101	Westrex International KBW2400, "L" enter	561C102	Zenith 102W N63S-7 EN(EURO) (also Honeywell) Fcc:GJK101WN5
349E108	Win98 keyboard (also Linkworld), rounded keys,	986C101	Zenith KB-5323 FCC:E H8KB5323 (also Chicony)
508D104	Winbest Turbojet KB8801R+ (also HQK)	833C85	Zenith Z-Star noteb ook 433VLP (also Pack Bell)
856C85	Winbook XP Portable w/trackball	151D102	Zenith KB5323 w/windows (EURO)(also Chicony)
857C85	Winbook XP portable w/trackpoint & touchpad	325C84	Zentec ADM11 full keys(also Lear Siegler)
788D89	Winbook XL W/ Win keys, Glidepoint	733A103	Zentec Series 1000
150E118	Wincor Nixdorf /Siemens POS C ompu ter w/Flat keys	162B107	Zentec ADM 12(+)
123G125	Wincor Nixdorf SPOS G86-61401 EUADSA	52B86	Zentec Technicon T2201
245D88	Wintek ACK-595 (also Acekey)	51B88	Zentec Technicon 4201
886E90	Wireless Computing RF220 compact keyboard Fcc:L7MR220	263B108	Zentec 8392
885E107	Wireless Computing RF250 Fcc: L7MR250	38C82	Zeos N otebook Portable (also Everex)
410G104	Wireless Computing RF240	749E90	Zippy WK-620
590B125	Wisconsin Bell Keyboard	768E104	Zippy WK-720
643D89	Wombat SPR8697/W6 Wireless (Euro) (also SeJin)	405G120	Zippy WK725
656D139	Wombat SKI1292 (also Keysource)	478G107	ZK-520
657D159	Wombat SKI1290A (also Keysource)	517C95	Zorba Telecon Keyboard
804D103	Wombat Wizard SKR1196WT6A/KSI 2196	872E58	Zygo Polyana Laptop
805D160	Wombat KSI1290 W/ CC Reader		
573E160	Wombat KSI1290-A (also Keysource Int'l.)		
501E86	Wombat Wireless FDC3402, rec enter (also Microslate)		
896E159	Wombat KSY1390NBC		
74G85	The Writer by Advanced Keyboard Technobgies		
119G85	The WriterFusion by Advanced Keyboard Technologies		
565A83	Wyse 30 840013-01, 900023-08		
385A101	Wyse 50/75/350/840059 (also Altos, Radio Shack)		
179D102	Wyse 55 #841135-01		
391B103	Wyse 60 (103 Switch Euro)840362-01 (Raised above function keys)		
840A101	Wyse 60/160 ASCII/ANS I/150(also Altos) #840338-01		
727A84	Wyse 60AT		

P/N	Description	P/N	Description
-----	-------------	-----	-------------

Mouse Seels

411G03	AOPEN KM826 MOUSE
650D02	AST M-34 FCC:DZL210472 (ALSO LOGITECH)
50G03	ATIVA OPTICAL GS600, 789-104
10G03	BELKIN F8E32MSE
13G03	BELKIN F8E815MSE
14G03	BELKIN F8E500PT
181E03	COMPAQ M/N M-S48A FCC:JNZ201213
724E03	DELL M-S69 FCC:JNZ211499 (ALSO LOGITECH)
80G03	DELL M-S89 FCC:INZ211443
55G05	DYNEX DX-WOM2
52G03	FELLOWES 98921
77G07	GYRATION AIR MOUSE GC15M
732D02	HEWLETT PACKARD C3751B, FCC:DZL211029
412C01	HONEYWELL 2HW53-4E
288G03	INLAND MOUSE 70120
51G06	IO GEAR 1600DPI GME521
280G03	IO GEAR GKM551R
54G04	KENSINGTON 72121
258G01	KENSINGTON SLIMBLADE K72279US
79G03	LABTEC MEDIA WIRELESS M-RBB107
724E03	LOGITECH M-S69 FCC: JNZMRR67A (ALSO DELL)
779E01	LOGITECH TRACKMAN WHEEL T-BB18, 804360-1000
975E02	LOGITECH M-RBA97
53G07	LOGITECH V X REVOLUTION 631628-0403, FCC:DZL202251
59G03	LOGITECH RX300, 832343-001
57G05	LOGITECH LX710, LX310
650D02	LOGITECH M-S34, FCC:DZL210472
735E03	LOGITECH M-S69
56G06	LOGITECH MX3200
68G03	LOGITECH S510
317G03	LOGITECH M-R00006
322G03	LOGITECH M-RCE95
361G06	LOGITECH MK700
469G03	LOGITECH LX5 SCROLL MOUSE
317G03	LOGITECH MK300
629G03	LOGITECH MK320
995E03	MICRO INNOVATIONS PD435P WHEEL MOUSE
824E01	MICROSOFT OPTICAL 2.0, 1034, FCC:2003DT1034
941E03	MICROSOFT BASIC OPTICAL 1.0 800898
998E02	MICROSOFT 6000, 1052, X0803468-06
994E01	MICROSOFT OPTICAL 2000, X802382-002, X806939
58G04	MICROSOFT OPTICAL 4000, 1050, 1051
646C02	MICROSOFT 28898, C3K5K5COMB
645C02	MICROSOFT 52695, C3KMMP3
335G05	MICROSOFT WIRELESS LASER 8000
385G03	MICROSOFT OPTICAL 700 V2-1133
404G01	MICROSOFT 5000 MOUSE
432G03	MICROSOFT 8000 MOUSE
488G03	MICROSOFT X800496-104
625G03	MICROSOFT 800
970B03	MOUSE SYSTEMS
950C03	SUN TYPE 5, 370-1398-03, CWE403356
286G03	VERBATIM KG0570
331G03	VERSAPOINT VP6510
297G03	WYSE MO42KON

P/N Description

P/N Description

TELEPHONE MODELS

347G39 AASTRA 6757i	191G25 AVAYA 1603
348G31 AASTRA 6731i	412G36 AVAYA 56 10, 56 10SW IP
211G36 AASTRA 91331 - NO DISPLAY	521G39 AVAYA 1405, 700469851
236G37 AASTRA 480i (also Vertical)	562G42 AVAYA 1408
428G45 AASTRA DIALOG 4225	569G50 AVAYA 1616, 700458540
456G36 ADTRAN IP706, 1Z00769E1#B	***** AVAYA PHONES SEE AT&T****
457G43 ADTRAN IP712, 1Z00770E1#B	260B22 AZUKI STC 10 PRO-616
343D29 AID V-Band AID-4	272E30 BOSCH #10-7101-0006
225G42 ALLWORX 9212	273E31 BOSCH #10-9101-0008
718D27 AMERIPHONE VCO	410E32 CISCO SYSTEMS IP PHONE 7960
717D30 AMERIPHONE XL-30	521E20 CISCO SYSTEMS 7905, 7911 SERIES
717D30 AMERIPHONE DIALOGUE XL30	866E26 CISCO SYSTEMS IP 7910
718D27 AMERIPHONE DIALOGUE VCO	02G28 CISCO 7941, IP7900, IP7942
852E03 AMERIPHONE HA-40 HANDSET AMPLIFIER	352G30 CISCO CP6921
654D36 ASPECT 3190	541G37 CISCO 7965IP
646B13 AT&T STANDARD DESK W/RECALL	542G33 CISCO 7945IP
239B20 AT&T MODEI 3130	612G32 CISCO SPA508G
998B39 AT&T 9010D MLX-10/1SDN 8510T	41B13 COMDIAL EXECUTECH II
418D39 AT&T 9010D MLX-10 LASER	631B36 COMDIAL 6600S-PG 6414/6614
47C34 AT&T COMKEY 416/2981-A02- 50AT/ 2981A01-50AT	08B40 COMDIAL 8 LINE PHONE
784A12 AT&T MERLIN	463B19 COMDIAL 3528(18/KEYS)2564/2565
275B30 AT&T MERLIN HFAI-10	453B41 COMDIAL 6414L-AB/6614
804B12 AT&T MERLIN 3270	65C42 COMDIAL 6620
60C54 AT&T MLS 34D	66C32 COMDIAL 6714X/6702X/6706X
318C57 AT&T MLX-28D	146C46 COMDIAL DIGITECH 77005-PG
807B25 AT&T PARTNER MLS-6	826B15 COMDIAL EXECUTECH 2000#6701XPG
806B38 AT&T PARTNER MLS-12	147C32 COMDIAL EXECUTECH 6714X-PG
805B38 AT&T PARTNER MLS-12D/MLS18D	471C43 COMDIAL 77 14-X
569B28 AT&T SPIRIT (6 button set/entire)	549C28 COMDIAL 8112N-PT
239B28 AT&T SPIRIT (6 button set/keypad)	682C36 COMDIAL IMPACT 8012S-PT
972A46 AT&T SPIRIT (24 button set)	660C33 COMDIAL IMPACT 8112S-GT
901C12 AT&T 7406	871C48 COMDIAL IMPACT 8024S-GT
815C29 AT&T 8102	736D36 COMDIAL IMPACT 8312S-PT 12 LINE
816C13 AT&T 8101M	737D51 COMDIAL IMPACT 8324S-PT 24 LINE
817C15 AT&T 8101	738D32 COMDIAL IMPACT 8312N-PT 12 LINE
818C32 AT&T 8110	739D20 COMDIAL IMPACT 8201N-PT
819C 12 AT&T 2500MMGL BASIC	839C41 COMDIAL UNISYN 1122S-FB
820C16 AT&T 2500YMGL FEATURE	858C44 COMDIAL UNISYN 1022S-PT
747C12 AT&T 2554 (CMC SET)	32D16 COMDIAL 8101N-GT
975C26 AT&T(LUCENT)7311H12 PARTNER ENDEAVOR 6 SERIES 1	858C44 COMDIAL IMPRESSION 2022S
978C38 AT&T(LUCENT) 7311H13 3158/05- PARTNER 18 SERIES 1	67E32 COMDIAL IMPACT 8212N-FB
977C42 AT&T (LUCENT) 7311H14 3158/07-PARTNER 18D	198E53 COMDIAL DET-7260/DX80
979C58 AT&T 7515H04 34button	03G54 COMDIAL7261-00
976C48 AT&T ADJUNCT 605B	82G48 COMDIAL VERTICAL EP100G-24, EDGE 100,VWE100-24
194D60 AT&T EXPANSION MODULE DSS	144G44 COM TEL DP5032-SD (also Toshiba)
193D55 AT&T MLX-20L	145G34 COM TEL DP5022-SDM (ALS O Toshiba)
525D39 AT&T 8410	269C34 CONTEL/EXECUTONE 2992501
790D23 AT&T 906	492D31 CORTELCO 219375-MOE
838D52 AT&T (LUCENT) 4424+	04D30 CORTELCO 911800-MOE / E103449 ALSO PREMIER
871D26 AT&T (LUCENT) 4406	846D25 CORTELCO 501200-750-100
170E45 AT&T (LUCENT) MLX-16DP	90E18 CORTELCO 530600-750-001
185E15 AT&T (LUCENT) Merlin Magix #4400	91E44 CORTELCO EXECUTIVE MODEL #532800-750-001 SCREEN DISPLAY
422E51 AT&T (LUCENT) 6424 DTM	92E28 CORTELCO 531600-750-001
290E41 AT&T 952	995C37 DASH OPS-5
288E43 AT&T 7035	397E30 DIGITAL INPUT STATION DA113 DICTAPHONE EMUL
270E14 AT&T (LUCENT) 2554MMGN	191B25 DIGITEL OSU-60
937E35 AT&T (LUCENT) 6408D	248E49 EPIC/TMC ET4000
115D48 ATLAS 32	205C33 ERICKSON DIALOG 2531
596E19 AVAYA MODEL 6402D	323G28 ERICKSON DIALOG 4222
910E58 AVAYA 3B-58 KEY / 34D SERIES II	369D41 ESI/ESTECH 1VX
911E42 AVAYA 3B-42 KEY, partner 18B, 700340193, 700340219 SERIES II	508E36 ESI MODEL IVX24
912E26 AVAYA MODEL 22B, partner 6b, 700340169, 700340185 SERIES II	700E59 ESI 48KEY IPFP
991E36 Avaya Imagineering PH051	732E43 ESI model ESIDP1
838D52 Avaya 4412	734E26 ESI 12key DIP
187G58 AVAYA 34D/34D EURO	146B18 EXECUTONE 6K 40055
	462A26 EXECUTONE 14K 40060
	147B29 EXECUTONE 17K 40056
	269C34 EXECUTONE 22K 2992501
	452A38 EXECUTONE 26K 40050
	148B40 EXECUTONE 28K 40057

P/N	Description	P/N	Description
141C41	EXECUTONE 29K 40058	132B41	ITT AIRES EKS-401
654C26	EXECUTONE MODEL 12 84300-2	995B19	ITT CORTELCO EKS802D
655C30	EXECUTONE MODEL 18/32 84700-2	952C38	ITT CORTELCO EKS-1664
712C01	EXECUTONE MODEL 32 "DISPLAY ONLY"	915B32	ITT MLVS-20
715C35	EXECUTONE MODEL 64	588C14	ITT WALL PHONE W/FLASH BUTTON
26D20	EXECUTONE 8 BUTTON #2992509	747C12	ITT WALL PHONE
716C01	EXECUTONE MODEL 64 "DISPLAY ONLY"	329D70	IWATSU/OMEGA DIRECT STATION UNIT A-2 IX-DSS-A-2
718C45	EXECUTONE/CONTEL ECX-33 P/N2992503	330D28	IWATSU VERAPHONE IX-VT
713C37	EXECUTONE "AGENT" PHONE	331D16	IWATSU BUSY-BYPASS/AUTODIAL IX-BPAD-2
714C01	EXECUTONE "AGENT" "DISPLAY ONLY"	332D51	IWATSU 12 BUTTON DISPLAY (51 KEYS TOTAL) IX-12KTD-2
945C20	EXECUTONE ENCORE CX-8 2992509	333D39	IWATSU 12 BUTTON DISPLAY (39 KEYS TOTAL) IX-12KTD-2
376D14	EXECUTONE RING INTERCOM	254E52	IWATSU OMEGA IX-12KTS-3
265B20	EXTRON HMS-6)	255E40	IWATSU OMEGA IX-12EIK-3
195B01	"FONE CAP" TELEPHONE MOUTHPIECE	256E70	IWATSU OMEGA DIRECT STATION SIGNAL IX-DSS-3
67D35	FUJITSU F-10B-0816-B001	266E55	IWATSU OMEGA 1000 CONSOLE (2X PRICE)
223D45	FUJITSU 9600 CONSOLE	933E37	IWATSU 18I/18D 107899-18
468D34	FUJITSU CT10/CT20	934E28	IWATSU 12I/12D 107899-12
43B22	GAITRONIC SCOPE SYSTEM	174B42	KANDA 42 SWITCH
49B30	GAITRONIC SCOPE SYSTEM	*****	LUCENT PHONES SEE AT&T****
372G32	GEEMARC CL300FCC -LARGE KEY PHONE WITH MOVABLE SCREEN	68C45	MACROTEL EXCEL 816BKS
372G04	GEEMARC CL300FCC SCREEN COVER	902B45	MACROTEL MT 16H
154B43	GST AMERICAN	*****	MERIDAN ALSO SEE NORTEL ****
323C46	GTE FUJITSU CONSOLE F04B-6027	173B24	MERIDAN M7208 (NORSTAR /w/spker)
570C00	GTE FUJITSU ADD-ON CONSOLE	373B24	MERIDAN M7208 (NORSTAR /w/o spker)
300A25	GTE MICROFONE II	372B42	MERIDAN M7310 (NORSTAR)
971C43	HARRIS OPTIC 1 #780830	614C31	MERIDAN M2616 W/DISPLAY NTZK16BA35
149D20	INFINITE INI-411-51	624C43	MERIDAN NORSTAR M7324 EXPANDEDNT8B40AA03-02-A00V
700B25	INTERCOM ITE 12(+)	242C21	MERIDIAN M2006
341E50	INTERPHONE/DSG IP900	625C01	MERIDAN NORSTAR ADD ON MODULE 48 BUTTON
795A40	INTER-TEL SPK II	879B17	MERIDAN/NORSTAR Model M7100 NT8B14
673C24	INTER-TEL GLX STANDARD 612.3201	318D24	MERIDAN M5009
895C42	INTER-TEL GLX EXECUTIVE 612.3301	936B65	MERIDAN/NORTHERN TELECOM M1250/M2250 CONSOLE (2X'S PRICE)
851C44	INTER-TEL GLX PLUS W/O LCD 612.4300/612.4200	105D32	MERIDAN/NORTHERN TELECOM M2317 ASH
717C36	INTER-TEL/AXXESS STANDARD 550.4000	128D24	MERIDAN/NORTHERN TELECOMM7208 (FU 3SIDES)
717C36	INTER-TEL/AXXESS DISPLAY 550.4300	288C23	MERIDAN/NORTHERN TELECOM M2008
855C50	INTER-TEL/AXXESS EXECUTIVE 550.4100	434D27	MERIDAN/NORTHERN TELECOM 5112 NT4X31
897C60	INTER-TEL/AXXESS DSS STATION 550.4200	506D43	MERIDAN M7310 FULL PHONE FLAP UNDER
845C36	INTER-TEL 8 LINE IMX AIM 660.7400 (22 BTN)	779D20	MERIDAN/NORSTAR 20 KEYS
846C34	INTER-TEL 8 LINE IMX STD 660.7500 (22 BTN)	780D48	MERIDAN/NORSTAR NTA804AA-93 EXPANSION MODULE
847C52	INTER-TEL 12 LINE IMX 660.7900/660.7800 (40 BUTTON)	781D24	MERIDAN/NORSTAR 8N/NTA801BA-93
848C54	INTER-TEL 12 LINE IMX AIM 660.7200 (40 BUTTON)	782D17	MERIDAN/NORSTAR M7100N NTA800BA-93
849C66	INTER-TEL 24 LINE IMX AIM 660.7000 (52 BUTTON)	783D43	MERIDAN/NORSTAR M7324N NTA803BA-93
850C64	INTER-TEL 24 LINE IMX 660.7700/660.7600 (52 BUTTON)	784D42	MERIDAN/NORSTAR M7310N NTA802AA-93
852C44	INTER-TEL 8 LINE DVK 662.3501/662.3601	115E27	MERIDAN/NORSTAR T7208
853C48	INTER-TEL 12 LINE DVK 662.3901/662.4001	116E18	MERIDAN/NORSTAR T7100
854C66	INTER-TEL 24 LINE DVK 662.3401/662.3801	117E46	MERIDAN/NORSTAR T7316
896C60	INTER-TEL DVK DSS STATION 662.3700	809E47	MERIDIAN T7316E
133D32	INTER-TEL AXXENT KTS BASIC 520.4000	203B44	MICROTEL (44 KEYS)
218D18	INTER-TEL SLT3 900.0200	*****	MITEL CONSOLES ARE 2 TIMES THE PRICE*****
272D44	INTER-TEL EXEC-DIGITAL 550.4500A	44B13	MITEL SUPERSWITCH
273D36	INTER-TEL STANDARD DIGITAL 550.4400	162D37	MITEL SUPERSET 420
564D21	INTER-TEL MARQUIS 2700 MW5 #651391	163D28	MITEL SUPERSET 410
207E39	INTER-TEL ENCORE	164D23	MITEL SUPERSET 401+
275E31	INTER-TEL ECLIPSE 560-4100 BASIC	981A42	MITEL CONSOLE PABX#9 110-107-000(42 KEYS)(2X)
276E60	INTER-TEL ECLIPSE CONSOLE 560-4000 (2X PRICE)	374D42	MITEL CONSOLE 5X50 (2X PRICE)
277E43	INTER-TEL ECLIPSE 560-4200 ASSOC.	808B44	MITEL SX-2000 CONSOLE (2X)
278E51	INTER-TEL ECLIPSE 560-4300 PROFESS.	227D119	MITEL MU 190 CONSOLE(2X)
479E38	INTER-TEL AXXESS 8520	107E39	MITEL SUPERSET 4025 FCC:BN2CAN -25148KXT
483E54	INTER-TEL AXXESS 8520 W/MINIDSS	468E27	MITEL SUPERSET 4015
482E46	INTER-TEL AXXESS 8560	469E32	MITEL SUPERSET 4150
480E62	INTER-TEL AXXESS 8560 W/MINIDSS	958C44	MITEL SUPERCONSOLE 1000(2X)
481E36	INTER-TEL AXXESS 8500	959C38	MITEL SUPERSET 4
799E46	INTER-TEL ECX2000 ENCORE CX		
800E38	INTER-TEL ECX1000 ENCORE CX		
801E27	INTER-TEL ECX1000		
423A22	ITT 2830		

P/N	Description	P/N	Description
107E39	MITEL SUPERSET 4025	608D28	NITSUKO 60080B DM32
979E18	MITEL 5201	806D52	NITSUKO 92753 DX2NA-12CTXH
63G33	MITEL 5550IP CONSOLE P/N 5000164 4 (2X)	53E54	NITSUKO 92760 DX2NA-18CTUH PART#66200599
181G34	MITEL 5212	54E48	NITSUKO 92750 DX2NA-12CTH PART#66204399
247G47	MITEL 5340IP	76E58	NITSUKO 92763 DX2NA-18C TUXH
248G35	MITEL 5330	115E27	NORTEL T7208
433G44	MITEL 5540 CONSOLE (2X)	116E18	NORTEL T7100
575G22	MITEL 5304IP	117E46	NORTEL T7316
627G46	MITEL 8568IP	809E47	NORTEL T7316E
814C14	MOTOROLA PAGECOM/SITEMATE #E24WRE0011AN ***** NEC ALL DTU & DTP ARE THE SAME	344E24	NORTEL M5008
641A38	NEC ELECTRA 100	832E40	NORTEL M3904
395C28	NEC ELECTRA ETW-8-1	807E35	NORTEL M3903 33AB6
394C58	NEC ELECTRA ETW-16-DD-1	836E29	NORTEL M3902
994C57	NEC ETT-16-1	837E18	NORTEL M3901
528D59	NEC DTERM SERIES E DTP-32D-1, DTU-32D	873E32	NORTEL M2616 W/ DISPLAY NTZK16BA93
33D38	NEC ETW -16-DC-1	820E24	NORTEL COMPANION PHONE
239D30	NEC D TERM SERIES III ETJ-8-2	636G39	NORTEL 1140E *****NORTHERN TELECOM ALSO SEE NORTEL
312D13	NEC ETT-1-2	164C41	NORTHERN TELECOM NT1K00AD
66D45	NEC SN619 Console(2X price)	115C12	NORTHERN TELECOM UNITY I NT0C22
478D37	NEC DTU-16D-1 770030	171C15	NORTHERN TELECOM UNITY II NT0C22AP-35
479D29	NEC DTU-8-1 DTU-8-2 770010	822B23	NORTHERN TELECOM UNITY NT4L01AHR6
480D85	NEC D-TERM SERIESII ETE-6D-2	823B31	NORTHERN TELECOM UNITY NT445AC35
481D25	NEC D-TERM SERIESII ETE-6-2	242C21	NORTHERN TELECOM M2006 BASIC NTZK06AA35
482D55	NEC D-TERM SERIESII ETE-16D-2	920C15	NORTHERN TELECOM M8003 NT2N26AA111
633D53	NEC D-TERM DTU-32-1	06D12	NORTHERN TELECOM M8001
634D37	NEC ELECTRO ELITE DTU -16-1	288C23	NORTHERN TELECOM NTZK08AA93
635D43	NEC D-TERM DTP-16D-1/2	200D25	NORTHERN TELECOM QSU-60 SL-1
636D35	NEC D-TERM DTP-8D-1	205D35	NORTHERN TELECOM M8417 2 LINE
59E23	NEC D-TERM DTP-2DT-1	206D32	NORTHERN TELECOM M8417 1 LINE
123E14	NEC DTP-1-2 #770082	207D34	NORTHERN TELECOM M8417 1 LINE W/VMAIL
59E23	NEC D-TERM SERIES E DTP-2DT-1 STOCK #770075	213D24	NORTHERN TELECOM M8009 NT2N24AD2141
123E14	NEC DTP-1-2 STOCK#770082	625C01	NORTHERN TELECOM KEY MODULE NT8B41FA35
227E52	NEC/NITSUKO 80573, 80570 BDS22-BTN, DS1000, DS2000	902D48	NORTHERN TELECOM 48 KEY ADD-ON MODULE
484E63	NEC D TR-32-D-1/DTH-32D-1	969D17	NORTHERN TELECOM M7100 NT8B14AB-03
485E60	NEC DCR-60-1	574B24	NORTHWESTERN BELL INTEGRA 75001
486E47	NEC D TR-16LD -1/DTH-16LD-1	602B43	NORTHWESTERN BELL INTEGRA 75005
487E47	NEC D TR-16D-1/DTH-16D-1/JTR-16D-2	983A26	OMEGA IV
488E39	NEC D TR-8D-1/DTH-8D-1/JTR -8D-2	29B40	OMEGA EXECUTECH
489E27	NEC D TR-1-HM-1	515C46	OMEGA-PHONE by ATCOM ZS-6KTD-SP
490E25	NEC D TR-2DT-1	199E46	OMEGA ZT-D #ZT-24KTX-SP
491E17	NEC D TR-1-1	53B35	PANASONIC EASA-PHONE
492E33	NEC D TR-8-1/DTH-8-1	249B49	PANASONIC EASA-PHONE
633E53	NEC 1P1NA-12THX890043-22, 22B LCD	139C35	PANASONIC EASA-PHONE KXT2365
679E47	NEC 1P1NA-12TH-22B ASPIRE PHONE	602B39	PANASONIC EASA-PHONE KXT3155
681E65	NEC 1PNA-24THX890045	499C38	PANASONIC KXT-3185
689E52	NEC CONSOLE SN716-201285 (2X'S PRICE)	130C40	PANASONIC KXT7020
766E25	NEC ASPIRE 2bt 1P1NA-DSL-TEL	206C38	PANASONIC KXT 7050
969E47	NEC DTH-16D-2	85D27	PANASONIC HYBRID SYS. KX-T-7055
970E39	NEC DTH-8D	245C44	PANASONIC VB-43220
42G52	NEC DSX22B DISPLAY PHONE	679B56	PANASONIC 43233/43231
163G42	NEC UX5000-12BTN 1P3NA-12TXH	678B38	PANASONIC 42210/43210
164G54	NEC UX5000-24BTN 1P3NA-24TXH	829C50	PANASONIC KXT-7130
268G37	NEC DT300-DLE-6D	748C49	PANASONIC KXT-7220
269G40	NEC DT300 DTL-12D-1	809C54	PANASONIC KXT-7230
637G52	NEC DT300 DTL -24D-1	184D37	PANASONIC VB-44210
638G27	NEC DT300 DTL -2E-1	217D47	PANASONIC DBS VB-44223-6/44220
522G33	NEC DTERM ITR-4D-3, 780019	265D47	PANASONIC VB-44225 W/LARGE DISPLAY
227E52	NITSUKO/NEC 80573 BDS 22-BTN	386D27	PANASONIC KXT-7250
576C38	NITSUKO AMERICA 88660 BC-DC NHF	413D43	PANASONIC VB-44220-G
948C38	NITSUKO AMERICA 88660 BC-DS NHF	609D24	PANASONIC VB-43310
949C38	NITSUKO AMERICA 88673 DS01 MF/DSP	740D54	PANASONIC KXT- 7433-B
154D16	NITSUKO AMERICA 88350 DGTL-S/L	754D28	PANASONIC KXT-2315 EASA-PHONE
138C46	NITSUKO AMERICA 88360 (also TIE)	801D50	PANASONIC KXT-7425-B
323D48	NITSUKO AMERICA PORTRAIT 824 W/DISPLAY PART # 82473-22 BUTTON	802D38	PANASONIC KXT-7420-B
324D40	NITSUKO AMERICA PORTRAIT 824 NO/DISPLAY PART #82460-6 BUTTON	818D40	PANASONIC KXT-7431B
522D16	NITSUKO AMERICA 92550 66VU4596	831D26	PANASONIC KXT -2310
523D50	NITSUKO AMERICA 92570 66VU3995	944D48	PANASONIC KXT-3280
555D52	NITSUKO AMERICA 92573 DX2NA-16BTXH		

P/N	Description	P/N	Description
289E24	PANASONIC KX-TSC12W	131B13	STANDARD DESK PH TOTAL SEEL DRAPES OVERSIDES
311E33	PANASONIC (ADVANCED ITS)XTS108W / KXTS105W	218B16	STARTEL #18-1117-003 (16 KEYS)
382E37	PANASONIC VB-44210A-B	449A13	STROMBERG CARLSON WALL PHONE
565E50	PANASONIC KXT-7735B W/DISPLAY	450A14	STROMBERG CARLSON DESK PHONE
566E50	PANASONIC KXT-7720 NO DISPLAY	603B28	SUN MOON STAR-SOLSTAR DKTS (+)
569E47	PANASONIC VB44223A-B	342E05	SUPER TECHNOLOGIES DISPLAY UNIT ID# 710079
682E50	PANASONIC KXT-7625-B	883E49	3COM 3C10402A, 3102
685E54	PANASONIC KXT-7636-B, KXT-7630-B, KXT-7633	882E30	3COM 3C10401SPKRA, 3 101 BASIC
686E12	PANASONIC ADD-ON-MODULE KXT-7603-B	924B38	TADIRAN EKT 321 (24 Button)
936E32	PANASONIC KXT7665-CB	925B30	TADIRAN EKT 321 (16 Button)
565E50	PANASONIC KXT7731	926B22	TADIRAN EKT 321 (8 Button)
130G38	PANASONIC KXT-7667C-B	95C40	TADIRAN "PEM" MODULE
305G55	PANASONIC KXDT343B, DT333B	844C26	TADIRAN DKT-2100 (12B)
318G60	PANASONIC KX-NT305-B/DT-390B ADD ON 60 KEY	34D26	TADIRAN CORAL DKT-1100
319G12	PANASONIC KX-NT303B, 12KEY ADD ON MODULE	35D42	TADIRAN CORAL DKT-2300
320G55	PANASONIC KX-N T346B, KX-DT346B IP	369D41	TADIRAN ESI ESTECH
358G31	PANASONIC KXDT321	238G50	TADIRAN 28DLX
345E40	POLYCOM SOUNDPOINT L	765B08	TALK-A-PHONE INTERCOM
471G40	POLYCOM IP550SIP	389C30	TELEMATRIX TMX400
434C27	PREMIER/NORTHCOM 1A3 NC-612	390C40	TELEMATRIX TMX 208
578C16	PREMIER DELIGHT 270044-MBA-20L	391C43	TELEMATRIX TMX 508
659C12	PREMIER 2554	06G27	TELEMATRIX 763391, Fcc: 2n3chn44578 mtt (TOPSEEL)
04D30	PREMIER #475406	615B28	TEL RAD BX
684E12	PREMIER FCC:GV13RE 19475-TE-1	676C23	TEL RAD DIGITAL BX BASIC CAT 79-240-0000/3
878C13	PROFIT PHONE 707	99A39	TEL RAD KEY-BX 83-050-000/1
741B49	PROSTAR/STC 816	638A52	TEL RAD KEY-BX 73-120-000/8
393C61	PROSTAR 824	639A42	TEL RAD KEY-BX 73-120-000/9
577C34	PROSTAR/SAMSUNG 812	796A40	TEL RAD FEATURE E-STYLE
363C24	ROLM (IBM) MODEL 61000 120	978A39	TEL RAD KEY-BX 73-150-000/1
364C36	ROLM (IBM) MODEL 62000 240	976A44	TEL RAD D SPLY STATION 73-140-000/6
366C52	ROLM (IBM) MODEL 64100A 400	977A40	TEL RAD KEYBX FEATURE STATION 73-150-01014-UG
803C36	ROLM (IBM) MODEL 51001A CONSOLE	263D35	TEL RAD 4 BUTTON DIGITAL W/DISPLAY CATALOG #79-520
462D36	ROLM RP624SL	264D23	TEL RAD 4 BUTTON DIGITAL NO/DISPLAY CATALOG #79-400
491D24	ROLM RP312	380D70	TEL RAD DIGITAL EXEC. 79-100-0000/3
510D20	ROLM 9632 ADD-ON-MODULE	406D31	TEL RAD DIGITAL 79-260-0000/1
822C42	SAMSUNG DCS STD 24B	407D31	TEL RAD DIGITAL 79-200-0000/7
823C36	SAMSUNG DCS AOM	753E39	TEL RAD M-13 cat#79-640-0000B
824C46	SAMSUNG DCS LCD 24B	424A21	TIE EK-1A2E
825C30	SAMSUNG DCS BASIC 12B	568C36	TIE 41650 EK412/416
258D24	SAMSUNG DCS BASIC 7B	503C44	TIE DCX MBKTEL-D89760
259D17	SAMSUNG DCS SINGLE LINE	643B16	TIE SINGLE LINE #89765
741B49	SAMSUNG/PROSTAR/STC816	644B46	TIE MULTI-LINE #88161
393C61	SAMSUNG/PROSTAR 824	735A21	TIE 60015/16/20/21/25/30/31
577C34	SAMSUNG/PROSTAR 812	69C28	TIE 60081A DM32
903C34	SAMSUNG 34 KEY DIGITAL	331C27	TIE I-820
127E28	SAMSUNG FALCON KPDF08SEN/XAR	138C46	TIE 88260B ON YX L/C30BTN
128E38	SAMSUNG FALCON KPDF18SEN/XAR	204B22	TIE MODKEY 60010
129E64	SAMSUNG FALCON KPDF64SDSW/XAR	632A56	TIE ULTRACOMM UAT-64
130E14	SAMSUNG FALCON KPDF14SDSW/XAR	979A22	TIE BUSINESS COM 16
131E48	SAMSUNG FALCON KPDF28SEW/XAR	267B44	TIE BUSINESS COM 36TS
174E64	SAMSUNG DC64B EXPANSION MODULE	266B56	TIE BUSINESS COM 64TS
406E46	SAMSUNG DS24D	139B30	TIE I 1236
561G41	SAMSUNG DS-5014D	264B40	TIE TC 22
17G32	SHORETEL 530	345B40	TIE MER HX
160G34	SHORETEL 230	411B44	TIE HX DISPLAY
161G38	SHORETEL 560	100C61	TIE UAT-64E
315G22	SHORETEL 110	65D57	TMC/SOHO MODEL 4010 HAC M4000/4010
176E29	SIEMENS 530817-57004 W/DISP	753D57	TMC/SOHO MODEL 4010 HACM4000/4010
791E22	SIEMENS OPTIPOINT 500 ENTRY M/N 69901	248E49	TMC/EPIC ET4000
753D57	SOHO/TMC HAC-M4000/M4010	804E44	TMC 4000
133B33	SOUTHWESTERN BELL FS 800	431A25	TOSHIBA 25 SWITCH OLDER MODEL
134B50	SOUTHWESTERN BELL FS 900	433A26	TOSHIBA 26 SWITCH OLD STYLE)
249D26	SOUTHWESTERN BELL DKS 830	304B26	TOSHIBA 26 SWITCH
517D46	SOUTHWESTERN BELL FT484	432A36	TOSHIBA 36 SWITCH
530D44	SOUTHWESTERN BELL DKS925	941A16	TOSHIBA 6000
485D43	SPRINT NORTH 261-181532 (20DCL)	900A27	TOSHIBA 6010
486D38	SPRINT NORTH 261-181476 (W/LCD)		
487D50	SPRINT NORTH 261-193005 (DSS)		
488D29	SPRINT NORTH 261-181474		
775E50	SPRINT 28DLX.BL		
26A12	STANDARD 12 BUTTON DESK PHONE		
19A18	STANDARD 18 BUTTON SX STATION PH		

P/N	Description	P/N	Description
909A36	TOSHIBA 6020		
334C30	TOSHIBA DKT 2010H/ 299C30		
621C33	TOSHIBA DTK 2010SD		
473C40	TOSHIBA DKT-2020S		
298C43	TOSHIBA DKT 2020SD		
443C39	TOSHIBA EKT-6520SD		
33B35	TOSHIBA EKT-103		
445B26	TOSHIBA EKT-6510H		
467B36	TOSHIBA EKT-6520H		
155E18	TOSHIBA DKT2001		
403D20	TOSHIBA DADM2020 ADD ON MODULE		
320E44	TOSHIBA DKT-3020-SD		
321E34	TOSHIBA DKT-3010-SD		
322E30	TOSHIBA DKT-30 10-S		
333E50	TOSHIBA DKT-3014-SD		
334E40	TOSHIBA DKT 3020-S		
717E20	TOSHIBA DKT3001		
733E31	TOSHIBA DKT-3007SD		
162G30	TOSHIBA DP5018S (ALSO COMTEL)		
144G44	TOSHIBA DP50 32-SD (ALSO COMTEL)		
145G34	TOSHIBA DP5022-SDM (ALSO COMTEL)		
255G20	TOSHIBA DP5008		
182G44	TOSHIBA IPT2020-SD		
183G34	TOSHIBA IP2010-SD		
185D50	TRANSTEL SUPERKEY SK-EKT/D		
443E46	TRANSTEL TD-DK1, D/G/ TCI		
720D52	ULTRATEC 1000		
706D51	ULTRATEC SUPERCOM 4400		
719D73	ULTRATEC SUPERPRINT PRO80		
720D52	ULTRATEC UNIVERSAL TELE		
867E45	VERTICAL NETOWRKS VN24DDS		
236G37	VERTICAL 480i (ALSO AASTRA)		
237G47	VERTICAL SBX IP320 -24BTN, PART#4024-00		
291G25	VERTICAL WAVE EDGE 700		
838C43	VODAVI STARPLUS ENHANCED SP61612/61614		
46D26	VODAVI STARPLUS 1411-XX EIS-85500		
144D40	VODAVI STARPLUS SP7312-71		
143D28	VODAVI STARPLUS SP7311-71		
142D43	VODAVI STARPLUS SP7314-71		
180D12	VODAVI STARPLUS II HAC-2601 HAC-2602		
758D36	VODAVI INFINITE IN9012-71		
769D27	VODAVI STARPLUS/TRIAD TR9011-71		
770D48	VODAVI STARPLUS/TRIAD TR9015-71		
771D36	VODAVI STARPLUS/TRIAD TR9014-71		
852D48	VODAVI INFINITE IN9015-71		
945D15	VODAVI 2701-00		
71E22	VODAVI INFINITE IN9011-71		
132E28	VODAVI 2702-08		
133E29	VODAVI 2703-08		
134E31	VODAVI 2704-08		
135E32	VODAVI 2705-00		
136E38	VODAVI 2706-00		
497E29	VODAVI 3012-71 W/DISPLAY		
498E57	VODAVI 3515-71 W/DISPLAY- STS		
842C27	VODAVI STARPLUS BASIC SP61610		
28D46	VODAVI STARPLUS W/DISPLAY 1412-XX/1414 EIS-85100/EIS-85300		
513E57	VODAVI 3015-71 W/DISPLAY		
108G26	VODAVI 3011-71, XTS-IP 8BUTTON ENHANCED		
456B64	WALKER MARATON MK-30E EXEC-OA-TEL		
457B37	WALKER MK-30E E18		
934B47	WIN 16S MK-100D		
711E55	WIN MK-44 OCT/32-D		
710E43	WIN MK-44 OCT/20-D		
214G47	XBLUE 45P		
215G46	XBLUE 16DTE/16EKT W/DISPLAY		

If you do not see your model listed, please call us. We will be happy to design a custom "VIZIFLEX SEEL" with a minimum initial order of 50 seels. We will also require the use of your telephone for two to three. The telephone will be returned to you undamaged.

P/N Description

P/N Description
